



## **Body Fluid Identification Test No. 22-5781 Summary Report**

---

Each participant received a sample pack containing six items for examination. Participants were asked to examine each item and report the body fluid(s) identified. Data were returned from 232 participants and are compiled into the following tables:

<b>Report Contents:</b>	<u>Page</u>
<a href="#"><u>Manufacturer's Information</u></a>	2
<a href="#"><u>Summary Comments</u></a>	3
<a href="#"><u>Key for Screening Tests Used</u></a>	4
<a href="#"><u>Table 1: Screening Conclusions &amp; Test(s) Performed</u></a>	5
<a href="#"><u>Table 2: Additional Comments</u></a>	134
<a href="#"><u>Appendix: Data Sheet</u></a>	

This report contains the data received from the participants in this test. Since these participants are located in many countries around the world, and it is their option how the samples are to be used (e.g., training exercise, known or blind proficiency testing, research and development of new techniques, etc.), the results compiled in the Summary Report are not intended to be an overview of the quality of work performed in the profession and cannot be interpreted as such. The Summary Comments are included for the benefit of participants to assist with maintaining or enhancing the quality of their results. These comments are not intended to reflect the general state of the art within the profession.

Participant results are reported using a randomly assigned "WebCode". This code maintains participant's anonymity, provides linking of the various report sections, and will change with every report.

## Manufacturer's Information

Each sample pack consisted of six separate items for testing. Two items contained non-scenario related swabs (Items 1 and 2), two items contained swabs that related to the provided scenario (Items 3 and 4), and two items (Items 5 and 6) contained complete items of evidence that also related to the provided scenario. Participants were asked to examine Items 1 and 2 for body fluids that they typically encounter in routine casework examinations. For Items 3 through 6, the participants were asked to examine the items using the information provided by the scenario for guidance.

### SAMPLE PREPARATION:

The stain on Item 1 (Swabs: white plastic handle) was prepared using human blood. The stain on Item 2 (Swabs: pink plastic handle) was prepared using human saliva. The stain on Item 3 (Swabs: blue plastic handle) was prepared using a suspension of human blood and semen. The stain on Item 4 (Swabs: yellow plastic handle) was prepared using a suspension of human blood and saliva. The stain on Item 5 (red rag) was prepared using human blood. The stain on Item 6 (sanitary pad) was prepared using human semen. For the swab samples where semen was used, the semen was mixed in a 1:1 ratio with TAE buffer. In all samples where a mixture is present, the two body fluids were mixed in a 1:1 ratio. Stains from different sources were prepared at separate times and were packaged once thoroughly dried.

### SAMPLE SET ASSEMBLY:

Each sample set contained the following: questioned swabs (Items 1, 2, 3, and 4), two questioned complete items of evidence (Item 5 and 6), and one package of unused swabs for substrate control. All items were packaged and sealed into individual envelopes, which were then packaged together.

### VERIFICATION:

Laboratories that conducted predistribution analysis of the samples reported results which confirmed the presence of body fluids that made up each item.

### *Sample Preparation Schedule*

<u>Item</u>	<u>Substrate</u>	<u>Body Fluid</u>	<u>Volume</u>
1	4 Swabs: white plastic handle	Blood	100 $\mu$ L per swab
2	4 Swabs: pink plastic handle	Saliva	100 $\mu$ L per swab
3	4 Swabs: blue plastic handle	Blood & Semen Mixture	100 $\mu$ L per swab
4	4 Swabs: yellow plastic handle	Blood & Saliva Mixture	100 $\mu$ L per swab
5	Red Rag	Blood	100 $\mu$ L
6	Sanitary Pad	Semen	100 $\mu$ L

Completed sample sets were stored at -20°C until shipment on March 21, 2022, following receipt of predistribution results.

## **Summary Comments**

The 22-5781 Body Fluid Identification test was designed to allow participants to assess their proficiency in the identification of stains that may contain dried body fluids. Each participant received six items for testing; four items were swabs and two were whole evidence items. A scenario was not provided for Items 1 and 2; participants were requested to test for body fluids that they typically encounter in casework. A scenario was provided for Items 3 - 6, and participants were asked to treat these items as they would normal casework, testing for the fluids they deemed necessary after reading the scenario.

The following paragraphs discuss the overall conclusions reported for each item. Individual tests and the respective results will only be mentioned if a trend of participant results was noted.

Item 1 consisted of four swabs containing blood. The majority of responding participants reported the expected results: "Positive/Indicative" for blood (100%), "Negative" for semen (99%), and "Negative" for saliva (96%).

Item 2 consisted of four swabs containing saliva. The majority of responding participants reported the expected results: "Negative" for blood (98%), "Negative" for semen (99%), and "Positive/Indicative" for saliva (99%).

Item 3 consisted of four swabs containing a mixture of blood and semen. The majority of responding participants reported the expected results: "Positive/Indicative" for blood (100%), "Positive/Indicative" for semen (100%), and "Negative" for saliva (92%).

Item 4 consisted of four swabs containing a mixture of blood and saliva. The majority of responding participants reported the expected results: "Positive/Indicative" for blood (100%), "Negative" for semen (99%), and "Positive/Indicative" for saliva (99%).

Item 5 consisted of a red rag containing blood. The majority of responding participants reported the expected results: "Positive/Indicative" for blood (100%), "Negative" for semen (99%), and "Negative" for saliva (95%).

Item 6 consisted of sanitary pad containing semen. The majority of responding participants reported the expected results: "Negative" for blood (99%), "Positive/Indicative" for semen (99%), and "Negative" for saliva (97%).

## **Key for Screening Tests Used**

Participants were asked to use, where possible, the following chart of abbreviated screening test names. This was not an all inclusive list and was not designed to determine what tests should be performed. Participants were advised that tests not on this list may be used for screening.

<u>Test</u>	<u>Abbreviation</u>
Acid Phosphatase	AP
Alternate Light Source	ALS
Kastle Meyer	KM
Leucomalachite Green	LMG
Microscopic	Micro
Ortho-tolidine	O-tol
Phenolphthalein-Tetramethyl benzidine	PTMB
Prostate Specific Antigen	PSA
Rapid Stain Identification	RSID
Tetramethyl benzidine	TMB

# Screening Conclusions & Test(s) Performed

Indicate the overall conclusion from the results of the screening tests performed.

Table 1 - Item 1  
Evidence - Four white plastic swabs containing Blood

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
24D4LA	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> PSA <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	The [Laboratory] does not conduct forensic serological tests for Saliva. <b>Conclusion:</b> Not Tested
24XLKP	<b>Conclusion:</b> Not Tested	AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
27ZRVP	HEMASTIX <i>Positive/Indicative</i> LUMINOL <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	BRENTAMINE <i>Negative</i> <b>Conclusion:</b> Negative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
2HAFUE	KM <i>Positive/Indicative</i> Hemastix <i>Positive/Indicative</i> HemaTrace (ABAcad) <i>Positive/Indicative</i> Luminol <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
2PGRAY	LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	Amylase Diffusion <i>Negative</i> <b>Conclusion:</b> Negative
2QN273	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
3EC4Q2	LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> PSA <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	Amylase Radial Diffusion <i>Inconclusive</i> <b>Conclusion:</b> Inconclusive
3HUDM7	TMB <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> Hemastix <i>Positive/Indicative</i> Luminol <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
3KX989	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
3KXA9U	O-tol <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative

Table 1 - Item 1  
Evidence - Four white plastic swabs containing Blood

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
3QHEXN	LMG	Positive/Indicative	see additional comments		see additional comments	
	<b>Conclusion:</b> No Response		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
3RYBLG	HEMASTIX	Positive/Indicative	BRENTAMINE	Negative	NO AVAILABLE TEST FOR Saliva	
	LUMINOL	Positive/Indicative				
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
3U376K	HEMASTIX	Positive/Indicative	BRENTAMINE	Negative	NO AVAILABLE TEST FOR Saliva	
	LUMINOL	Positive/Indicative				
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
447TM9	Micro	Positive/Indicative	AP	Negative	RSID Negative	
	KM	Positive/Indicative	Micro	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
4ABGEP	SERATEC HemDirect	Positive/Indicative	Christmas Tree	Negative	SERATEC Amylase Test Negative	
			Immunochromatography Test			
			Identification of Human Semen			
			(RSID-Semen)	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
4B9RAR	HemDirect Hemoglobin Seratec	Positive/Indicative	Christmas Tree Stain (Micro)	Negative	Amylase test Seratec Negative	
			PSA Seratec	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
4BN4RW	LMG	Positive/Indicative	AP	Negative	Amylase Diffusion Negative	
	HemaTrace	Positive/Indicative	Micro	Negative		
			PSA	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
4E79LL	KM	Positive/Indicative	RSID-Semen	Negative	RSID-Saliva Negative	
	OBTI	Positive/Indicative	PSA	Negative		
			Sperm Hyliter PI	Negative		
			AP	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
4JLRRR	Micro	Positive/Indicative	AP	Negative	RSID Negative	
	KM	Positive/Indicative	Micro	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
4K8M4G	Hemastix (HemaTrace)	Positive/Indicative	Brentamine (AP)	Negative	According to SOP no presumptive tests conducted on the Saliva swabs	
	Luminol	Positive/Indicative				
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
4L7NCT	PTMB	Positive/Indicative				
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	

Table 1 - Item 1  
Evidence - Four white plastic swabs containing Blood

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
4LA7EY	KM <i>Positive/Indicative</i> Modified Takayama <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	Phadebas Amylase <i>Negative</i> <b>Conclusion:</b> Negative
<u>Other Tests Performed</u> Species Origin - HemaTrace <i>Positive/Indicative</i> Urine - Creatinine <i>Negative</i> Fecal Material - Urobilinogen <i>Negative</i>			
4QDG2H	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested
4UKGK4	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
4V7FET	SERATEC HemDirect <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Christmas tree <i>Negative</i> Immunochromatography test Rapid Stain Identification of Human Semen (RSID-Semen) <i>Negative</i> SERATEC-PSA <i>Negative</i> <b>Conclusion:</b> Negative	SERATEC Amylase Test <i>Negative</i> <b>Conclusion:</b> Negative
4XZ2BQ	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Negative</i> AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
62TKQU	PTMB <i>Positive/Indicative</i> RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	Phadebas Tablets <i>Negative</i> <b>Conclusion:</b> Negative
<u>Other Tests Performed</u> Urine - Uritrace <i>Negative</i>			
66TUYA	HT, Hemastix, KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID-Saliva <i>Negative</i> <b>Conclusion:</b> Negative
67PA82	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
68KVZR	PTMB <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	Phadebas Tablet <i>Negative</i> <b>Conclusion:</b> Negative
<u>Other Tests Performed</u> Urine - Uritrace <i>Negative</i>			
6B3X4Q	Kastle Meyer/3% Hydrogen Peroxide <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Acid Phosphatase <i>Negative</i> Micro (In-house prepped) <i>Negative</i> <b>Conclusion:</b> Negative	RSID-Saliva <i>Negative</i> <b>Conclusion:</b> Negative

Table 1 - Item 1  
Evidence - Four white plastic swabs containing Blood

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
6CWLLL	PTMB	Positive/Indicative	AP, PSA, Micro	Negative	Phadebas	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
6H3EEW	Phenolphthalein	Positive/Indicative	p30	Negative	Phadebas	Negative
			Micro	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
6PKQLW	Hemastix	Positive/Indicative	AP	Negative	RSID	Negative
	HemaTrace	Positive/Indicative	Micro	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
6VPH62	Hemastix	Positive/Indicative				
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
	<u>Other Tests Performed</u>					
	Alternate Light Source Negative					
776VCW	LMG	Positive/Indicative	AP	Negative	Saliva testing is not performed at the laboratory.	
	HemaTrace	Positive/Indicative	PSA	Negative		
			Micro	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
7CTBC2	TMB	Positive/Indicative	AP	Negative	RSID	Negative
	HEMASTIX	Positive/Indicative				
	HemaTrace	Positive/Indicative				
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
7CWXP9	Phenolphthalein	Positive/Indicative	Acid Phosphatase	Negative	RSID	Negative
	Hemastix	Positive/Indicative				
	HemaTrace	Positive/Indicative				
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
7U9PLJ	KM	Positive/Indicative	AP	Negative	RSID-Saliva Negative	
	OBTI	Positive/Indicative	RSID-Semen	Negative		
			PSA	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
7V63AW	KM	Positive/Indicative	AP	Negative	Laboratory does not test for Saliva	
			Micro	Negative		
			PSA	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
89PX43	KM	Positive/Indicative	PSA	Negative	[Laboratory] does not routinely test for Saliva.	
	HemaTrace	Positive/Indicative	Micro	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
8NM624	KM	Positive/Indicative	AP	Negative	RSID	Negative
			Micro	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	



Table 1 - Item 1  
Evidence - Four white plastic swabs containing Blood

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
8QN8Q6	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
8UNBTZ	LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	Amylase Radial Diffusion <i>Inconclusive</i> <b>Conclusion:</b> Inconclusive
92M92N	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
94QAGR	BLUESTAR (LUMINOL) <i>Positive/Indicative</i> HEXAGON OBTI TEST <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	Phadebas <i>Negative</i> <b>Conclusion:</b> Negative
97KPG4	KM <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
987KRA	HEMASTIX <i>Positive/Indicative</i> LUMINOL <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	BRENTAMINE <i>Negative</i> <b>Conclusion:</b> Negative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
9J6AWQ	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> PSA <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
9RWMWQ	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
9TC7FM	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
9TT6UK	LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Micro <i>Negative</i> AP <i>Negative</i> <b>Conclusion:</b> Negative	Amylase Diffusion <i>Negative</i> <b>Conclusion:</b> Negative
A49C8Z	LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
A4L4XW	KM <i>Positive/Indicative</i> HT <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
AARLDN	LMG, HemDirect <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	Saliva is not tested <b>Conclusion:</b> Not Tested

Table 1 - Item 1  
Evidence - Four white plastic swabs containing Blood

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
AB9QVM	O-tol HemaTrace	Positive/Indicative Positive/Indicative	AP	Negative	RSID	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
AMYUTL	KM OBTI	Positive/Indicative Positive/Indicative	AP PSA RSID-Semen Sperm HY-Liter PI	Negative Negative Negative Negative	RSID-Saliva	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
AP8KHP	Phenolphthalein	Positive/Indicative	Microscopic Examination Seminal Fluid - p30	Negative Negative	Phadebas	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
AQW9HW	KM	Positive/Indicative	ALS	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
AW84KK	KM	Positive/Indicative	AP	Negative	Amylase	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
AYDKY4			AP	Negative		
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
B2BMZP	LMG	Positive/Indicative	AP Micro PSA	Negative Negative Negative	Amylase Diffusion	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
B3839F	KM	Positive/Indicative	Micro p30	Negative Negative		Not validated procedure
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
B4JQUZ	KM HemaTrace	Positive/Indicative Positive/Indicative	Micro PSA	Negative Negative		Saliva testing not offered by our laboratory
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
BBLR7N	LMG RSID	Positive/Indicative Positive/Indicative	AP RSID	Negative Negative	RSID	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
BCFFPJ	Visual examination for Blood KM	Positive/Indicative Positive/Indicative	AP Microscopic examination for Sperm heads	Negative Negative	Phadebas tube test	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
	<b>Other Tests Performed</b>					
	Urine - Urea <i>Inconclusive</i>					
	Urine - Creatinine <i>Inconclusive</i>					
	Faeces - Urobilinogen Tube Test <i>Negative</i>					

Table 1 - Item 1  
Evidence - Four white plastic swabs containing Blood

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
BFWV63	Micro KM	Positive/Indicative Positive/Indicative	AP Micro	Negative Negative	RSID	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
BHL7WV	KM	Positive/Indicative	ALS	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
BKMANH	LMG	Positive/Indicative	AP Micro	Negative Negative	Amylase Diffusion	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
BQBWEG	HemDirect Seratec	Positive/Indicative	Micro PSA	Negative Negative	Amylase Seratec	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
BT7FKP	LMG HemaTrace	Positive/Indicative Positive/Indicative	AP PSA	Negative Negative	Amylase Diffusion	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
BUB9BG	HemDirect Hemoglobin (SERATEC)	Positive/Indicative	Christmas Tree Stain Slide (Micro) PSA Semiquant (SERATEC)	Negative Negative	Amylase Test (SERATEC)	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
BVQAGP	LMG ([Laboratory]: Leuco-Malachite)	Positive/Indicative	AP	Negative	[Laboratory] does not employ tests for Saliva	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
C8J7Z3	Hemastix HemaTrace Phenolphthalein Luminol	Positive/Indicative Positive/Indicative Positive/Indicative Positive/Indicative	AP	Negative	RSID	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
CBXYV3	O-tol HemaTrace	Positive/Indicative Positive/Indicative	p30 AP Microscopy	Negative Negative Negative	Phadebas RSID	Negative Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
CFCELU	Phenolphthalein Takayama	Positive/Indicative Positive/Indicative	Acid Phosphatase	Negative	Phadebas	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
	<b>Other Tests Performed</b>					
	Species - HemaTrace Positive/Indicative					
	Urine - Creatinine Negative					
	Fecal Matter - Urobilinogen Negative					
CNJDUV	KM, Hexagon OBTI	Positive/Indicative	AP	Negative	Phadebas	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	

Table 1 - Item 1  
Evidence - Four white plastic swabs containing Blood

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
CUTGYB	KM <i>Positive/Indicative</i> <b>Conclusion:</b> No Response	Micro, p30 <i>Negative</i> <b>Conclusion:</b> No Response	<b>Conclusion:</b> Not Tested
D7426P	Visual <i>Positive/Indicative</i> LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID-Saliva <i>Negative</i> <b>Conclusion:</b> Negative
D94JU6	HEMASTIX <i>Positive/Indicative</i> LUMINOL <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	BRENTAMINE <i>Negative</i> <b>Conclusion:</b> Negative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
DF7NRF	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	BCIP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
	<u>Other Tests Performed</u> Amylase Diffusion <i>Inconclusive</i>		
DKXZJ7	Hemastix (TMB) <i>Positive/Indicative</i> Luminol Test <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Brentamine test (AP) <i>Negative</i> <b>Conclusion:</b> Negative	There is no presumptive test for Saliva in Evidence Recovery (ER). Swab will be submitted for DNA Process (Analysis) <b>Conclusion:</b> Not Tested
DXNMY	<b>Conclusion:</b> Not Tested	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
E3A4KN	LMG <i>Positive/Indicative</i> Ouchterlony <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Micro <i>Negative</i> PSA <i>Negative</i> <b>Conclusion:</b> Negative	Amylase Radial Diffusion <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative
EC6X2V	LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> Visual Examination <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
EGZPDX	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
EJN4ZM	Phenolphthalein <i>Positive/Indicative</i> Modified Takyama <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Acid Phosphatase <i>Negative</i> <b>Conclusion:</b> Negative	Phadebas <i>Negative</i> <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> HemaTrace <i>Positive/Indicative</i> Creatinine <i>Negative</i> Urobilinogen <i>Negative</i>		

Table 1 - Item 1  
Evidence - Four white plastic swabs containing Blood

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
ELP4ZK	KM HemaTrace	Positive/Indicative Positive/Indicative	AP PSA Micro	Negative Negative Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
EM3NZG	Seratec Hem LN 200076 D.D: 22-09	Positive/Indicative	Christmas tree RSID LN 092120S1 D. D. 22-09	Negative Negative	Seratec AMY LN 200078 D.D: 22-09	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
EPBXTE	Human Blood	Positive/Indicative	CHRISTMAS TREE SemenOGELINA	Negative Negative	Human Saliva	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
ERGE8W	KM	Positive/Indicative	AP	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
EYDBVZ	Hemastix HemaTrace	Positive/Indicative Positive/Indicative	AP	Negative	RSID	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
FATH8U	LMG HemaTrace Visual	Positive/Indicative Positive/Indicative Positive/Indicative	AP	Negative	RSID	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
FC3HEM	KM HemaTrace	Positive/Indicative Positive/Indicative	AP test	Negative	Blue paper test	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
FHJBBD	Kastle-Meyer	Positive/Indicative	Acid phosphatase Microscopy and Christmas Tree staining	Negative Negative	Phadebas tube test	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
FKR6D6	TMB (Hstix) Luminol	Positive/Indicative Positive/Indicative	AP (Brentamine)	Negative	No presumptive test for Saliva	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
FP8NMZ	KM HemaTrace	Positive/Indicative Positive/Indicative	AP p30 Micro	Negative Negative Negative	Phadebas	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
FQ2ELM	HEMASTIX LUMINOL	Positive/Indicative Positive/Indicative	BRENTAMINE	Negative	NO AVAILABLE TEST FOR Saliva	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	

Table 1 - Item 1  
Evidence - Four white plastic swabs containing Blood

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
FQHTUW	Hemastix KM HemaTrace	Positive/Indicative Positive/Indicative Positive/Indicative	AP Micro	Negative Negative	RSID	Negative
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative
FXXDW9	KM OBTI	Positive/Indicative Positive/Indicative	AP RSID-Semen PSA Sperm Hy-Liter PI	Negative Negative Negative Negative	RSID-Saliva	Negative
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative
G2QWBC	Visual, KM	Positive/Indicative	AP, Microscopy	Negative	Phadebas Tube	Negative
		<b>Conclusion:</b> No Response		<b>Conclusion:</b> No Response		<b>Conclusion:</b> No Response
G43C6D	Visual and KM	Positive/Indicative	AP Xmas Tree Slide	Negative Negative	Phadebas	Negative
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative
G4LB8G	LMG	Positive/Indicative	AP	Negative		
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested
G6R26K	LMG	Positive/Indicative	AP Micro PSA	Negative Negative Negative	Amylase Diffusion	Negative
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative
GD9E9P	KM	Positive/Indicative	ALS	Negative		
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested
GDUVL8	KM OBTI	Positive/Indicative Positive/Indicative	AP RSID-Semen PSA	Negative Negative Negative	RSID-Saliva	Negative
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative
GL4D2J	KM HemaTrace	Positive/Indicative Positive/Indicative	AP PSA Micro	Negative Negative Negative		
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested
GP7BEX	TMB HemaTrace	Positive/Indicative Positive/Indicative	AP RSID Micro	Negative Negative Negative	Phadebas	Negative
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative
GUZ6CY	KM, ABACard HemaTrace	Positive/Indicative Positive/Indicative	AP, Sperm search	Negative	[Laboratory] biology does not test swabs for the presence of Saliva (using the Phadebas press test).	
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested

Table 1 - Item 1  
Evidence - Four white plastic swabs containing Blood

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
HBXUYF	PTMB <i>Positive/Indicative</i> RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Not online with seminal fluid screening <b>Conclusion:</b> Not Tested	Not online with Saliva screening <b>Conclusion:</b> Not Tested
HKMHYN	KM <i>Positive/Indicative</i> Modified Takayama <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	Phadebas <i>Negative</i> <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> Species Origin - HemaTrace <i>Positive/Indicative</i> Urine - Creatinine <i>Negative</i> Fecal Matter - Urobilinogen <i>Negative</i>		
HLFHP9	HEMASTIX <i>Positive/Indicative</i> LUMINOL <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	BRENTAMINE <i>Negative</i> <b>Conclusion:</b> Negative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
HQB89Z	HEMASTIX <i>Positive/Indicative</i> LUMINOL <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	BRENTAMINE <i>Negative</i> <b>Conclusion:</b> Negative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
HYKPTJ	KM <i>Positive/Indicative</i> Modified Takayama <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	Phadebas Amylase <i>Negative</i> <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> Urine-Creatinine <i>Negative</i> Fecal Material-Urobilinogen <i>Negative</i>		
J2T2AL	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
J8YXUL	KM <i>Positive/Indicative</i> Heme-direct <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	No Saliva testing at Lab <b>Conclusion:</b> Not Tested
JGGLF8	HEMASTIX <i>Positive/Indicative</i> LUMINOL <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	BRENTAMINE <i>Negative</i> <b>Conclusion:</b> Negative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
K4Q6CR	KM, Hemastix, HemaTrace, Luminol <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID Saliva <i>Negative</i> <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> Body Fluid - Test Performed: ALS <i>Negative</i>		

Table 1 - Item 1  
Evidence - Four white plastic swabs containing Blood

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
K8PF9R	KM HemaTrace	Positive/Indicative Positive/Indicative	AP	Negative	RSID	Negative
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Negative
KBAB8D	TMB	Positive/Indicative	AP PSA Microscopic	Negative Negative Negative	alpha-Amylase test card	Negative
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Negative
KED2FE	KM HemaTrace	Positive/Indicative Positive/Indicative	AP PSA Micro	Negative Negative Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
KF2JBK	KM HemaTrace	Positive/Indicative Positive/Indicative	AP PSA Micro	Negative Negative Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
KMLH4D	LMG	Positive/Indicative	AP	Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
	<u>Other Tests Performed</u>					
	HEMDIRECT Positive/Indicative					
KWN32Z	H/stix Luminol (HemaTrace) KM	Positive/Indicative Positive/Indicative	Brentamine (AP)	Negative	As per SOP we don't do prelim testing for Saliva	
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
KYVDX4	KM OBTI	Positive/Indicative Positive/Indicative	AP RSID-Semen PSA Sperm Hy-Liter PI	Negative Negative Negative Negative	RSID-Saliva	Negative
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Negative
L47NTJ	KM	Positive/Indicative	ALS	Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
L7D2GC	LMG	Positive/Indicative	AP	Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
L9YRHG	KM RSID-Blood	Positive/Indicative Positive/Indicative	AP TEST	Negative	RSID-Saliva	Negative
	<b>Conclusion:</b>	No Response	<b>Conclusion:</b>	No Response	<b>Conclusion:</b>	No Response
LA84XW	HEMASTIX LUMINOL	Positive/Indicative Positive/Indicative	BRENTAMINE	Negative	NO AVAILABLE TEST FOR Saliva	
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested



Table 1 - Item 1  
Evidence - Four white plastic swabs containing Blood

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
LBC97F	KM <i>Positive/Indicative</i> Visual <i>Positive/Indicative</i>		AP <i>Negative</i>		Phadebas Blue Paper <i>Negative</i>	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
LNPRB2	KM <i>Positive/Indicative</i> OBTI <i>Positive/Indicative</i>		AP <i>Negative</i> PSA <i>Negative</i> RSID-Semen <i>Negative</i>		RSID-Saliva <i>Negative</i>	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
M2XQ6T	TMB <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i>		AP <i>Negative</i> PSA <i>Negative</i>		RSID <i>Negative</i>	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
M6CLLQ	TMB <i>Positive/Indicative</i>		Microscopy <i>Negative</i> p30 <i>Negative</i>		Phadebas <i>Negative</i>	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
MGNXUE	LMG <i>Positive/Indicative</i>		AP <i>Negative</i> Micro <i>Negative</i> PSA <i>Negative</i>		Amylase Diffusion <i>Negative</i>	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
MH42MK	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i>		AP <i>Negative</i>			
	<b>Conclusion:</b> No Response		<b>Conclusion:</b> No Response		<b>Conclusion:</b> Not Tested	
MHGTDG	KM - Hemophan (paper test for Blood erythrocytes, haemoglobin) by Erba Lachema - non-specific test for Blood <i>Positive/Indicative</i> FOB - cassette test for determination of faecal occult Blood by NADAL - specific test for Human Blood <i>Positive/Indicative</i>		AP - Phosphatesmo (paper test for the determination of acid phosphatase) by Macherey-Nagel <i>Negative</i> PSA - cassette test for prostate specific antigen by SERATEC <i>Negative</i>		RSID-Saliva <i>Negative</i>	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
MLM86G	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i>		AP <i>Negative</i>		RSID <i>Negative</i>	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
MP2R6B	Seratec HemDirect <i>Positive/Indicative</i>		Micro <i>Negative</i> Seratec PSA <i>Negative</i>		Seratec Amylase Test <i>Negative</i>	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
MUB6RF	KM <i>Positive/Indicative</i>		AP <i>Negative</i> Micro <i>Negative</i> PSA <i>Negative</i>			
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	

Table 1 - Item 1  
Evidence - Four white plastic swabs containing Blood

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
MVA9KQ	Hemastix KM Luminol HemaTrace	Positive/Indicative Positive/Indicative Positive/Indicative Positive/Indicative	AP	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
MW4W4L	KM HemaStix HemaTrace	Positive/Indicative Positive/Indicative Positive/Indicative	AP	Negative	RSID	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
MZLBBT	TMB HemaTrace	Positive/Indicative Positive/Indicative	AP	Negative	RSID	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
N4UXGG	KM	Positive/Indicative	ALS	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
NPXL8D	KM HemDirect Cassette	Positive/Indicative Positive/Indicative	AP	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
NXRWAV	TMB - Hstix Luminol	Positive/Indicative Positive/Indicative	AP (Brent)	Negative	No presumptive test for Saliva	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
P3FYU7	SERATEC-SANGRE	Positive/Indicative	MicroSCOPIO RSID-Semen	Negative Negative	SERATEC-Saliva	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
P69KR4	LMG HemaTrace	Positive/Indicative Positive/Indicative	AP Micro	Negative Negative	Amylase Diffusion	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
P8RWB7	LMG	Positive/Indicative	AP	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
PAX8GH	[Participant did not return results for Item 1]					
PEULCK	KM HemaTrace	Positive/Indicative Positive/Indicative	PSA Micro	Negative Negative	The [Laboratory] does not perform tests for Saliva	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
PF4ZDY	KM OBTI	Positive/Indicative Positive/Indicative	AP RSID-Semen PSA	Negative Negative Negative	RSID-Saliva	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	

Table 1 - Item 1  
 Evidence - Four white plastic swabs containing Blood

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
PN2NBQ	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> Hemastix <i>Positive/Indicative</i> Luminol <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	RSID Saliva <i>Negative</i> <b>Conclusion:</b> Negative
PU4R3A	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> PSA <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
Q62YBE	Leucomalachite Green <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	No tests available. <b>Conclusion:</b> Not Tested	No tests available. <b>Conclusion:</b> Not Tested
QC3ALD	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
QDWVJB	KM <i>Positive/Indicative</i> Modified Takayama <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	Phadebas <i>Negative</i> <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> Blood - HemaTrace <i>Positive/Indicative</i> Urine - Creatinine <i>Negative</i> Fecal Material - Urobilinogen <i>Negative</i>		
QGHK4N	<b>Conclusion:</b> Not Tested	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
QP966F	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
QQ3V99	ALS <i>Negative</i> KM <i>Positive/Indicative</i> RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> ALS <i>Negative</i> RSID <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	ALS <i>Negative</i> RSID <i>Negative</i> <b>Conclusion:</b> Negative
QRFNNA	KM <i>Positive/Indicative</i> <b>Conclusion:</b> No Response	AP SPOT <i>Negative</i> <b>Conclusion:</b> No Response	<b>Conclusion:</b> Not Tested
QYE6K9	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> PSA <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested

Table 1 - Item 1  
Evidence - Four white plastic swabs containing Blood

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
R3UUJC	KM HemaTrace <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative	PSA Micro-Sperm <b>Conclusion:</b> Negative	Negative Negative	Saliva RSID <b>Conclusion:</b> Negative	Negative
R6ZHWF	Phenolphthalein HemaTrace <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative	Acid Phosphatase <b>Conclusion:</b> Negative	Negative	RSID-Saliva <b>Conclusion:</b> Negative	Negative
RJ28Y9	Hemastix RSID Blood <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative	AP RSID Semen <b>Conclusion:</b> Negative	Negative Negative	RSID Saliva <b>Conclusion:</b> Negative	Negative
RJGF2G	KM TMB HemaTrace Hemastix Luminol <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative Positive/Indicative Positive/Indicative Positive/Indicative	AP PSA Micro <b>Conclusion:</b> Negative	Negative Negative Negative	RSID <b>Conclusion:</b> Negative	Negative
RKCZMV	KM OBTI <b>Conclusion:</b> Positive/Indicative	Positive/Indicative	AP RSID-Semen PSA Sperm Hy-Liter PI <b>Conclusion:</b> Negative	Negative Negative Negative Negative	RSID-Saliva <b>Conclusion:</b> Negative	Negative
RQ44Y8	KM HemaTrace <b>Conclusion:</b> Positive/Indicative	Positive/Indicative	AP PSA Micro <b>Conclusion:</b> Negative	Negative Negative Negative	<b>Conclusion:</b> Not Tested	
RRATXA	HEMASTIX LUMINOL <b>Conclusion:</b> Positive/Indicative	Positive/Indicative	BRENTAMINE <b>Conclusion:</b> Negative	Negative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested	
RT728F	TMB HemaTrace <b>Conclusion:</b> Positive/Indicative	Positive/Indicative	AP Micro <b>Conclusion:</b> Negative	Negative Negative	RSID <b>Conclusion:</b> Negative	Negative
RT9VQL	see comments section <b>Conclusion:</b> Not Tested		AP <b>Conclusion:</b> Negative	Negative	see comments section <b>Conclusion:</b> Not Tested	
RX2XQE	KM <b>Conclusion:</b> Positive/Indicative	Positive/Indicative	ALS <b>Conclusion:</b> Negative	Negative	<b>Conclusion:</b> Not Tested	
RXG4AB	Hemochromogen <b>Conclusion:</b> Positive/Indicative	Positive/Indicative	AP Micro PSA <b>Conclusion:</b> Negative	Negative Negative Negative	<b>Conclusion:</b> Not Tested	

Table 1 - Item 1  
Evidence - Four white plastic swabs containing Blood

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
RYVJNC	KM HemaTrace	Positive/Indicative Positive/Indicative	AP	Negative	RSID	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
T6UMQF	TMB Hemastix HemaTrace	Positive/Indicative Positive/Indicative Positive/Indicative	AP	Negative	RSID	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
TDB779	LMG	Positive/Indicative	AP	Negative	Amylase Diffusion	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
TJXU6K			AP	Negative		
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
TK3Q4U	HEMASTIX LUMINOL	Positive/Indicative Positive/Indicative	BRENTAMINE	Negative	NO AVAILABLE TEST FOR Saliva	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
TLZRC7	LMG	Positive/Indicative	AP Micro PSA	Positive/Indicative Negative Negative	Amylase Diffusion	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
TPKL98	Hemophan FOB	Positive/Indicative Positive/Indicative	PSA RSID Semen	Negative Negative	RSID Saliva	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
TPY8KU	KM HemaTrace	Positive/Indicative Positive/Indicative				
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
U2DKJA	Visual KM HemaTrace	Positive/Indicative Positive/Indicative Positive/Indicative	Visual ALS AP Micro	Negative Positive/Indicative Negative Negative	Visual ALS RSID	Negative Positive/Indicative Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
U4ZY9K			AP	Negative		
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
UA43XH			AP Micro	Negative Negative		
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	

Table 1 - Item 1  
Evidence - Four white plastic swabs containing Blood

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
UBHEU3	Visual O-tol HemaTrace	Positive/Indicative Positive/Indicative Positive/Indicative	ALS AP	Negative Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
UBYTX6	O-tol HEX-OBTI	Positive/Indicative Positive/Indicative	AP NA	Negative NA		Our Agency does not test for Saliva
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
UD69B4	KM HemaTrace	Positive/Indicative Positive/Indicative	AP PSA	Negative Negative		Phadebas Negative
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Negative
UJAUJ7	ALS O-tol OBTI	Positive/Indicative Positive/Indicative Positive/Indicative	ALS AP	Positive/Indicative Negative		Our lab does not test for Saliva.
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
UMQJHA	O-tol HemaTrace	Positive/Indicative Positive/Indicative	AP PSA Micro	Negative Negative Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
UNPFCD	Visual KM HemaTrace	Positive/Indicative Positive/Indicative Positive/Indicative	ALS ABAcad p30	Inconclusive Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
UTYHE9	O-tol HemaTrace	Positive/Indicative Positive/Indicative				
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Not Tested	<b>Conclusion:</b>	Not Tested
VCNGT7	O-tol HemaTrace	Positive/Indicative Positive/Indicative	p30/PSA Micro	Negative Negative		RSID-Saliva Negative
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Negative
VGJ7F6	LMG HemaTrace	Positive/Indicative Positive/Indicative	ACP PSA Micro	Positive/Indicative Negative Negative		Amylase Diffusion Negative
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Negative
VXTUT6	LMG	Positive/Indicative	AP Micro PSA	Negative Negative Negative		Amylase Diffusion Negative
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Negative
VY377Z	SERATEC- HemDirect hemoglobin Assay	Positive/Indicative	Christmas Tree Stain-Micro RSID Semen	Negative Negative		SERATEC-Amylase Test Negative
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Negative

Table 1 - Item 1  
Evidence - Four white plastic swabs containing Blood

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
W6MFGJ	Hemochromogen	Positive/Indicative				
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Not Tested	<b>Conclusion:</b>	Not Tested
W7EDQB	KM	Positive/Indicative	ALS	Inconclusive		
	ABACard HemaTrace	Positive/Indicative	ABACard p30	Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
W7H6F7	HEMASTIX	Positive/Indicative	BRENTAMINE	Negative		NO AVAILABLE TEST FOR Saliva
	LUMINOL	Positive/Indicative				
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
W7HZ4H	Hemastix	Positive/Indicative	AP	Negative		RSID-Saliva Negative
	HemaTrace	Positive/Indicative				
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Negative
WC7HLZ	KM	Positive/Indicative	AP	Negative		Phadebas Amylase Negative
			PSA	Negative		
	<b>Conclusion:</b>	No Response	<b>Conclusion:</b>	No Response	<b>Conclusion:</b>	No Response
WET9M6	O-tol	Positive/Indicative	AP	Negative		Amylase Diffusion Negative
	Seratec HemDirect	Positive/Indicative	Seratec PSA	Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Negative
WFKMR9	KM	Positive/Indicative	ALS	Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
WGZMBX	KM	Positive/Indicative	AP	Negative		RSID Negative
			Micro	Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Negative
WHCE4E	KM	Positive/Indicative	AP	Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
WHTE3B	LMG	Positive/Indicative	AP	Negative		Amylase Radial Diffusion Inconclusive
	HemaTrace	Positive/Indicative	PSA	Negative		
			Micro	Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Inconclusive
WKDHV2	LMG	Positive/Indicative	AP	Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
WREWG3	KM	Positive/Indicative	AP	Negative		
	HemaTrace	Positive/Indicative	PSA	Negative		
			Micro	Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
WUNL77	Visual	Positive/Indicative	AP	Negative		RSID Negative
	LMG	Positive/Indicative				
	HemaTrace	Positive/Indicative				
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Negative

Table 1 - Item 1  
Evidence - Four white plastic swabs containing Blood

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
WUZP9W	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested
WWAL2G	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
WYFXTQ	HEMASTIX <i>Positive/Indicative</i> LUMINOL <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	BRENTAMINE <i>Negative</i> <b>Conclusion:</b> Negative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
X3B7GW	Hem Direct Immunocromatografic SERATEC <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Christmas tree coloration <i>Negative</i> Rapid Stain Identification Semen RSID <i>Negative</i> <b>Conclusion:</b> Negative	Forensic test Kit SERATEC Amylase test Immunocromatografic <i>Negative</i> <b>Conclusion:</b> Negative
X6KZP4	Hemastix <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Micro <i>Negative</i> AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
X9ZNU9	Hemochromogen <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
XENFB3	Visual <i>Positive/Indicative</i> KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> No Response	AP <i>Negative</i> <b>Conclusion:</b> No Response	Phadebas paper <i>Negative</i> <b>Conclusion:</b> No Response
XF2TU6	Visual <i>Positive/Indicative</i> LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
XPMX36	KM <i>Positive/Indicative</i> Modified Takayama <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	Phadebas <i>Negative</i> <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> Species - HemaTrace <i>Positive/Indicative</i> Urine - Creatinine <i>Negative</i> Feces - Urobilinogen <i>Negative</i>		
XQK9X8	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Micro <i>Negative</i> ALS <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative



Table 1 - Item 1  
Evidence - Four white plastic swabs containing Blood

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
XW6FC7	KM HemaTrace	Positive/Indicative Positive/Indicative	AP Micro PSA	Negative Negative Negative	Amylase radial Diffusion	Inconclusive
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Inconclusive	
XZ8C2Z	KM HemaTrace	Positive/Indicative Positive/Indicative	AP PSA Micro	Negative Negative Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
Y44E48	KM	Positive/Indicative	AP Micro	Negative Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
Y6GWGK	HEMASTIX LUMINOL	Positive/Indicative Positive/Indicative	BRENTAMINE	Negative	NO AVAILABLE TEST FOR Saliva	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
Y8JR6U	HemDirect Hemoglobin (SERATEC)	Positive/Indicative	Christmas Tree Coloring Immunocromatographic Test (Semen-RSID)	Negative Negative	Amylase Test (SERATEC)	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
YKN8N6	TMB FOB Seratec PMB Test peripheral Seratec PMB Test menstrual	Positive/Indicative Positive/Indicative Positive/Indicative Negative	AP RSID Semen	Negative Negative	RSID Saliva Seratec Alpha Amylase	Negative Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
YQDKUY	KM HemaTrace	Positive/Indicative Positive/Indicative	AP p30 Micro	Negative Negative Negative	SALigAE Micro	Negative Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
	<b>Other Tests Performed</b>					
	Urine - Urea Test Negative					
YXE6X	O-tol HemaTrace	Positive/Indicative Positive/Indicative	AP	Negative	RSID	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
Z6CT77	KM HemaTrace	Positive/Indicative Positive/Indicative	AP	Negative	Saliva testing not performed in lab	
	<b>Conclusion:</b> No Response		<b>Conclusion:</b> No Response		<b>Conclusion:</b> Not Tested	
ZAHM23	LMG HemaTrace	Positive/Indicative Positive/Indicative	AP PSA Micro	Negative Negative Negative	NT	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	

**Table 1 - Item 1**  
**Evidence - Four white plastic swabs containing Blood**

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
ZFBUGP	HEMASTIX LUMINOL	Positive/Indicative Positive/Indicative	BRENTAMINE	Negative	NO AVAILABLE TEST FOR Saliva	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
ZM8LR6	KM	Positive/Indicative	AP	Negative	Do not perform	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
ZPJAFB	Micro KM	Positive/Indicative Positive/Indicative	AP Micro	Negative Negative	RSID Negative	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
ZUCGUD			AP	Negative		
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
ZWYX9R	KM	Positive/Indicative	AP	Negative	RSID Negative	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	

**Response Summary for Table 1 - Item 1: Four white plastic swabs containing Blood**

	<u>Blood</u>	<u>Semen</u>	<u>Saliva</u>
Positive/Indicative	213	1	0
Negative	0	212	120
Inconclusive	0	0	4
Not Tested (NT)	9	10	103
No Response	10	9	5
Total	232	232	232

# Screening Conclusions & Test(s) Performed

Indicate the overall conclusion from the results of the screening tests performed.

Table 1 - Item 2  
Evidence - Four pink plastic handle swabs containing Saliva

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
24D4LA	KM <i>Negative</i> HemaTrace <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> PSA <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	The [Laboratory] does not conduct forensic serological tests for Saliva. <b>Conclusion:</b> Not Tested
24XLKP	<b>Conclusion:</b> Not Tested	AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
27ZRVP	HEMASTIX <i>Negative</i> LUMINOL <i>Negative</i> <b>Conclusion:</b> Negative	BRENTAMINE <i>Negative</i> <b>Conclusion:</b> Negative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
2HAFUE	Not conducted due to no visible red-brown staining <b>Conclusion:</b> Not Tested	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
2PGRAY	Visual exam - no red-brown staining <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	Amylase Diffusion <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
2QN273	KM <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
3EC4Q2	LMG <i>Negative</i> HemaTrace <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> PSA <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	Amylase Radial Diffusion <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
3HUDM7	Not tested due to the absence of visible red brown staining <b>Conclusion:</b> Not Tested	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
3KX989	KM <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
3KXA9U	O-tol <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
3QHEXN	see additional comments <b>Conclusion:</b> Not Tested	see additional comments <b>Conclusion:</b> Not Tested	see additional comments <b>Conclusion:</b> Not Tested
3RYBLG	HEMASTIX <i>Negative</i> LUMINOL <i>Negative</i> <b>Conclusion:</b> Negative	BRENTAMINE <i>Negative</i> <b>Conclusion:</b> Negative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested

**Table 1 - Item 2**  
**Evidence - Four pink plastic handle swabs containing Saliva**

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
3U376K	HEMASTIX LUMINOL	Negative Negative	BRENTAMINE	Negative	NO AVAILABLE TEST FOR Saliva	
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
447TM9	KM	Negative	AP Micro	Negative Negative	RSID	Positive/Indicative
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
4ABGEP	SERATEC HemDirect	Negative	Christmas Tree Immunochromatography test identification of Human Semen (RSID-Semen)	Negative Negative	SERATEC Amylase Test	Positive/Indicative
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> No Response		<b>Conclusion:</b> Positive/Indicative	
4B9RAR	HemDirect Hemoglobin Seratec	Negative	Christmas Tree Stain (Micro) PSA Seratec	Negative Negative	Amylase test Seratec	Positive/Indicative
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
4BN4RW	No red/brown discoloration present		AP Micro PSA	Negative Negative Negative	Amylase Diffusion	Positive/Indicative
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
4E79LL	KM	Negative	RSID-Semen PSA Sperm Hyliter PI AP	Negative Negative Negative Negative	RSID-Saliva	Positive/Indicative
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
4JLRA	Micro KM	Negative Negative	AP Micro	Negative Negative	RSID	Positive/Indicative
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
4K8M4G	Hemastix (HemaTrace) Luminol	Negative Negative	Brentamine (AP)	Positive/Indicative	According to SOP Saliva swabs are not tested for presumptive testing	
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested	
4L7NCT	PTMB	Negative				
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
4LA7EY	KM	Negative	AP	Negative	Phadebas Amylase	Positive/Indicative
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
	<u>Other Tests Performed</u>					
	Urine - Creatinine Negative					
4QDG2H	No Visual evidence of Blood.					
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
4UKGK4	No red/brown stain noted		AP	Negative		
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	

Table 1 - Item 2  
Evidence - Four pink plastic handle swabs containing Saliva

WebCode	BLOOD		SEMEN		SALIVA					
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results				
4V7FET	SERATEC HemDirect	Negative	Christmas tree Immunochromatography test Rapid Stain Identification of Human Semen (RSID-Semen)	Negative Negative Negative	SERATEC-PSA	Negative	SERATEC Amylase Test Positive/Indicative			<b>Conclusion:</b> Positive/Indicative
4XZ2BQ			ALS AP	Negative Negative						<b>Conclusion:</b> Not Tested
62TKQU	PTMB	Negative	AP PSA	Negative Negative			Phadebas Tablets	Positive/Indicative		<b>Conclusion:</b> Positive/Indicative
	<u>Other Tests Performed</u> Urine - Uritrace Negative									
66TUYA	no RBS observed on swabs		AP	Negative			RSID-Saliva	Positive/Indicative		<b>Conclusion:</b> Positive/Indicative
67PA82	KM	Negative	AP	Negative						<b>Conclusion:</b> Not Tested
68KVZR	PTMB	Negative	AP	Negative			Phadebas Tablet	Positive/Indicative		<b>Conclusion:</b> Positive/Indicative
	<u>Other Tests Performed</u> Urine - Uritrace Negative									
6B3X4Q	No staining consistent with possible Blood.		Acid Phosphatase Micro (In-house prepped)	Negative Negative			RSID-Saliva	Positive/Indicative		<b>Conclusion:</b> Positive/Indicative
6CWLL	no red staining present		AP, PSA, Micro	Negative			Phadebas	Positive/Indicative		<b>Conclusion:</b> Positive/Indicative
	<u>Other Tests Performed</u> urine-RSID Negative									
6H3EEW	Phenolphthalein	Negative	p30 Micro	Negative Negative			Phadebas	Positive/Indicative		<b>Conclusion:</b> Positive/Indicative
6PKQLW	Hemastix	Negative	AP Micro	Negative Negative			RSID	Positive/Indicative		<b>Conclusion:</b> Positive/Indicative
6VPH62			AP	Negative						<b>Conclusion:</b> Not Tested
	<u>Other Tests Performed</u> Alternate Light Source Positive/Indicative									

Table 1 - Item 2  
Evidence - Four pink plastic handle swabs containing Saliva

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
776VCW	<b>Conclusion:</b> Not Tested	AP Negative PSA Negative Micro Negative <b>Conclusion:</b> Negative	Saliva testing is not performed at the laboratory. <b>Conclusion:</b> Not Tested
7CTBC2	No red/brown staining observed <b>Conclusion:</b> Not Tested	AP Negative <b>Conclusion:</b> Negative	RSID Positive/Indicative <b>Conclusion:</b> Positive/Indicative
7CWXP9	<b>Conclusion:</b> Not Tested	Acid Phosphatase Negative Micro Negative <b>Conclusion:</b> Negative	RSID Positive/Indicative <b>Conclusion:</b> Positive/Indicative
7U9PLJ	KM Negative <b>Conclusion:</b> Negative	AP Negative RSID-Semen Negative PSA Negative <b>Conclusion:</b> Negative	RSID-Saliva Positive/Indicative <b>Conclusion:</b> Positive/Indicative
7V63AW	No Visual stain observed <b>Conclusion:</b> Not Tested	AP Negative Micro Negative PSA Negative <b>Conclusion:</b> Negative	Laboratory does not test for Saliva <b>Conclusion:</b> Not Tested
89PX43	No RBS observed. <b>Conclusion:</b> Not Tested	PSA Negative Micro Negative <b>Conclusion:</b> Negative	[Laboratory] does not routinely test for Saliva. <b>Conclusion:</b> Not Tested
8NM624	KM Negative <b>Conclusion:</b> Negative	AP Negative Micro Negative <b>Conclusion:</b> Negative	RSID Positive/Indicative <b>Conclusion:</b> Positive/Indicative
8QN8Q6	KM Negative <b>Conclusion:</b> Negative	AP Negative Micro Negative <b>Conclusion:</b> Negative	RSID Positive/Indicative <b>Conclusion:</b> Positive/Indicative
8UNBTZ	LMG Negative <b>Conclusion:</b> Negative	AP Negative <b>Conclusion:</b> Negative	Amylase Radial Diffusion Positive/Indicative <b>Conclusion:</b> Positive/Indicative
92M92N	LMG Negative <b>Conclusion:</b> Negative	AP Negative <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
94QAGR	BLUESTAR (LUMINOL) Negative <b>Conclusion:</b> Negative	AP Negative <b>Conclusion:</b> Negative	Phadebas Positive/Indicative <b>Conclusion:</b> Positive/Indicative
97KPG4	KM Negative Micro Negative <b>Conclusion:</b> Negative	AP Negative Micro Negative <b>Conclusion:</b> Negative	RSID Positive/Indicative <b>Conclusion:</b> Positive/Indicative

Table 1 - Item 2  
Evidence - Four pink plastic handle swabs containing Saliva

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
987KRA	HEMASTIX <i>Negative</i> LUMINOL <i>Negative</i> <b>Conclusion:</b> Negative	BRENTAMINE <i>Negative</i> <b>Conclusion:</b> Negative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
9J6AWQ	KM <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> PSA <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
9RWMWQ	LMG <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
9TC7FM	LMG <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
9TT6UK	Visual <i>Negative</i> <b>Conclusion:</b> Negative	Micro <i>Negative</i> AP <i>Negative</i> <b>Conclusion:</b> Negative	Amylase Diffusion <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
A49C8Z	Visual <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
A4L4XW	KM <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
AARLDN	LMG <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> <b>Conclusion:</b> Negative	Saliva is not tested <b>Conclusion:</b> Not Tested
AB9QVM	O-tol <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
AMYUTL	KM <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> PSA <i>Negative</i> RSID-Semen <i>Negative</i> Sperm HY-Liter PI <i>Negative</i> <b>Conclusion:</b> Negative	RSID-Saliva <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
AP8KHP	Phenolphthalein <i>Negative</i> <b>Conclusion:</b> Negative	Microscopic Examination <i>Negative</i> Seminal Fluid - p30 <i>Negative</i> <b>Conclusion:</b> Negative	Phadebas <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
AQW9HW	<b>Conclusion:</b> Not Tested	ALS <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
AW84KK	KM <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> <b>Conclusion:</b> Negative	Amylase <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
AYDKY4	<b>Conclusion:</b> Not Tested	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested

Table 1 - Item 2  
Evidence - Four pink plastic handle swabs containing Saliva

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
B2BMZP	No red/brown discoloration upon Visual inspection. <b>Conclusion:</b> Not Tested	AP Negative Micro Negative PSA Negative <b>Conclusion:</b> Negative	Amylase Diffusion Positive/Indicative <b>Conclusion:</b> Positive/Indicative
B3839F	Not red stained <b>Conclusion:</b> Not Tested	Micro Negative p30 Negative <b>Conclusion:</b> Negative	Not validated procedure <b>Conclusion:</b> Not Tested
B4JQUZ	Visual examination conducted-lab reports "no Visual stains" for unstained items. <b>Conclusion:</b> Not Tested	Micro Negative PSA Negative <b>Conclusion:</b> Negative	Saliva testing not offered by our laboratory <b>Conclusion:</b> Not Tested
BBLR7N	LMG Negative RSID Negative <b>Conclusion:</b> Negative	AP Negative RSID Negative <b>Conclusion:</b> Negative	RSID Positive/Indicative <b>Conclusion:</b> Positive/Indicative
BCFFPJ	Visual examination Negative KM Negative <b>Conclusion:</b> Negative	AP Negative Microscopic examination for Sperm heads Negative <b>Conclusion:</b> Negative	Phadebas Tube Test Positive/Indicative <b>Conclusion:</b> Positive/Indicative
	<u>Other Tests Performed</u> Urine - Urea Negative Urine - Creatinine Negative Faeces - Urobilinogen Tube Test Negative		
BFWV63	Micro Negative KM Negative <b>Conclusion:</b> Negative	AP Negative Micro Negative <b>Conclusion:</b> Negative	RSID Positive/Indicative <b>Conclusion:</b> Positive/Indicative
BHL7WV	<b>Conclusion:</b> Not Tested	ALS Negative <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
BKMANH	Visually unstained <b>Conclusion:</b> Not Tested	AP Negative Micro Negative <b>Conclusion:</b> Negative	Amylase Diffusion Positive/Indicative <b>Conclusion:</b> Positive/Indicative
BQBWEG	HemDirect Seratec Negative <b>Conclusion:</b> Negative	Micro Negative PSA Negative <b>Conclusion:</b> Negative	Amylase Seratec Positive/Indicative <b>Conclusion:</b> Positive/Indicative
BT7FKP	No red-brown color observed <b>Conclusion:</b> Not Tested	AP Negative PSA Negative <b>Conclusion:</b> Negative	Amylase Diffusion Positive/Indicative <b>Conclusion:</b> Positive/Indicative
BUB9BG	HemDirect Hemoglobin (SERATEC) Negative <b>Conclusion:</b> Negative	Christmas Tree Stain Slide (Micro) Negative PSA Semiquant (SERATEC) Negative <b>Conclusion:</b> Negative	Amylase Test (SERATEC) Positive/Indicative <b>Conclusion:</b> Positive/Indicative



Table 1 - Item 2  
Evidence - Four pink plastic handle swabs containing Saliva

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
BVQAGP	Nothing visibly observed on swab; No darkening under ALS/IR (IR=Infrared) <b>Conclusion:</b> Not Tested	AP Negative <b>Conclusion:</b> Negative	[Laboratory] does not employ tests for Saliva <b>Conclusion:</b> Not Tested
C8J7Z3	white swabs <b>Conclusion:</b> Not Tested	AP Negative <b>Conclusion:</b> Negative	RSID Positive/Indicative <b>Conclusion:</b> Positive/Indicative
CBXYV3	<b>Conclusion:</b> Not Tested	AP Negative p30 Negative Microscopy Negative <b>Conclusion:</b> Negative	Phadebas Positive/Indicative RSID Positive/Indicative <b>Conclusion:</b> Positive/Indicative
CFCELU	Phenolphthalein Negative <b>Conclusion:</b> Negative	Acid Phosphatase Negative <b>Conclusion:</b> Negative	Phadebas Positive/Indicative <b>Conclusion:</b> Positive/Indicative
	<u>Other Tests Performed</u> Urine - Creatinine Negative		
CNJDUV	lab policy <b>Conclusion:</b> Not Tested	AP Negative <b>Conclusion:</b> Negative	Phadebas Positive/Indicative <b>Conclusion:</b> Positive/Indicative
CUTGYB	Item not brown stained. <b>Conclusion:</b> Not Tested	Micro, p30 Negative <b>Conclusion:</b> No Response	<b>Conclusion:</b> Not Tested
D7426P	Visual Negative <b>Conclusion:</b> Negative	AP Negative <b>Conclusion:</b> Negative	RSID-Saliva Positive/Indicative <b>Conclusion:</b> Positive/Indicative
D94JU6	HEMASTIX Negative LUMINOL Negative <b>Conclusion:</b> Negative	BRENTAMINE Negative <b>Conclusion:</b> Negative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
DF7NRF	KM Negative <b>Conclusion:</b> Negative	BCIP Negative <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
	<u>Other Tests Performed</u> Amylase Diffusion Positive/Indicative		
DKXZJ7	Hemastix test (TMB) Negative Luminol test Negative <b>Conclusion:</b> Negative	Brentamine test (AP) Negative <b>Conclusion:</b> Negative	No presumptive test for Saliva in ER. Swab will be submitted for DNA Analysis <b>Conclusion:</b> Not Tested
DXNMY Y	<b>Conclusion:</b> Not Tested	AP Negative <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
E3A4KN	LMG Negative <b>Conclusion:</b> Negative	AP Negative Micro Negative PSA Negative <b>Conclusion:</b> Negative	Amylase Radial Diffusion Positive/Indicative Micro Negative <b>Conclusion:</b> Positive/Indicative

Table 1 - Item 2  
Evidence - Four pink plastic handle swabs containing Saliva

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
EC6X2V	LMG <i>Negative</i> Visual Examination <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
EGZPDX	KM <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
EJN4ZM	Phenolphthalein <i>Negative</i> <b>Conclusion:</b> Negative	Acid Phosphatase <i>Negative</i> <b>Conclusion:</b> Negative	Phadebas <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
	<u>Other Tests Performed</u> Creatinine <i>Negative</i>		
ELP4ZK	KM <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> PSA <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
EM3NZG	Seratec Hem LN 200076 D.D: 22-09 <i>Negative</i> <b>Conclusion:</b> Negative	RSID Semen LN 092120S1 D. D. 22-09 <i>Negative</i> Christmas tree <i>Negative</i> <b>Conclusion:</b> Negative	Seratec AMY LN 200078 D.D: 22-09 <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
EPBXTE	Human Blood <i>Negative</i> <b>Conclusion:</b> Negative	CHRISTMAS TREE <i>Negative</i> SemenOGELINA <i>Negative</i> <b>Conclusion:</b> Negative	Human Saliva <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
ERGE8W	KM <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
EYDBVZ	no Blood testing conducted due to lack of rbs on swabs <b>Conclusion:</b> Not Tested	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
FATH8U	Visual <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
FC3HEM	No staining with appearance of Blood <b>Conclusion:</b> Not Tested	AP <i>Negative</i> <b>Conclusion:</b> Negative	Blue Paper test <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
FHJBBD	Kastle-Meyer <i>Negative</i> <b>Conclusion:</b> Negative	Acid phosphatase <i>Negative</i> Microscopy and Christmas Tree staining <i>Negative</i> <b>Conclusion:</b> Negative	Phadebas tube test <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
FKR6D6	TMB (Hstix) <i>Negative</i> Luminol <i>Negative</i> <b>Conclusion:</b> Negative	AP (Brentamine) <i>Negative</i> <b>Conclusion:</b> Negative	No presumptive test for Saliva <b>Conclusion:</b> Not Tested

**Table 1 - Item 2**  
**Evidence - Four pink plastic handle swabs containing Saliva**

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
FP8NMZ	KM	Negative	AP	Negative	Phadebas	Positive/Indicative
			p30	Negative		
			Micro	Negative		
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
FQ2ELM	HEMASTIX	Negative	BRENTAMINE	Negative	NO AVAILABLE TEST FOR Saliva	
	LUMINOL	Negative				
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
FQHTUW			AP	Negative	RSID	Positive/Indicative
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
FXXDW9	KM	Negative	AP	Negative	RSID-Saliva	Positive/Indicative
			RSID-Semen	Negative		
			PSA	Negative		
			Sperm Hy-Liter PI	Negative		
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
G2QWBC	Visual, KM	Negative	AP, Microscopy	Negative	Phadebas Tube	Positive/Indicative
	<b>Conclusion:</b> No Response		<b>Conclusion:</b> No Response		<b>Conclusion:</b> No Response	
G43C6D	Visual and KM	Negative	Ap	Negative	Phadebas	Positive/Indicative
			Xmas Tree Slide	Negative		
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
G4LB8G	LMG	Negative	AP	Negative	<b>Conclusion:</b> Not Tested	
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative			
G6R26K	Swab was white in color		AP	Negative	Amylase Diffusion	Positive/Indicative
			Micro	Negative		
			PSA	Negative		
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
GD9E9P			ALS	Negative	<b>Conclusion:</b> Not Tested	
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Negative			
GDUVL8	KM	Negative	AP	Negative	RSID-Saliva	Positive/Indicative
			RSID-Semen	Negative		
			PSA	Negative		
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
GL4D2J	KM	Negative	AP	Negative	<b>Conclusion:</b> Not Tested	
			PSA	Negative		
			Micro	Negative		
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative			

Table 1 - Item 2  
Evidence - Four pink plastic handle swabs containing Saliva

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
GP7BEX	TMB	Negative	AP	Negative	Phadebas	Positive/Indicative
			RSID	Negative		
			Micro	Negative		
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
GUZ6CY	KM	Negative	AP, Sperm search	Negative	[Laboratory] biology does not test swabs for the presence of Saliva (using the Phadebas press test).	
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
HBXUYF	PTMB	Negative	Not online with seminal fluid screening		Not online with Saliva screening	
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
HKMHYN	KM	Negative	AP	Negative	Phadebas	Positive/Indicative
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
	<u>Other Tests Performed</u>					
	Urine - Creatinine Negative					
HLFHP9	HEMASTIX	Negative	BRENTAMINE	Negative	NO AVAILABLE TEST FOR Saliva	
	LUMINOL	Negative				
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
HQB89Z	HEMASTIX	Negative	BRENTAMINE	Negative	NO AVAILABLE TEST FOR Saliva	
	LUMINOL	Negative				
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
HYKPTJ	KM	Negative	AP	Negative	Phadebas Amylase	Positive/Indicative
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
	<u>Other Tests Performed</u>					
	Urine-Creatinine Negative					
J2T2AL	KM	Negative	AP	Negative	RSID	Positive/Indicative
			Micro	Negative		
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
J8YXUL	No stains for testing		AP	Negative	No Saliva testing at Lab	
			Micro	Negative		
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
JGGLF8	HEMASTIX	Negative	BRENTAMINE	Negative	NO AVAILABLE TEST FOR Saliva	
	LUMINOL	Negative				
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
K4Q6CR	No reddish-brown staining observed		AP	Negative	RSID Saliva	Positive/Indicative
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
	<u>Other Tests Performed</u>					
	Body Fluid - Test Performed: ALS Positive/Indicative					

Table 1 - Item 2  
Evidence - Four pink plastic handle swabs containing Saliva

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
K8PF9R	No visible staining observed <b>Conclusion:</b> Not Tested	AP Negative <b>Conclusion:</b> Negative	RSID Positive/Indicative <b>Conclusion:</b> Positive/Indicative
KBAB8D	TMB Negative <b>Conclusion:</b> Negative	AP Negative PSA Negative Microscopic Negative <b>Conclusion:</b> Negative	alpha-Amylase test card Positive/Indicative <b>Conclusion:</b> Positive/Indicative
KED2FE	KM Negative <b>Conclusion:</b> Negative	AP Negative PSA Negative Micro Negative <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
KF2JBK	No red-brown staining <b>Conclusion:</b> Not Tested	AP Negative PSA Negative Micro Negative <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
KMLH4D	LMG Negative <b>Conclusion:</b> Negative	AP Negative <b>Conclusion:</b> Negative	Phadebas Negative <b>Conclusion:</b> Negative
KWN32Z	H/stix Negative <b>Conclusion:</b> Negative	Brentamine (AP) Negative <b>Conclusion:</b> Negative	As per SOP no preliminary test to be performed for Saliva <b>Conclusion:</b> Not Tested
KYVDX4	KM Negative <b>Conclusion:</b> Negative	AP Negative RSID-Semen Negative PSA Negative Sperm Hy-Liter PI Negative <b>Conclusion:</b> Negative	RSID-Saliva Positive/Indicative <b>Conclusion:</b> Positive/Indicative
L47NTJ	<b>Conclusion:</b> Not Tested	ALS Negative <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
L7D2GC	LMG Negative <b>Conclusion:</b> Negative	AP Negative <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
L9YRHG	KM TEST Negative <b>Conclusion:</b> No Response	AP TEST Negative <b>Conclusion:</b> No Response	RSID-Saliva Positive/Indicative <b>Conclusion:</b> No Response
LA84XW	HEMASTIX Negative LUMINOL Negative <b>Conclusion:</b> Negative	BRENTAMINE Negative <b>Conclusion:</b> Negative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
LBC97F	Visual - no staining observed Negative <b>Conclusion:</b> Not Tested	AP Negative <b>Conclusion:</b> Negative	Phadebas Blue Paper Positive/Indicative <b>Conclusion:</b> Positive/Indicative

Table 1 - Item 2  
Evidence - Four pink plastic handle swabs containing Saliva

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
LNPRB2	KM	Negative	AP	Negative	RSID-Saliva	Positive/Indicative
			PSA	Negative		
			RSID-Semen	Negative		
		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative
M2XQ6T	TMB	Negative	AP	Negative	RSID	Positive/Indicative
	HemaTrace	Negative	PSA	Negative		
		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative
M6CLLQ			Microscopy	Negative	Phadebas	Positive/Indicative
			p30	Negative		
		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative
MGNXUE	LMG	Negative	AP	Negative	Amylase Diffusion	Positive/Indicative
			Micro	Negative		
			PSA	Negative		
		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative
MH42MK		Did not observe red brown staining	AP	Negative		
		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> No Response		<b>Conclusion:</b> Not Tested
MHGTDG	KM - Hemophan (paper test for Blood erythrocytes, haemoglobin) by Erba Lachema - non-specific test for Blood Negative		AP - Phosphatesmo (paper test for the determination of acid phosphatase) by Macherey-Nagel Negative		RSID-Saliva Positive/Indicative	
	FOB - cassette test for determination of faecal occult Blood by NADAL - specific test for Human Blood Negative		PSA - cassette test for prostate specific antigen by SERATEC Negative			
		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative
MLM86G	KM	Negative	AP	Negative	Phadabes Paper	Positive/Indicative
		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative
MP2R6B	Seratec HemDirect	Negative	Micro	Negative	Seratec Amylase Test	Positive/Indicative
			Seratec PSA	Negative		
		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative
MUB6RF	KM	Negative	AP	Negative		
			Micro	Negative		
			PSA	Negative		
		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested
MVA9KQ	Hemastix	Negative	AP	Negative		
	KM	Negative				
	Luminol	Negative				
		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested
MW4W4L		No red/brown staining on item	AP	Negative	RSID	Positive/Indicative
		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative

Table 1 - Item 2  
Evidence - Four pink plastic handle swabs containing Saliva

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
MZLBBT	TMB <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
N4UXGG	KM <i>Negative</i> <b>Conclusion:</b> Negative	ALS <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
NPXL8D	No visible Blood stain present for testing <b>Conclusion:</b> Not Tested	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
NXRWAV	TMB - Hstix <i>Negative</i> Luminol <i>Negative</i> <b>Conclusion:</b> Negative	AP (Brent) <i>Negative</i> <b>Conclusion:</b> Negative	No presumptive test for Saliva <b>Conclusion:</b> Not Tested
P3FYU7	SERATEC-SANGRE <i>Negative</i> <b>Conclusion:</b> Negative	MicroSCOPIO <i>Negative</i> RSID-Semen <b>Conclusion:</b> Negative	SERATEC-Saliva <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
P69KR4	LMG <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	Amylase Diffusion <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
P8RWB7	LMG <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
PAX8GH	[Participant did not return results for Item 2]		
PEULCK	Not tested due to Visual appearance <b>Conclusion:</b> Not Tested	PSA <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	The [Laboratory] does not perform tests for Saliva <b>Conclusion:</b> Not Tested
PF4ZDY	KM <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> RSID-Semen <i>Negative</i> PSA <i>Negative</i> <b>Conclusion:</b> Negative	RSID-Saliva <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
PN2NBQ	no staining consistent with Blood <b>Conclusion:</b> Not Tested	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID Saliva <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
PU4R3A	KM <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> PSA <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
Q62YBE	Leucomalachite Green <i>Negative</i> <b>Conclusion:</b> Negative	No tests available. <b>Conclusion:</b> Not Tested	No tests available. <b>Conclusion:</b> Not Tested
	<u>Other Tests Performed</u> Forensic light source <i>Negative</i>		
QC3ALD	<b>Conclusion:</b> Not Tested	ALS <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested

Table 1 - Item 2  
Evidence - Four pink plastic handle swabs containing Saliva

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
QDWWJB	KM <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> <b>Conclusion:</b> Negative	Phadebas <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
	<u>Other Tests Performed</u> Urine - Creatinine <i>Negative</i>		
QGHK4N	<b>Conclusion:</b> Not Tested	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
QP966F	<b>Conclusion:</b> Not Tested	ALS <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
QQ3V99	ALS <i>Negative</i> KM <i>Negative</i> RSID <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> ALS <i>Negative</i> RSID <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	ALS <i>Negative</i> RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
QRFPNA	<b>Conclusion:</b> Not Tested	AP SPOT <i>Negative</i> <b>Conclusion:</b> No Response	<b>Conclusion:</b> Not Tested
QYE6K9	KM <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> PSA <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
R3UUJC	No reddish-brown staining seen. <b>Conclusion:</b> Not Tested	PSA <i>Negative</i> Micro-Sperm <i>Negative</i> <b>Conclusion:</b> Negative	Saliva RSID <i>Positive/Indicative</i> Phadebas <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
R6ZHWF	No red/brown discoloration <b>Conclusion:</b> Not Tested	Acid Phosphatase <i>Negative</i> <b>Conclusion:</b> Negative	RSID-Saliva <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
RJ28Y9	Hemastix <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> RSID Semen <i>Negative</i> <b>Conclusion:</b> Negative	RSID Saliva <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
RJGF2G	KM <i>Negative</i> TMB <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
RKCZMV	KM <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Negative</i> RSID-Semen <i>Negative</i> PSA <i>Negative</i> Sperm Hy-Liter PI <i>Negative</i> <b>Conclusion:</b> Negative	RSID-Saliva <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative



Table 1 - Item 2  
Evidence - Four pink plastic handle swabs containing Saliva

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
RQ44Y8	KM <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Negative</i> PSA <i>Negative</i> Micro <i>Negative</i>  <b>Conclusion:</b> Negative	   <b>Conclusion:</b> Not Tested
RRATXA	HEMASTIX <i>Negative</i> LUMINOL <i>Negative</i>  <b>Conclusion:</b> Negative	BRENTAMINE <i>Negative</i>  <b>Conclusion:</b> Negative	NO AVAILABLE TEST FOR Saliva  <b>Conclusion:</b> Not Tested
RT728F	No visible staining observed, swabs white in color  <b>Conclusion:</b> Not Tested	AP <i>Negative</i>  <b>Conclusion:</b> Negative	RSID <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative
RT9VQL	see comments section  <b>Conclusion:</b> Not Tested	AP <i>Negative</i>  <b>Conclusion:</b> Negative	see comments section  <b>Conclusion:</b> Not Tested
RX2XQE	  <b>Conclusion:</b> Not Tested	ALS <i>Negative</i>  <b>Conclusion:</b> Negative	  <b>Conclusion:</b> Not Tested
RXG4AB	  <b>Conclusion:</b> Not Tested	AP <i>Negative</i> Micro <i>Negative</i> PSA <i>Negative</i>  <b>Conclusion:</b> Negative	   <b>Conclusion:</b> Not Tested
	<u>Other Tests Performed</u> Submitted for Possible Biological Material		
RYVJNC	KM <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Negative</i>  <b>Conclusion:</b> Negative	RSID <i>Positive/Indicative</i> Phadebas <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative
T6UMQF	Not performed due to lack of color/unstained swabs  <b>Conclusion:</b> Not Tested	AP <i>Negative</i>  <b>Conclusion:</b> Negative	RSID <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative
TDB779	Visually inconsistent with Blood.  <b>Conclusion:</b> Not Tested	AP <i>Negative</i> PSA <i>Negative</i>  <b>Conclusion:</b> Negative	Amylase Diffusion <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative
TXU6K	  <b>Conclusion:</b> Not Tested	AP <i>Negative</i>  <b>Conclusion:</b> Negative	  <b>Conclusion:</b> Not Tested
TK3Q4U	HEMASTIX <i>Negative</i> LUMINOL <i>Negative</i>  <b>Conclusion:</b> Negative	BRENTAMINE <i>Negative</i>  <b>Conclusion:</b> Negative	NO AVAILABLE TEST FOR Saliva  <b>Conclusion:</b> Not Tested
TLZRC7	LMG <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Negative</i>  <b>Conclusion:</b> Negative	Amylase Diffusion <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative

Table 1 - Item 2  
Evidence - Four pink plastic handle swabs containing Saliva

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
TPKL98	HEMOPHAN FOB	Positive/Indicative Inconclusive	RSID Semen PSA	Negative Positive/Indicative	RSID Saliva	Positive/Indicative
	<b>Conclusion:</b> Inconclusive		<b>Conclusion:</b> Inconclusive		<b>Conclusion:</b> Positive/Indicative	
TPY8KU	No Visual evidence of Blood.					
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
U2DKJA	Visual KM	Negative Negative	Visual ALS AP Micro	Negative Negative Negative Negative	Visual ALS RSID	Negative Negative Positive/Indicative
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
U4ZY9K			AP	Negative		
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
UA43XH			AP Micro	Negative Negative		
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
UBHEU3	Visual O-tol	Negative Negative	ALS AP Micro PSA	Positive/Indicative Negative Negative Negative		
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
UBYTX6			AP	Negative		Our Agency dos not test for Saliva
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> No Response		<b>Conclusion:</b> Not Tested	
UD69B4	KM HemaTrace	Negative Negative	AP PSA	Negative Negative	Phadebas	Positive/Indicative
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
UJAUJ7	ALS	Negative	ALS AP	Positive/Indicative Negative		Our lab does not test for Saliva.
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
UMQJHA	O-tol	Negative	AP PSA Micro	Negative Negative Negative		
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
UNPFCD	Visual KM	Negative Negative	ALS ABACard p30	Negative Negative		
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
UTYHE9	O-tol	Negative				
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	

Table 1 - Item 2  
Evidence - Four pink plastic handle swabs containing Saliva

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
VCNGT7	NT: no staining indicative of Blood to warrant testing <b>Conclusion:</b> Not Tested	p30/PSA Negative Micro Negative <b>Conclusion:</b> Negative	RSID-Saliva Positive/Indicative Micro Positive/Indicative <b>Conclusion:</b> Positive/Indicative
VGJ7F6	HemaTrace Negative <b>Conclusion:</b> Negative	AP Positive/Indicative PSA Negative Micro Negative <b>Conclusion:</b> Negative	Amylase Diffusion Positive/Indicative <b>Conclusion:</b> Positive/Indicative
VXTUT6	Visually inconsistent with Blood <b>Conclusion:</b> Not Tested	AP Negative Micro Negative <b>Conclusion:</b> Negative	Amylase Diffusion Positive/Indicative <b>Conclusion:</b> Positive/Indicative
VY377Z	SERATEC- HemDirect hemoglobin Assay Negative <b>Conclusion:</b> Negative	Christmas Tree Stain-Micro Negative RSID Semen Negative <b>Conclusion:</b> Negative	SERATEC-Amylase Test Positive/Indicative <b>Conclusion:</b> Positive/Indicative
W6MFGJ	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested
	<u>Other Tests Performed</u> Submitted for Possible Biological Material		
W7EDQB	KM Negative <b>Conclusion:</b> Negative	ALS Negative ABAcad p30 Negative <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
W7H6F7	HEMASTIX Negative LUMINOL Negative <b>Conclusion:</b> Negative	BRENTAMINE Negative <b>Conclusion:</b> Negative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
W7HZ4H	No visible staining <b>Conclusion:</b> Not Tested	AP Negative <b>Conclusion:</b> Negative	RSID-Saliva Positive/Indicative <b>Conclusion:</b> Positive/Indicative
WC7HLZ	KM Negative <b>Conclusion:</b> No Response	AP Negative <b>Conclusion:</b> No Response	Phadebas Amylase Positive/Indicative <b>Conclusion:</b> No Response
WET9M6	O-tol Negative Seratec HemDirect Negative <b>Conclusion:</b> Negative	AP Negative Seratec PSA Negative <b>Conclusion:</b> Negative	Amylase Diffusion Positive/Indicative <b>Conclusion:</b> Positive/Indicative
WFKMR9	<b>Conclusion:</b> Not Tested	ALS Negative <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
WGZMBX	KM Negative <b>Conclusion:</b> Negative	AP Negative Micro Negative <b>Conclusion:</b> Negative	RSID Positive/Indicative <b>Conclusion:</b> Positive/Indicative
WHCE4E	KM Negative <b>Conclusion:</b> Negative	AP Negative <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested

**Table 1 - Item 2**  
**Evidence - Four pink plastic handle swabs containing Saliva**

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
WHT3B	LMG HemaTrace	Negative Negative	AP PSA Micro	Negative Negative Negative	Amylase Radial Diffusion	Positive/Indicative
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
WKDHV2	LMG	Negative	AP	Negative		
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
WREWG3	KM	Negative	AP PSA Micro	Negative Negative Negative		
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
WUNL77	Visual	Negative	AP	Negative	RSID	Positive/Indicative
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
WUZP9W	KM	Negative	AP	Negative		
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
WWAL2G	KM	Negative	AP Micro	Negative Negative	RSID	Positive/Indicative
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
WYFXTQ	HEMASTIX LUMINOL	Negative Negative	BRENTAMINE	Negative	NO AVAILABLE TEST FOR Saliva	
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
X3B7GW	Hem Direct Inmunocromatografic SERATEC	Negative Negative	Christmas tree coloration Rapid Stain Identification Semen RSID	Negative Negative Negative	Forensic test Kit SERATEC Amylase test Inmunocromatografic	Positive/Indicative
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
X6KZP4	Hemastix	Negative	Micro AP	Negative Negative	RSID	Positive/Indicative
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
X9ZNU9			AP	Negative		
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
	<u>Other Tests Performed</u> Submitted for Possible Biological Material					
XENFB3	Visual KM	Negative Negative	AP	Negative	Phadebas paper	Positive/Indicative
	<b>Conclusion:</b> No Response		<b>Conclusion:</b> No Response		<b>Conclusion:</b> No Response	
XF2TU6	Visual	Negative	AP	Negative	RSID	Positive/Indicative
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
XPMX36	KM	Negative	AP	Negative	Phadebas	Positive/Indicative
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
	<u>Other Tests Performed</u> Urine - Creatinine					
	Negative					

**Table 1 - Item 2**  
**Evidence - Four pink plastic handle swabs containing Saliva**

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
XQK9X8	KM <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Negative</i> Micro <i>Negative</i> ALS <i>Positive/Indicative</i>  <b>Conclusion:</b> Negative	RSID <i>Positive/Indicative</i> ALS <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative
XW6FC7	No Blood-like stain observed  <b>Conclusion:</b> Not Tested	AP <i>Negative</i> Micro <i>Negative</i> PSA <i>Negative</i>  <b>Conclusion:</b> Negative	Amylase radial Diffusion <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative
XZ8C2Z	KM <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Negative</i> PSA <i>Negative</i> Micro <i>Negative</i>  <b>Conclusion:</b> Negative	    <b>Conclusion:</b> Not Tested
Y44E48	KM <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Negative</i> Micro <i>Negative</i>  <b>Conclusion:</b> Negative	    <b>Conclusion:</b> Not Tested
Y6GWGK	HEMASTIX <i>Negative</i> LUMINOL <i>Negative</i>  <b>Conclusion:</b> Negative	BRENTAMINE <i>Negative</i>  <b>Conclusion:</b> Negative	NO AVAILABLE TEST FOR Saliva  <b>Conclusion:</b> Not Tested
Y8JR6U	HemDirect Hemoglobin (SERATEC) <i>Negative</i>  <b>Conclusion:</b> Negative	Christmas Tree Coloring <i>Negative</i> Immunocromatographic Test (Semen-RSID) <i>Negative</i>  <b>Conclusion:</b> Negative	Amylase Test (SERATEC) <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative
YKN8N6	TMB <i>Positive/Indicative</i> FOB <i>Positive/Indicative</i> Seratec PMB Test menstrual <i>Negative</i> Seratec PMB Test peripheral <i>Negative</i>  <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> RSID Semen <i>Negative</i>  <b>Conclusion:</b> Negative	RSID Saliva <i>Positive/Indicative</i> Seratec alpha Amylase test <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative
YQDKUY	Not tested due to absence of red-brown staining.  <b>Conclusion:</b> Not Tested	AP <i>Negative</i> p30 <i>Negative</i> Micro <i>Negative</i>  <b>Conclusion:</b> Negative	SALigAE <i>Positive/Indicative</i> Micro <i>Negative</i>  <b>Conclusion:</b> Positive/Indicative
	<u>Other Tests Performed</u> Urine - Urea Test <i>Inconclusive</i>		
YXEV6X	O-tol <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Negative</i>  <b>Conclusion:</b> Negative	RSID <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative
Z6CT77	KM <i>Negative</i>  <b>Conclusion:</b> No Response	AP <i>Negative</i>  <b>Conclusion:</b> No Response	Saliva testing not performed in lab  <b>Conclusion:</b> Not Tested

**Table 1 - Item 2**  
**Evidence - Four pink plastic handle swabs containing Saliva**

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
ZAHM23	NT		AP Negative PSA Negative Micro Negative		NT	
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
ZFBUGP	HEMASTIX Negative LUMINOL Negative		BRENTAMINE Negative		NO AVAILABLE TEST FOR Saliva	
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
ZM8LR6	KM Negative		AP Negative		Do not perform	
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
ZPJAFB	Micro Negative KM Negative		AP Negative Micro Negative		RSID Positive/Indicative	
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
ZUCGUD			AP Negative			
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
ZWYX9R	KM Negative		AP Negative		RSID Positive/Indicative	
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	

**Response Summary for Table 1 - Item 2: Four pink plastic handle swabs containing Saliva**

	<u>Blood</u>	<u>Semen</u>	<u>Saliva</u>
Positive/Indicative	1	1	124
Negative	149	211	1
Inconclusive	1	1	0
Not Tested (NT)	75	8	102
No Response	6	11	5
Total	232	232	232

# Screening Conclusions & Test(s) Performed

Indicate the overall conclusion from the results of the screening tests performed.

Table 1 - Item 3

Evidence - Four blue plastic swabs containing Blood & Semen Mixture

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
24D4LA	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	The [Laboratory] does not conduct forensic serological tests for Saliva. <b>Conclusion:</b> Not Tested
24XLKP	<b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
27ZRVP	HEMASTIX <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	BRENTAMINE <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
2HAFUE	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> PSA (ABACard) <i>Positive/Indicative</i> PSA (Seratec) <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
2PGRAY	LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> p30 <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Amylase Diffusion <i>Negative</i> <b>Conclusion:</b> Negative
2QN273	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Scenario did not support testing for Semen <b>Conclusion:</b> Not Tested	Scenario did not support testing for Saliva <b>Conclusion:</b> Not Tested
3EC4Q2	LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Amylase Radial Diffusion <i>Inconclusive</i> <b>Conclusion:</b> Inconclusive
3HUDM7	TMB <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
3KX989	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
3KXA9U	O-tol <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Scenario does not suggest Saliva present on this sample. <b>Conclusion:</b> Not Tested
3QHEXN	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> No Response	see additional comments <b>Conclusion:</b> Not Tested	see additional comments <b>Conclusion:</b> Not Tested

**Table 1 - Item 3**  
**Evidence - Four blue plastic swabs containing Blood & Semen Mixture**

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
3RYBLG	HEMASTIX	<i>Positive/Indicative</i>	BRENTAMINE	<i>Positive/Indicative</i>	NO AVAILABLE TEST FOR Saliva	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested	
3U376K	HEMASTIX	<i>Positive/Indicative</i>	BRENTAMINE	<i>Positive/Indicative</i>	NO AVAILABLE TEST FOR Saliva	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested	
447TM9	Micro	<i>Positive/Indicative</i>	AP	<i>Positive/Indicative</i>	RSID <i>Negative</i>	
	KM	<i>Positive/Indicative</i>	Micro	<i>Positive/Indicative</i>		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative	
4ABGEP	SERATEC HemDirect	<i>Positive/Indicative</i>	Christmas Tree	<i>Positive/Indicative</i>	SERATEC Amylase Test <i>Negative</i>	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative	
4B9RAR	HemDirect Hemoglobin Seratec	<i>Positive/Indicative</i>	Christmas Tree Stain (Micro)	<i>Positive/Indicative</i>	Not tested	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested	
4BN4RW	LMG	<i>Positive/Indicative</i>	AP	<i>Positive/Indicative</i>	Amylase Diffusion <i>Negative</i>	
			Micro	<i>Positive/Indicative</i>		
			PSA	<i>Positive/Indicative</i>		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative	
4E79LL	KM	<i>Positive/Indicative</i>	RSID-Semen	<i>Positive/Indicative</i>	Generally not tested unless specified	
	OBTI	<i>Positive/Indicative</i>	PSA	<i>Positive/Indicative</i>		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested	
4JLRRR	Micro	<i>Positive/Indicative</i>	AP	<i>Positive/Indicative</i>	RSID <i>Negative</i>	
	KM	<i>Positive/Indicative</i>	Micro	<i>Positive/Indicative</i>		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative	
4K8M4G	Hemastix (HemaTrace)	<i>Positive/Indicative</i>	Brentamine (AP)	<i>Positive/Indicative</i>		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested	
4L7NCT	PTMB	<i>Positive/Indicative</i>				
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
4LA7EY	KM	<i>Positive/Indicative</i>	AP	<i>Positive/Indicative</i>	Phadebas Amylase <i>Negative</i>	
	Modified Takayama	<i>Positive/Indicative</i>	Micro	<i>Positive/Indicative</i>		
			PSA	<i>Positive/Indicative</i>		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative	
4QDG2H	KM	<i>Positive/Indicative</i>				
	HemaTrace	<i>Positive/Indicative</i>				
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
4UKGK4	KM	<i>Positive/Indicative</i>	AP	<i>Positive/Indicative</i>		
			Micro	<i>Positive/Indicative</i>		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested	



Table 1 - Item 3  
Evidence - Four blue plastic swabs containing Blood & Semen Mixture

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
4V7FET	SERATEC HemDirect	Positive/Indicative	Christmas tree	Positive/Indicative	SERATEC Amylase Test	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative	
4XZ2BQ	LMG	Positive/Indicative	ALS	Negative		
	<b>Conclusion:</b> Positive/Indicative		AP	Positive/Indicative	<b>Conclusion:</b> Not Tested	
62TKQU	PTMB	Positive/Indicative	AP	Positive/Indicative	No indications of Saliva	
	RSID	Positive/Indicative	PSA	Positive/Indicative	<b>Conclusion:</b> Not Tested	
66TUYA	HT, Hemastix, KM	Positive/Indicative	AP, Micro, p30	Positive/Indicative	RSID-Saliva	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative	
67PA82	KM	Positive/Indicative	AP	Positive/Indicative		
	<b>Conclusion:</b> Positive/Indicative		Microscope	Positive/Indicative	<b>Conclusion:</b> Not Tested	
68KVZR	PTMB	Positive/Indicative	AP	Positive/Indicative	No indication of possible Saliva	
	<b>Conclusion:</b> Positive/Indicative		PSA	Positive/Indicative	<b>Conclusion:</b> Not Tested	
6B3X4Q	Kastle Meyer/3% Hydrogen Peroxide	Positive/Indicative	Per case scenario, no need to test for Semen on this item.		Per case scenario, no need to test for Saliva on this item.	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
6CWLLL	PTMB	Positive/Indicative	AP, PSA, Micro	Positive/Indicative	Phadebas	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative	
6H3EEW	Phenolphthalein	Positive/Indicative	p30	Positive/Indicative	Phadebas	Negative
	<b>Conclusion:</b> Positive/Indicative		Micro	Positive/Indicative	<b>Conclusion:</b> Negative	
6PKQLW	Hemastix	Positive/Indicative	Micro	Positive/Indicative	RSID	Negative
	HemaTrace	Positive/Indicative	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative	
6VPH62	Hemastix	Positive/Indicative	AP	Positive/Indicative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested	
	<u>Other Tests Performed</u>					
	Alternate Light Source <i>Inconclusive</i>					
776VCW	LMG	Positive/Indicative	AP	Positive/Indicative	Saliva testing is not performed at the laboratory.	
	HemaTrace	Positive/Indicative	PSA	Positive/Indicative		
	<b>Conclusion:</b> Positive/Indicative		Micro	Positive/Indicative	<b>Conclusion:</b> Not Tested	

Table 1 - Item 3  
Evidence - Four blue plastic swabs containing Blood & Semen Mixture

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
7CTBC2	TMB <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
7CWXP9	Phenolphthalein <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Acid Phosphatase <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> Prostate Specific Antigen <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
7U9PLJ	KM <i>Positive/Indicative</i> OBTI <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID-Semen <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Generally not tested unless specified. <b>Conclusion:</b> Not Tested
7V63AW	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Laboratory does not test for Saliva <b>Conclusion:</b> Not Tested
89PX43	KM <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	[Laboratory] does not routinely test for Saliva. <b>Conclusion:</b> Not Tested
8NM624	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
8QN8Q6	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
8UNBTZ	LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Amylase Radial Diffusion <i>Inconclusive</i> <b>Conclusion:</b> Inconclusive
92M92N	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
94QAGR	BLUESTAR (LUMINOL) <i>Positive/Indicative</i> HEXAGON OBTI TEST <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> SERATEC PSA SEMI QUANT <i>Positive/Indicative</i> RSID Semen (UNIVERSAL BUFFER) <i>Positive/Indicative</i> RSID Semen (DUAL BUFFER) <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Phadebas <i>Negative</i> <b>Conclusion:</b> Negative

Table 1 - Item 3  
Evidence - Four blue plastic swabs containing Blood & Semen Mixture

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
97KPG4	KM Micro <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative	AP Micro <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative	RSID <b>Conclusion:</b> Negative	Negative
987KRA	HEMASTIX LUMINOL <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative	BRENTAMINE <b>Conclusion:</b> Positive/Indicative	Positive/Indicative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested	
9J6AWQ	KM HemaTrace <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative	AP PSA Micro <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative Positive/Indicative	<b>Conclusion:</b> Not Tested	
9RWMWQ	LMG <b>Conclusion:</b> Positive/Indicative	Positive/Indicative	AP Micro PSA <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative Positive/Indicative	<b>Conclusion:</b> Not Tested	
9TC7FM	LMG <b>Conclusion:</b> Positive/Indicative	Positive/Indicative	AP Micro PSA <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative Positive/Indicative	<b>Conclusion:</b> Not Tested	
9TT6UK	LMG <b>Conclusion:</b> Positive/Indicative	Positive/Indicative	AP Micro PSA <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative Positive/Indicative	Amylase Diffusion <b>Conclusion:</b> Negative	Negative
A49C8Z	LMG HemaTrace <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative	AP p30 Microscopic <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative Positive/Indicative	RSID <b>Conclusion:</b> Negative	Negative
A4L4XW	KM <b>Conclusion:</b> Positive/Indicative	Positive/Indicative	AP Micro <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative	scenario does not support testing <b>Conclusion:</b> Not Tested	
AARLDN	LMG, HemDirect <b>Conclusion:</b> Positive/Indicative	Positive/Indicative	AP, Micro, PSA <b>Conclusion:</b> Positive/Indicative	Positive/Indicative	Saliva is not tested <b>Conclusion:</b> Not Tested	
AB9QVM	O-tol HemaTrace <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative	AP Micro <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative	Case scenario does not indicate the need for this testing. <b>Conclusion:</b> Not Tested	
AMYUTL	KM OBTI <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative	PSA RSID-Semen <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative	Generally not tested, unless specified. <b>Conclusion:</b> Not Tested	

Table 1 - Item 3  
Evidence - Four blue plastic swabs containing Blood & Semen Mixture

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
AP8KHP	Phenolphthalein	Positive/Indicative	Microscopic Examination	Positive/Indicative	Phadebas	Negative
			Seminal Fluid - p30	Positive/Indicative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative	
AQW9HW	KM	Positive/Indicative	ALS	Positive/Indicative		
			PSA	Positive/Indicative		
			Micro	Positive/Indicative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested	
AW84KK	KM	Positive/Indicative	AP	Positive/Indicative	As per laboratory protocol, an item that tests positive for Semen is not tested for Saliva	
			Micro	Positive/Indicative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested	
AYDKY4			AP	Positive/Indicative		
			Micro	Positive/Indicative		
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested	
B2BMZP	LMG	Positive/Indicative	AP	Positive/Indicative	Amylase Diffusion	Negative
			Micro	Positive/Indicative		
			PSA	Positive/Indicative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative	
B3839F	KM	Positive/Indicative	Micro	Positive/Indicative	Not validated procedure	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested	
B4JQUZ	KM	Positive/Indicative	Micro	Positive/Indicative	Saliva testing not offered by our laboratory	
	HemaTrace	Positive/Indicative				
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested	
BBLR7N	LMG	Positive/Indicative	AP	Positive/Indicative	RSID	Negative
	RSID	Positive/Indicative	RSID	Positive/Indicative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative	
BCFFPJ	Visual examination	Positive/Indicative	AP	Positive/Indicative	Phadebas Tube Test	Negative
	KM	Positive/Indicative	Microscopic examination for Sperm heads	Positive/Indicative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative	
BFWV63	Micro	Positive/Indicative	AP	Positive/Indicative	RSID	Negative
	KM	Positive/Indicative	Micro	Positive/Indicative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative	
BHL7WV	KM	Positive/Indicative	ALS	Positive/Indicative		
			PSA	Positive/Indicative		
			Micro	Positive/Indicative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested	

Table 1 - Item 3  
 Evidence - Four blue plastic swabs containing Blood & Semen Mixture

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
BKMANH	LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Amylase Diffusion <i>Negative</i> <b>Conclusion:</b> Negative
BQBWEG	HemDirect Seratec <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Micro <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Amylase Seratec <i>Negative</i> <b>Conclusion:</b> Negative
BT7FKP	LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Amylase Diffusion <i>Negative</i> <b>Conclusion:</b> Negative
BUB9BG	HemDirect Hemoglobin (SERATEC) <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Christmas Tree Stain Slide (Micro) <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Amylase Test (SERATEC) <i>Negative</i> <b>Conclusion:</b> Negative
BVQAGP	LMG ([Laboratory]: Leuco-Malachite) <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	[Laboratory] does not employ tests for Saliva <b>Conclusion:</b> Not Tested
C8JZ3	Hemastix <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	p30 <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	scenario indicated oral contact with breast <b>Conclusion:</b> Not Tested
CBXYV3	O-tol <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> p30 <i>Positive/Indicative</i> Microscopy <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
CFCELU	Phenolphthalein <i>Positive/Indicative</i> Takayama <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Acid Phosphatase <i>Positive/Indicative</i> Microscopic / Christmas Tree Stain <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Phadebas <i>Negative</i> <b>Conclusion:</b> Negative
CNJDUV	KM Hexagon OBTI <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	lab policy, case scenario <b>Conclusion:</b> Not Tested
CUTGYB	KM <i>Positive/Indicative</i> <b>Conclusion:</b> No Response	Micro <i>Positive/Indicative</i> <b>Conclusion:</b> No Response	<b>Conclusion:</b> Not Tested
D7426P	Visual <i>Positive/Indicative</i> LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> ABACard p30 <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID-Saliva <i>Negative</i> <b>Conclusion:</b> Negative
D94JU6	HEMASTIX <i>Positive/Indicative</i> LUMINOL <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	BRENTAMINE <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested

Table 1 - Item 3  
Evidence - Four blue plastic swabs containing Blood & Semen Mixture

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
DF7NRF	KM <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	BCIP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	   <b>Conclusion:</b> Not Tested
	<u>Other Tests Performed</u> Amylase Diffusion <i>Negative</i>		
DKXZJ7	Hemastix Test (TMB) <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	Brentamine Test (AP) <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	No presumptive test for Saliva in ER. No evidential value.  <b>Conclusion:</b> Not Tested
DXNMY	   <b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	   <b>Conclusion:</b> Not Tested
E3A4KN	LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> Ouchterlony <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	Amylase Radial Diffusion <i>Negative</i> Micro <i>Negative</i>  <b>Conclusion:</b> Negative
EC6X2V	LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> Visual Examination <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> p30 <i>Positive/Indicative</i> Microscopic Examination <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i>   <b>Conclusion:</b> Negative
EGZPDX	KM <i>Positive/Indicative</i>   <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i>   <b>Conclusion:</b> Negative
EJN4ZM	Phenolphthalein <i>Positive/Indicative</i> Modified Takyama <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	Acid Phosphatase <i>Positive/Indicative</i> Xmas Tree Stain/Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	Phadebas <i>Negative</i>   <b>Conclusion:</b> Negative
ELP4ZK	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	   <b>Conclusion:</b> Not Tested
EM3NZG	Seratec HEM LN 200076 D.D: 22-09 <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	RSID LN 092120S1 D. D. 22-09 <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	Seratec AMY LN 200078 D.D: 22-09 <i>Negative</i>  <b>Conclusion:</b> Negative
EPBXTE	Human Blood <i>Positive/Indicative</i>   <b>Conclusion:</b> Positive/Indicative	CHRISTMAS TREE <i>Positive/Indicative</i> SemenOGELINA <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	Human Saliva <i>Negative</i>   <b>Conclusion:</b> Negative
ERGE8W	KM <i>Positive/Indicative</i>   <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i>   <b>Conclusion:</b> Positive/Indicative	   <b>Conclusion:</b> Not Tested

**Table 1 - Item 3**  
**Evidence - Four blue plastic swabs containing Blood & Semen Mixture**

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
EYDBVZ	Phenolphthalein HemaTrace	Positive/Indicative Positive/Indicative	AP Micro PSA	Positive/Indicative Positive/Indicative Positive/Indicative	RSID	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative	
FATH8U	Visual LMG HemaTrace	Positive/Indicative Positive/Indicative Positive/Indicative	AP p30 Micro	Positive/Indicative Positive/Indicative Positive/Indicative	RSID	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative	
FC3HEM	KM HemaTrace	Positive/Indicative Positive/Indicative	AP Spermatozoa Microscopy	Positive/Indicative Positive/Indicative	Blue paper	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative	
FHJBBD	Kastle-Meyer	Positive/Indicative	Acid phosphatase Microscopy and Christmas Tree staining	Positive/Indicative Positive/Indicative	Phadebas tube test	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative	
FKR6D6	TMB (Hstix)	Positive/Indicative	AP (Brentamine)	Positive/Indicative	No presumptive test for Saliva; not tested due to nature of exhibit	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested	
FP8NMZ	KM HemaTrace	Positive/Indicative Positive/Indicative	AP p30 Micro	Positive/Indicative Positive/Indicative Positive/Indicative	Phadebas	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative	
FQ2ELM	HEMASTIX	Positive/Indicative	BRENTAMINE	Positive/Indicative	NO AVAILABLE TEST FOR Saliva	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested	
FQHTUW	KM	Positive/Indicative	AP Micro ABACard PSA Seratec PSA	Positive/Indicative Positive/Indicative Positive/Indicative Positive/Indicative	RSID	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative	
FXXDW9	KM OBTI	Positive/Indicative Positive/Indicative	RSID-Semen PSA	Positive/Indicative Positive/Indicative	Generally not tested unless specified	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested	
G2QWBC	Visual, KM	Positive/Indicative	AP, Microscopy	Positive/Indicative		
	<b>Conclusion:</b> No Response		<b>Conclusion:</b> No Response		<b>Conclusion:</b> Not Tested	
G43C6D	Visual and KM	Positive/Indicative	AP Xmas Tree Slide	Positive/Indicative Positive/Indicative	Phadebas	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative	



Table 1 - Item 3  
Evidence - Four blue plastic swabs containing Blood & Semen Mixture

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
G4LB8G	LMG	Positive/Indicative	AP Micro PSA	Positive/Indicative Positive/Indicative Positive/Indicative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Not Tested
G6R26K	LMG	Positive/Indicative	AP Micro PSA	Positive/Indicative Positive/Indicative Positive/Indicative	Amylase Diffusion	Negative
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative
GD9E9P	KM	Positive/Indicative	PSA ALS Micro	Positive/Indicative Positive/Indicative Positive/Indicative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Not Tested
GDUVL8	KM OBTI	Positive/Indicative Positive/Indicative	RSID-Semen PSA	Positive/Indicative Positive/Indicative	Generally not tested unless specified.	
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Not Tested
GL4D2J	KM HemaTrace	Positive/Indicative Positive/Indicative	AP PSA Micro	Positive/Indicative Positive/Indicative Positive/Indicative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Not Tested
GP7BEX	TMB HemaTrace	Positive/Indicative Positive/Indicative	AP RSID Micro	Positive/Indicative Positive/Indicative Positive/Indicative	Phadebas	Negative
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative
GUZ6CY	KM, ABACard HemaTrace	Positive/Indicative Positive/Indicative	AP, p30	Positive/Indicative	[Laboratory] biology does not test swabs for the presence of Saliva (using the Phadebas press test).	
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Not Tested
HBXUYF	PTMB RSID	Positive/Indicative Positive/Indicative	Not online with seminal fluid screening		Not online with Saliva screening	
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Not Tested	<b>Conclusion:</b>	Not Tested
HKMHYN	KM Modified Takayama	Positive/Indicative Positive/Indicative	AP Micro	Positive/Indicative Positive/Indicative	Phadebas	Negative
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative
HLFHP9	HEMASTIX	Positive/Indicative	BRENTAMINE	Positive/Indicative	NO AVAILABLE TEST FOR Saliva	
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Not Tested
HQB89Z	HEMASTIX	Positive/Indicative	BRENTAMINE	Positive/Indicative	NO AVAILABLE TEST FOR Saliva	
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Not Tested



**Table 1 - Item 3**  
**Evidence - Four blue plastic swabs containing Blood & Semen Mixture**

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
HYKPTJ	KM Modified Takayama <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative	AP Micro <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative	Phadebas Amylase <b>Conclusion:</b> Negative	Negative
J2T2AL	KM <b>Conclusion:</b> Positive/Indicative	Positive/Indicative	AP Micro <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative	Scenario did not provide any details that would lead me to test for Saliva <b>Conclusion:</b> Not Tested	
J8YXUL	KM Heme-direct <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative	AP PSA Micro <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative Positive/Indicative	No Saliva testing at Lab <b>Conclusion:</b> Not Tested	
JGGLF8	HEMASTIX <b>Conclusion:</b> Positive/Indicative	Positive/Indicative	BRENTAMINE <b>Conclusion:</b> Positive/Indicative	Positive/Indicative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested	
K4Q6CR	KM, Hemastix, HemaTrace, Luminol <b>Conclusion:</b> Positive/Indicative	Positive/Indicative	AP, Micro, PSA, p30 <b>Conclusion:</b> Positive/Indicative	Positive/Indicative	RSID Saliva <b>Conclusion:</b> Negative	Negative
	<u>Other Tests Performed</u> Body Fluid - Test Performed: ALS Negative					
K8PF9R	KM <b>Conclusion:</b> Positive/Indicative	Positive/Indicative	AP Micro PSA <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative Positive/Indicative	RSID <b>Conclusion:</b> Negative	Negative
KBAB8D	TMB <b>Conclusion:</b> Positive/Indicative	Positive/Indicative	AP PSA Microscopic <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative Positive/Indicative	alpha-Amylase test card <b>Conclusion:</b> Negative	Negative
KED2FE	KM HemaTrace <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative	AP PSA Micro <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative Positive/Indicative	<b>Conclusion:</b> Not Tested	
KF2JBK	KM HemaTrace <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative	AP PSA Micro <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative Positive/Indicative	<b>Conclusion:</b> Not Tested	
KMLH4D	LMG <b>Conclusion:</b> Positive/Indicative	Positive/Indicative	AP <b>Conclusion:</b> Positive/Indicative	Positive/Indicative	<b>Conclusion:</b> Not Tested	
	<u>Other Tests Performed</u> H&E Slide :+2H Positive/Indicative					

Table 1 - Item 3  
Evidence - Four blue plastic swabs containing Blood & Semen Mixture

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
KWN32Z	H/stix (KM) <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Brentamine (AP) <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	As per SOP no prelim for Saliva to be performed <b>Conclusion:</b> Not Tested
KYVDX4	KM <i>Positive/Indicative</i> OBTI <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID-Semen <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Generally not tested unless specified <b>Conclusion:</b> Not Tested
L47NTJ	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
L7D2GC	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
L9YRHG	KM TEST <i>Positive/Indicative</i> RSID-Blood <i>Positive/Indicative</i> <b>Conclusion:</b> No Response	AP TEST <i>Positive/Indicative</i> RSID-Semen <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> No Response	RSID-Saliva <i>Negative</i> <b>Conclusion:</b> No Response
LA84XW	HEMASTIX <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	BRENTAMINE <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
LBC97F	Visual <i>Positive/Indicative</i> KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Phadebas Blue Paper <i>Negative</i> <b>Conclusion:</b> Negative
LNPRB2	KM <i>Positive/Indicative</i> OBTI <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	PSA <i>Positive/Indicative</i> RSID-Semen <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Generally not tested unless specified <b>Conclusion:</b> Not Tested
M2XQ6T	TMB <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
M6CLLQ	TMB <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Microscopy <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Phadebas <i>Negative</i> <b>Conclusion:</b> Negative
MGNXUE	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Amylase Diffusion <i>Negative</i> <b>Conclusion:</b> Negative
MH42MK	KM <i>Positive/Indicative</i> <b>Conclusion:</b> No Response	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> No Response	<b>Conclusion:</b> Not Tested

Table 1 - Item 3  
Evidence - Four blue plastic swabs containing Blood & Semen Mixture

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
MHGTDG	KM - Hemophan (paper test for Blood erythrocytes, haemoglobin) by Erba Lachema - non-specific test for Blood Positive/Indicative FOB - cassette test for determination of faecal occult Blood by NADAL - specific test for Human Blood Positive/Indicative <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested
MLM86G	KM Positive/Indicative HemaTrace Positive/Indicative <b>Conclusion:</b> Positive/Indicative	AP Positive/Indicative p30 Positive/Indicative Micro Positive/Indicative <b>Conclusion:</b> Positive/Indicative	RSID Negative <b>Conclusion:</b> Negative
MP2R6B	Seratec HemDirect Positive/Indicative <b>Conclusion:</b> Positive/Indicative	Micro Positive/Indicative <b>Conclusion:</b> Positive/Indicative	Seratec Amylase Test Negative <b>Conclusion:</b> Negative
MUB6RF	KM Positive/Indicative <b>Conclusion:</b> Positive/Indicative	AP Positive/Indicative Micro Positive/Indicative PSA Positive/Indicative <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
MVA9KQ	Hemastix Positive/Indicative KM Positive/Indicative <b>Conclusion:</b> Positive/Indicative	AP Positive/Indicative Micro Positive/Indicative <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
MW4W4L	KM Positive/Indicative <b>Conclusion:</b> Positive/Indicative	AP Positive/Indicative Micro Positive/Indicative PSA Positive/Indicative <b>Conclusion:</b> Positive/Indicative	RSID Negative <b>Conclusion:</b> Negative
MZLBBT	TMB Positive/Indicative HemaTrace Positive/Indicative <b>Conclusion:</b> Positive/Indicative	AP Positive/Indicative Micro Positive/Indicative PSA Positive/Indicative <b>Conclusion:</b> Positive/Indicative	RSID Positive/Indicative <b>Conclusion:</b> Positive/Indicative
N4UXGG	KM Positive/Indicative <b>Conclusion:</b> Positive/Indicative	ALS Positive/Indicative PSA Positive/Indicative Micro Positive/Indicative <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
NPXL8D	KM Positive/Indicative <b>Conclusion:</b> Positive/Indicative	AP Positive/Indicative <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
NXRWAV	TMB - Hstix Positive/Indicative <b>Conclusion:</b> Positive/Indicative	AP (Brent) Positive/Indicative <b>Conclusion:</b> Positive/Indicative	No presumptive test for Saliva <b>Conclusion:</b> Not Tested
P3FYU7	SERATEC-SANGRE Positive/Indicative <b>Conclusion:</b> Positive/Indicative	MicroSCOPIO Positive/Indicative <b>Conclusion:</b> Positive/Indicative	SERATEC-Saliva Negative <b>Conclusion:</b> Negative

Table 1 - Item 3  
Evidence - Four blue plastic swabs containing Blood & Semen Mixture

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
P69KR4	LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Amylase Diffusion <i>Negative</i> <b>Conclusion:</b> Negative
P8RWB7	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
PAX8GH	[Participant did not return results for Item 3]		
PEULCK	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	The [Laboratory] does not perform tests for Saliva <b>Conclusion:</b> Not Tested
PF4ZDY	KM <i>Positive/Indicative</i> OBTI <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID-Semen <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Generally not tested unless specified <b>Conclusion:</b> Not Tested
PN2NBQ	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> ABACard PSA <i>Positive/Indicative</i> Seratec PSA <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID Saliva <i>Negative</i> <b>Conclusion:</b> Negative
PU4R3A	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
Q62YBE	Leucomalachite Green <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	No tests available. <b>Conclusion:</b> Not Tested	No tests available. <b>Conclusion:</b> Not Tested
QC3ALD	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
QDWVJB	KM <i>Positive/Indicative</i> Modified Takayama <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Phadebas <i>Negative</i> <b>Conclusion:</b> Negative
QGK4N	<b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested

**Table 1 - Item 3**  
**Evidence - Four blue plastic swabs containing Blood & Semen Mixture**

WebCode	BLOOD		SEMEN		SALIVA		
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results	
QP966F	KM	Positive/Indicative	ALS PSA Micro	Positive/Indicative Positive/Indicative Positive/Indicative			<b>Conclusion:</b> Not Tested
QQ3V99	ALS KM RSID	Negative Positive/Indicative Positive/Indicative	AP ALS RSID Micro	Positive/Indicative Negative Positive/Indicative Positive/Indicative	ALS RSID	Negative Negative	<b>Conclusion:</b> Negative
QRFPNA	KM	Positive/Indicative	AP SPOT	Positive/Indicative			<b>Conclusion:</b> Not Tested
	<u>Other Tests Performed</u> Micro Positive/Indicative						
QYE6K9	KM HemaTrace	Positive/Indicative Positive/Indicative	AP PSA Micro	Positive/Indicative Positive/Indicative Positive/Indicative			<b>Conclusion:</b> Not Tested
R3UUJC	KM HemaTrace	Positive/Indicative Positive/Indicative	PSA Micro-Sperm	Positive/Indicative Positive/Indicative	Saliva RSID	Negative	<b>Conclusion:</b> Negative
R6ZHWF	Phenolphthalein	Positive/Indicative	Acid Phosphatase Microscopic Identification of Spermatozoa PSA	Positive/Indicative Positive/Indicative Positive/Indicative	RSID-Saliva	Negative	<b>Conclusion:</b> Negative
RJ28Y9	Hemastix RSID Blood	Positive/Indicative Positive/Indicative	AP RSID Semen Microscopic Examination	Positive/Indicative Positive/Indicative Positive/Indicative	RSID Saliva	Negative	<b>Conclusion:</b> Negative
RJGF2G	KM TMB HemaTrace	Positive/Indicative Positive/Indicative Positive/Indicative	AP PSA Micro	Positive/Indicative Positive/Indicative Positive/Indicative	RSID	Negative	<b>Conclusion:</b> Negative
RKCZMV	KM OBTI	Positive/Indicative Positive/Indicative	RSID-Semen PSA	Positive/Indicative Positive/Indicative	Generally not tested unless specified		<b>Conclusion:</b> Not Tested

Table 1 - Item 3  
Evidence - Four blue plastic swabs containing Blood & Semen Mixture

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
RQ44Y8	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
RRATXA	HEMASTIX <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	BRENTAMINE <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
RT728F	TMB <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
RT9VQL	see comments section <b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	see comments section <b>Conclusion:</b> Not Tested
RX2XQE	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
RXG4AB	Hemochromogen <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
RYVJNC	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> p30 <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
T6UMQF	TMB <i>Positive/Indicative</i> Hemastix <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
TDB779	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Amylase Diffusion <b>Conclusion:</b> Negative
TJXU6K	<b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
TK3Q4U	HEMASTIX <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	BRENTAMINE <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested

Table 1 - Item 3  
Evidence - Four blue plastic swabs containing Blood & Semen Mixture

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
TLZRC7	LMG	Positive/Indicative	AP	Positive/Indicative	Amylase Diffusion	Negative
			Micro	Positive/Indicative		
			PSA	Positive/Indicative		
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative
TPKL98	Hemophan	Positive/Indicative	RSID Semen	Positive/Indicative	RSID Saliva	Negative
	FOB	Positive/Indicative	PSA	Positive/Indicative		
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative
TPY8KU	KM	Positive/Indicative				
	HemaTrace	Positive/Indicative				
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested
U2DKJA	Visual	Positive/Indicative	Visual	Negative	Visual	Negative
	KM	Positive/Indicative	ALS	Negative	ALS	Negative
	HemaTrace	Positive/Indicative	AP	Positive/Indicative	RSID	Negative
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative
U4ZY9K			AP	Positive/Indicative		
			Micro	Positive/Indicative		
		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested
UA43XH			AP	Positive/Indicative		
			Micro	Positive/Indicative		
		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested
UBHEU3	Visual	Positive/Indicative	ALS	Positive/Indicative		
	O-tol	Positive/Indicative	AP	Positive/Indicative		
	HemaTrace	Positive/Indicative	Micro	Positive/Indicative		
		<b>Conclusion:</b> Positive/Indicative	PSA	Positive/Indicative		
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested
UBYTX6	O-tol	Positive/Indicative	AP	Positive/Indicative	Our Agency does not test for Saliva	
	HEX OBTI	Positive/Indicative				
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested
UD69B4	KM	Positive/Indicative	AP	Positive/Indicative		
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested
UJAUJ7	ALS	Positive/Indicative	ALS	Positive/Indicative	Our lab does not test for Saliva.	
	O-tol	Positive/Indicative	AP	Positive/Indicative		
	OBTI	Positive/Indicative				
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested
UMQJHA	O-tol	Positive/Indicative	AP	Positive/Indicative		
	HemaTrace	Positive/Indicative	PSA	Positive/Indicative		
		<b>Conclusion:</b> Positive/Indicative	Micro	Positive/Indicative		
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested

Table 1 - Item 3  
 Evidence - Four blue plastic swabs containing Blood & Semen Mixture

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
UNPFCD	Visual Positive/Indicative KM Positive/Indicative HemaTrace Positive/Indicative <b>Conclusion:</b> Positive/Indicative	ALS Inconclusive ABACard p30 Positive/Indicative <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
UTYHE9	O-tol Positive/Indicative HemaTrace Positive/Indicative <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested
VCNGT7	O-tol Positive/Indicative HemaTrace Positive/Indicative <b>Conclusion:</b> Positive/Indicative	p30/PSA Positive/Indicative Micro Positive/Indicative <b>Conclusion:</b> Positive/Indicative	RSID-Saliva Negative <b>Conclusion:</b> Negative
VGJ7F6	LMG Positive/Indicative <b>Conclusion:</b> Positive/Indicative	AP Positive/Indicative PSA Positive/Indicative Micro Positive/Indicative <b>Conclusion:</b> Positive/Indicative	Amylase Diffusion Negative <b>Conclusion:</b> Negative
VXTUT6	LMG Positive/Indicative HemaTrace Positive/Indicative <b>Conclusion:</b> Positive/Indicative	AP Positive/Indicative Micro Positive/Indicative PSA Positive/Indicative <b>Conclusion:</b> Positive/Indicative	Amylase Diffusion Negative <b>Conclusion:</b> Negative
VY377Z	SERATEC- HemDirect hemoglobin Assay Positive/Indicative <b>Conclusion:</b> Positive/Indicative	Christmas Tree Stain-Micro Positive/Indicative <b>Conclusion:</b> Positive/Indicative	SERATEC-Amylase Test Negative <b>Conclusion:</b> Negative
W6MFGJ	Hemochromogen Positive/Indicative <b>Conclusion:</b> Positive/Indicative	AP Positive/Indicative Micro Positive/Indicative <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
W7EDQB	KM Positive/Indicative ABACard HemaTrace Positive/Indicative <b>Conclusion:</b> Positive/Indicative	ALS Inconclusive ABACard p30 Positive/Indicative <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
W7H6F7	HEMASTIX Positive/Indicative <b>Conclusion:</b> Positive/Indicative	BRENTAMINE Positive/Indicative <b>Conclusion:</b> Positive/Indicative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
W7HZ4H	pheno Positive/Indicative <b>Conclusion:</b> Positive/Indicative	AP Positive/Indicative Micro Positive/Indicative PSA Positive/Indicative <b>Conclusion:</b> Positive/Indicative	RSID-Saliva Negative <b>Conclusion:</b> Negative
WC7HLZ	KM Positive/Indicative <b>Conclusion:</b> No Response	AP Positive/Indicative PSA Positive/Indicative <b>Conclusion:</b> No Response	Phadebas Amylase Negative <b>Conclusion:</b> No Response
WET9M6	O-tol Positive/Indicative Seratec HemDirect Positive/Indicative <b>Conclusion:</b> Positive/Indicative	AP Positive/Indicative Seratec PSA Positive/Indicative <b>Conclusion:</b> Positive/Indicative	Amylase Diffusion Negative <b>Conclusion:</b> Negative



Table 1 - Item 3  
Evidence - Four blue plastic swabs containing Blood & Semen Mixture

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
WFKMR9	KM	Positive/Indicative	ALS	Positive/Indicative		
			PSA	Positive/Indicative		
			Micro	Positive/Indicative		
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested
WGZMBX	KM	Positive/Indicative	AP	Positive/Indicative	RSID	Negative
			Micro	Positive/Indicative		
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative
WHCE4E	KM	Positive/Indicative	AP	Positive/Indicative		
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested
WHTE3B	LMG	Positive/Indicative	AP	Positive/Indicative	Amylase Radial Diffusion	Inconclusive
	HemaTrace	Positive/Indicative	PSA	Positive/Indicative		
			Micro	Positive/Indicative		
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Inconclusive
WKDHV2	LMG	Positive/Indicative	AP	Positive/Indicative		
			Micro	Positive/Indicative		
			PSA	Positive/Indicative		
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested
WREWG3	KM	Positive/Indicative	AP	Positive/Indicative		
	HemaTrace	Positive/Indicative	PSA	Positive/Indicative		
			Micro	Positive/Indicative		
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested
WUNL77	Visual	Positive/Indicative	AP	Positive/Indicative	RSID	Negative
	LMG	Positive/Indicative	p30	Positive/Indicative		
	HemaTrace	Positive/Indicative	Micro	Positive/Indicative		
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative
WUZP9W	KM	Positive/Indicative				
	HemaTrace	Positive/Indicative				
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested
WWAL2G	KM	Positive/Indicative	AP	Positive/Indicative	RSID	Negative
			Micro	Positive/Indicative		
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative
WYFXTQ	HEMASTIX	Positive/Indicative	BRENTAMINE	Positive/Indicative	NO AVAILABLE TEST FOR Saliva	
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested
X3B7GW	Hem Direct Immunocromatografic SERATEC	Positive/Indicative	Christmas tree coloration	Positive/Indicative	Forensic test Kit SERATEC Amylase test Immunocromatografic	Negative
			Rapid Stain Identification Semen RSID	Positive/Indicative		
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative

Table 1 - Item 3  
Evidence - Four blue plastic swabs containing Blood & Semen Mixture

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
X6KZP4	Hemastix <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
X9ZNU9	Hemochromogen <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
XENFB3	Visual <i>Positive/Indicative</i> KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> No Response	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> No Response	Phadebas paper <i>Negative</i> <b>Conclusion:</b> No Response
XF2TU6	Visual <i>Positive/Indicative</i> LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> p30 <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
XPMX36	KM <i>Positive/Indicative</i> Modified Takayama <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Phadebas <i>Negative</i> <b>Conclusion:</b> Negative
XQK9X8	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> ALS <i>Negative</i> <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
XW6FC7	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Amylase radial Diffusion <i>Inconclusive</i> <b>Conclusion:</b> Inconclusive
XZ8C2Z	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
Y44E48	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
Y6GWGK	HEMASTIX <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	BRENTAMINE <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
Y8JR6U	HemDirect Hemoglobin (SERATEC) <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Christmas Tree Coloring <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Amylase Test (SERATEC) <i>Negative</i> <b>Conclusion:</b> Negative

Table 1 - Item 3  
Evidence - Four blue plastic swabs containing Blood & Semen Mixture

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
YKN8N6	TMB <i>Positive/Indicative</i> FOB <i>Positive/Indicative</i> Seratec PMB Test peripheral <i>Positive/Indicative</i> Seratec PMB Test menstrual <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> RSID Semen <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID Saliva <i>Negative</i> Seratec alpha Amylase test <i>Negative</i> <b>Conclusion:</b> Negative
YQDKUY	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> p30 <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	SALigAE <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative
YXEV6X	O-tol <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Scenario didn't support this analysis <b>Conclusion:</b> Not Tested
Z6CT77	KM <i>Positive/Indicative</i> <b>Conclusion:</b> No Response	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> No Response	Saliva testing not performed in lab <b>Conclusion:</b> Not Tested
ZAHM23	LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	NT <b>Conclusion:</b> Not Tested
ZFBUGP	HEMASTIX <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	BRENTAMINE <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
ZM8LR6	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Do not perform <b>Conclusion:</b> Not Tested
ZPJAFB	Micro <i>Positive/Indicative</i> KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
ZUCGUD	<b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
ZWYX9R	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i> <b>Conclusion:</b> Negative

**Response Summary for Table 1 -  
Item 3: Four blue plastic swabs containing Blood & Semen Mixture**

	<u>Blood</u>	<u>Semen</u>	<u>Saliva</u>
Positive/Indicative	213	211	3
Negative	0	1	92
Inconclusive	0	0	4
Not Tested (NT)	9	11	129
No Response	10	9	4
Total	232	232	232

# Screening Conclusions & Test(s) Performed

Indicate the overall conclusion from the results of the screening tests performed.

Table 1 - Item 4

Evidence - Four yellow plastic swabs containing Blood & Saliva Mixture

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
24D4LA	KM HemaTrace	Positive/Indicative Positive/Indicative	AP PSA Micro	Negative Negative Negative		The [Laboratory] does not conduct forensic serological tests for Saliva.
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested
24XLKP			AP	Negative		
		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested
27ZRVP	HEMASTIX	Positive/Indicative				NO AVAILABLE TEST FOR Saliva
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested
2HAFUE	KM	Positive/Indicative	AP	Negative		RSID
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative
2PGRAY	LMG HemaTrace	Positive/Indicative Positive/Indicative	AP Micro	Negative Negative		Amylase Diffusion
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative
2QN273	KM	Positive/Indicative		Scenario did not support testing for Semen		RSID
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Positive/Indicative
3EC4Q2	LMG HemaTrace	Positive/Indicative Positive/Indicative	AP PSA Micro	Negative Negative Negative		Amylase Radial Diffusion
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative
3HUDM7	TMB HemaTrace	Positive/Indicative Positive/Indicative	AP	Negative		RSID
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative
3KX989	KM	Positive/Indicative	AP	Negative		
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested
3KXA9U	O-tol HemaTrace	Positive/Indicative Positive/Indicative		Scenario does not suggest Semen present on this sample.		RSID
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Positive/Indicative
3QHEXN	LMG	Positive/Indicative		see additional comments		see additional comments
		<b>Conclusion:</b> No Response		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested
3RYBLG	HEMASTIX	Positive/Indicative				NO AVAILABLE TEST FOR Saliva
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested
3U376K	HEMASTIX	Positive/Indicative	BRENTAMINE	Negative		NO AVAILABLE TEST FOR Saliva
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested

Table 1 - Item 4  
 Evidence - Four yellow plastic swabs containing Blood & Saliva Mixture

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
447TM9	Micro KM	Positive/Indicative Positive/Indicative	AP Micro	Negative Negative	RSID	Positive/Indicative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
4ABGEP	SERATEC HemDirect	Positive/Indicative	Christmas Tree Immunochromatography Test identification of Human Semen (RSID-Semen)	Negative Negative	SERATEC Amylase Test	Positive/Indicative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
4B9RAR	HemDirect Hemoglobin Seratec	Positive/Indicative	Not tested		Amylase test Seratec	Positive/Indicative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Positive/Indicative	
4BN4RW	LMG	Positive/Indicative	AP Micro PSA	Negative Negative Negative	Amylase Diffusion	Positive/Indicative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
4E79LL	KM OBTI	Positive/Indicative Positive/Indicative	Not tested based on case scenario		RSID-Saliva	Positive/Indicative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Positive/Indicative	
4JLRRR	Micro KM	Positive/Indicative Positive/Indicative	AP Micro	Negative Negative	RSID	Positive/Indicative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
4K8M4G	Hemastix (HemaTrace)	Positive/Indicative	Not tested due to nature of where body fluid was collected and case summary		Saliva test swabs not tested according to SOP (no presumptive testing)	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
4L7NCT	PTMB	Positive/Indicative				
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
4LA7EY	KM Modified Takayama	Positive/Indicative Positive/Indicative	AP	Negative	Phadebas Amylase	Positive/Indicative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
4QDG2H	KM HemaTrace	Positive/Indicative Positive/Indicative				
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
4UKGK4	KM	Positive/Indicative	AP	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
4V7FET	SERATEC HemDirect	Positive/Indicative	Christmas tree Immunochromatography test Rapid Stain Identification of Human Semen (RSID-Semen) SERATEC-PSA	Negative Negative Negative	SERATEC Amylase Test	Positive/Indicative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	

**Table 1 - Item 4**  
**Evidence - Four yellow plastic swabs containing Blood & Saliva Mixture**

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
4XZ2BQ	LMG	Positive/Indicative	ALS	Negative		
		<b>Conclusion:</b> Positive/Indicative	AP	Negative		<b>Conclusion:</b> Not Tested
62TKQU	PTMB	Positive/Indicative	AP	Negative	Phadebas Tablets	Positive/Indicative
		<b>Conclusion:</b> Positive/Indicative	PSA	Negative		<b>Conclusion:</b> Positive/Indicative
66TUYA	HT, Hemastix, KM	Positive/Indicative	not run due to scenario provided		RSID-Saliva	Positive/Indicative
		<b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested			<b>Conclusion:</b> Positive/Indicative
67PA82	KM	Positive/Indicative	AP	Negative		
		<b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Negative			<b>Conclusion:</b> Not Tested
68KVZR	PTMB	Positive/Indicative	No indication of seminal fluid.		Phadebas Tablet	Positive/Indicative
		<b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested			<b>Conclusion:</b> Positive/Indicative
6B3X4Q	Kastle Meyer/3% Hydrogen Peroxide	Positive/Indicative	Per case scenario, no need to test for Semen on this item.		RSID-Saliva	Positive/Indicative
		<b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested			<b>Conclusion:</b> Positive/Indicative
6CWLLL	PTMB	Positive/Indicative	AP, PSA, Micro	Negative	Phadebas	Positive/Indicative
		<b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Negative			<b>Conclusion:</b> Positive/Indicative
6H3EEW	Phenolphthalein	Positive/Indicative	p30	Negative	Phadebas	Positive/Indicative
		<b>Conclusion:</b> Positive/Indicative	Micro	Negative		<b>Conclusion:</b> Positive/Indicative
6PKQLW	Hemastix	Positive/Indicative	Triaging scientist did not request breast swab for Semen detection		RSID	Positive/Indicative
	HemaTrace	Positive/Indicative	<b>Conclusion:</b> Not Tested			<b>Conclusion:</b> Positive/Indicative
6VPH62	Hemastix	Positive/Indicative				
		<b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested			<b>Conclusion:</b> Not Tested
	<u>Other Tests Performed</u>					
	Alternate Light Source Negative					
776VCW	LMG	Positive/Indicative	AP	Negative	Saliva testing is not performed at the laboratory.	
	HemaTrace	Positive/Indicative	PSA	Negative	<b>Conclusion:</b> Not Tested	
		<b>Conclusion:</b> Positive/Indicative	Micro	Negative		
7CTBC2	TMB	Positive/Indicative	Alleged ejaculation in vagina		RSID	Positive/Indicative
	HemaTrace	Positive/Indicative	<b>Conclusion:</b> Not Tested			<b>Conclusion:</b> Positive/Indicative
7CWXP9	Phenolphthalein	Positive/Indicative	Acid Phosphatase	Negative	RSID	Positive/Indicative
		<b>Conclusion:</b> Positive/Indicative	Micro	Negative		<b>Conclusion:</b> Positive/Indicative
			<b>Conclusion:</b> Negative			

Table 1 - Item 4  
Evidence - Four yellow plastic swabs containing Blood & Saliva Mixture

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
7U9PLJ	KM <i>Positive/Indicative</i> OBTI <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Not tested based on case scenario. <b>Conclusion:</b> Not Tested	RSID-Saliva <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
7V63AW	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Micro <i>Negative</i> PSA <i>Negative</i> <b>Conclusion:</b> Negative	Laboratory does not test for Saliva <b>Conclusion:</b> Not Tested
89PX43	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Scenario did not warrant testing. <b>Conclusion:</b> Not Tested	[Laboratory] does not routinely test for Saliva. <b>Conclusion:</b> Not Tested
8NM624	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
8QN8Q6	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
8UNBTZ	LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	Amylase Radial Diffusion <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
92M92N	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
94QAGR	BLUESTAR (LUMINOL) <i>Positive/Indicative</i> HEXAGON OBTI TEST <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	Phadebas <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
97KPG4	KM <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
987KRA	HEMASTIX <i>Positive/Indicative</i> LUMINOL <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
9J6AWQ	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> PSA <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
9RWMWQ	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested



Table 1 - Item 4  
Evidence - Four yellow plastic swabs containing Blood & Saliva Mixture

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
9TC7FM	LMG	Positive/Indicative	AP	Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
9TT6UK	LMG	Positive/Indicative	AP	Negative	Amylase Diffusion	Positive/Indicative
			Micro	Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Positive/Indicative
A49C8Z	LMG	Positive/Indicative	AP	Negative	RSID	Positive/Indicative
	HemaTrace	Positive/Indicative				
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Positive/Indicative
A4L4XW	KM	Positive/Indicative	scenario does not support testing		RSID	Positive/Indicative
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Not Tested	<b>Conclusion:</b>	Positive/Indicative
AARLDN	LMG, HemDirect	Positive/Indicative	AP	Negative	Saliva is not tested	
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
AB9QVM	O-tol	Positive/Indicative	Case scenario does not indicate the need for this testing.		RSID	Positive/Indicative
	HemaTrace	Positive/Indicative				
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Not Tested	<b>Conclusion:</b>	Positive/Indicative
AMYUTL	KM	Positive/Indicative	Not tested based on case scenario.		RSID-Saliva	Positive/Indicative
	OBTI	Positive/Indicative				
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Not Tested	<b>Conclusion:</b>	Positive/Indicative
AP8KHP	Phenolphthalein	Positive/Indicative	Microscopic Examination	Negative	Phadebas	Positive/Indicative
			Seminal Fluid - p30	Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Positive/Indicative
AQW9HW	KM	Positive/Indicative	ALS	Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
AW84KK	KM	Positive/Indicative	AP	Negative	Amylase	Positive/Indicative
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Positive/Indicative
AYDKY4			AP	Negative		
	<b>Conclusion:</b>	Not Tested	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
B2BMZP	LMG	Positive/Indicative	AP	Negative	Amylase Diffusion	Positive/Indicative
			Micro	Negative		
			PSA	Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Positive/Indicative
B3839F	KM	Positive/Indicative	Micro	Negative	Not validated procedure	
			p30	Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested

Table 1 - Item 4  
Evidence - Four yellow plastic swabs containing Blood & Saliva Mixture

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
B4JQUZ	KM HemaTrace	Positive/Indicative Positive/Indicative	Micro PSA	Negative Negative		Saliva testing not offered by our laboratory
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
BBLR7N	LMG RSID	Positive/Indicative Positive/Indicative	AP RSID	Negative Negative		RSID
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Positive/Indicative
BCFFPJ	Visual examination KM	Positive/Indicative Positive/Indicative				Phadebas Tube Test
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Not Tested	<b>Conclusion:</b>	Positive/Indicative
BFVW63	Micro KM	Positive/Indicative Positive/Indicative	AP Micro	Negative Negative		RSID
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Positive/Indicative
BHL7WV	KM	Positive/Indicative	ALS	Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
BKMANH	LMG	Positive/Indicative	AP Micro	Negative Negative		Amylase Diffusion
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Positive/Indicative
BQBWEG	HemDirect Seratec	Positive/Indicative	Micro PSA	Negative Negative		Amylase Seratec
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Positive/Indicative
BT7FKP	LMG HemaTrace	Positive/Indicative Positive/Indicative	AP PSA	Negative Negative		Amylase Diffusion
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Positive/Indicative
BUB9BG	HemDirect Hemoglobin (SERATEC)	Positive/Indicative	Christmas Tree Stain Slide (Micro) PSA Semiquant (SERATEC)	Negative Negative		Amylase Test (SERATEC)
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Positive/Indicative
BVQAGP	LMG ([Laboratory]: Leuco-Malachite)	Positive/Indicative	AP	Negative		[Laboratory] does not employ tests for Saliva
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
C8J7Z3	Hemastix	Positive/Indicative	p30	Negative		RSID
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Positive/Indicative
CBXYV3	O-tol HemaTrace	Positive/Indicative Positive/Indicative				RSID
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Not Tested	<b>Conclusion:</b>	Positive/Indicative
CFCELU	Phenolphthalein Takayama	Positive/Indicative Positive/Indicative	Acid Phosphatase	Negative		Phadebas
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Positive/Indicative

Table 1 - Item 4  
 Evidence - Four yellow plastic swabs containing Blood & Saliva Mixture

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
CNJDUV	KM HEXAGON OBTI <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	case scenario <b>Conclusion:</b> Not Tested	Phadebas <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
CUTGYB	KM <i>Positive/Indicative</i> <b>Conclusion:</b> No Response	Micro, p30 <i>Negative</i> <b>Conclusion:</b> No Response	<b>Conclusion:</b> Not Tested
D7426P	Visual <i>Positive/Indicative</i> LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID-Saliva <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
D94JU6	HEMASTIX <i>Positive/Indicative</i> LUMINOL <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	BRENTAMINE <b>Conclusion:</b> Negative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
DF7NRF	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	N/A per scenario <b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested
	<u>Other Tests Performed</u> Amylase Diffusion <i>Positive/Indicative</i>		
DKXZJ7	Hemastix Test (TMB) <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	No evidential value <b>Conclusion:</b> Not Tested	No presumptive test for Saliva in ER. Swab will be submitted for DNA analysis <b>Conclusion:</b> Not Tested
DXNMY	<b>Conclusion:</b> Not Tested	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
E3A4KN	LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> Ouchterlony <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Micro <i>Negative</i> PSA <i>Negative</i> <b>Conclusion:</b> Negative	Amylase Radial Diffusion <i>Positive/Indicative</i> Micro <i>Negative</i> <b>Conclusion:</b> Positive/Indicative
EC6X2V	LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> Visual Examination <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
EGZPDX	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
EJN4ZM	Phenolphthalein <i>Positive/Indicative</i> Modified Takyama <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Acid Phosphatase <i>Negative</i> <b>Conclusion:</b> Negative	Phadebas <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
ELP4ZK	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> PSA <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested

Table 1 - Item 4  
Evidence - Four yellow plastic swabs containing Blood & Saliva Mixture

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
EM3NZG	Seratec HEM LN 200076 D.D: 22-09 Positive/Indicative  <b>Conclusion:</b> Positive/Indicative	RSID LN 09120S1 D. D. 22-09 Negative Christmas Tree Negative  <b>Conclusion:</b> Negative	Seratec AMY LN 200078 D.D: 22-09 Positive/Indicative  <b>Conclusion:</b> Positive/Indicative
EPBXTE	Human Blood Positive/Indicative  <b>Conclusion:</b> Positive/Indicative	CHRISTMAS TREE Negative SemenOGELINA Negative  <b>Conclusion:</b> Negative	Human Saliva Positive/Indicative  <b>Conclusion:</b> Positive/Indicative
ERGE8W	KM Positive/Indicative  <b>Conclusion:</b> Positive/Indicative	AP Negative  <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
EYDBVZ	Phenolphthalein Positive/Indicative HemaTrace Positive/Indicative  <b>Conclusion:</b> Positive/Indicative	AP Negative  <b>Conclusion:</b> Negative	RSID Positive/Indicative  <b>Conclusion:</b> Positive/Indicative
FATH8U	Visual Positive/Indicative LMG Positive/Indicative HemaTrace Positive/Indicative  <b>Conclusion:</b> Positive/Indicative	AP Negative  <b>Conclusion:</b> Negative	RSID Positive/Indicative  <b>Conclusion:</b> Positive/Indicative
FC3HEM	KM Positive/Indicative HemaTrace Positive/Indicative  <b>Conclusion:</b> Positive/Indicative	AP Negative  <b>Conclusion:</b> Negative	Blue paper test Positive/Indicative  <b>Conclusion:</b> Positive/Indicative
FHJBBD	Kastle-Meyer Positive/Indicative  <b>Conclusion:</b> Positive/Indicative	Acid phosphatase Negative Microscopy and Christmas Tree staining Negative  <b>Conclusion:</b> Negative	Phadebas tube test Positive/Indicative  <b>Conclusion:</b> Positive/Indicative
FKR6D6	TMB (Hstix) Positive/Indicative  <b>Conclusion:</b> Positive/Indicative	Not tested due to nature of where body fluid is collected and case summary  <b>Conclusion:</b> Not Tested	No presumptive test for Saliva  <b>Conclusion:</b> Not Tested
FP8NMZ	KM Positive/Indicative HemaTrace Positive/Indicative  <b>Conclusion:</b> Positive/Indicative	AP Negative p30 Negative Micro Negative  <b>Conclusion:</b> Negative	Phadebas Positive/Indicative  <b>Conclusion:</b> Positive/Indicative
FQ2ELM	HEMASTIX Positive/Indicative  <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	NO AVAILABLE TEST FOR Saliva  <b>Conclusion:</b> Not Tested
FQHTUW	KM Positive/Indicative Luminol Positive/Indicative  <b>Conclusion:</b> Positive/Indicative	AP Negative  <b>Conclusion:</b> Negative	RSID Positive/Indicative  <b>Conclusion:</b> Positive/Indicative
FXXDW9	KM Positive/Indicative OBTI Positive/Indicative  <b>Conclusion:</b> Positive/Indicative	Not tested based on case scenario.  <b>Conclusion:</b> Not Tested	RSID-Saliva Positive/Indicative  <b>Conclusion:</b> Positive/Indicative

Table 1 - Item 4  
Evidence - Four yellow plastic swabs containing Blood & Saliva Mixture

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
G2QWBC	Visual, KM <i>Positive/Indicative</i> <b>Conclusion:</b> No Response	<b>Conclusion:</b> Not Tested	Phadebas Tube <i>Positive/Indicative</i> <b>Conclusion:</b> No Response
G43C6D	Visual and KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Xmas Tree Slide <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Phadebas <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
G4LB8G	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
G6R26K	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Micro <i>Negative</i> PSA <i>Negative</i> <b>Conclusion:</b> Negative	Amylase Diffusion <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
GD9E9P	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
GDUVL8	KM <i>Positive/Indicative</i> OBTI <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Not tested based on case scenario - taken from victim's breast. <b>Conclusion:</b> Not Tested	RSID-Saliva <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
GL4D2J	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> PSA <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
GP7BEX	TMB <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> RSID <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	Phadebas <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
GUZ6CY	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	based on case history not tested for Semen <b>Conclusion:</b> Not Tested	[Laboratory] biology does not test swabs for the presence of Saliva (using the Phadebas press test). <b>Conclusion:</b> Not Tested
HBXUYF	PTMB <i>Positive/Indicative</i> RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Not online with seminal fluid screening <b>Conclusion:</b> Not Tested	Not online with Saliva screening <b>Conclusion:</b> Not Tested
HKMHYN	KM <i>Positive/Indicative</i> Modified Takayama <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	Phadebas <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
HLFHP9	HEMASTIX <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
HQB89Z	HEMASTIX <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	BRENTAMINE <i>Negative</i> <b>Conclusion:</b> Negative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested

Table 1 - Item 4  
 Evidence - Four yellow plastic swabs containing Blood & Saliva Mixture

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
HYKPTJ	KM <i>Positive/Indicative</i> Modified Takayama <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	Phadebas Amylase <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
J2T2AL	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Scenario did not provide any details that would lead me to test for Semen <b>Conclusion:</b> Not Tested	RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
J8YXUL	KM <i>Positive/Indicative</i> Heme-direct <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	No Saliva testing at Lab <b>Conclusion:</b> Not Tested
JGGLF8	HEMASTIX <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
K4Q6CR	KM, Hemastix, HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID Saliva <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
	<u>Other Tests Performed</u> Body Fluid - Test Performed: ALS <i>Negative</i>		
K8PF9R	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
KBAB8D	TMB <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> PSA <i>Negative</i> Microscopic <i>Negative</i> <b>Conclusion:</b> Negative	alpha-Amylase test card <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
KED2FE	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> PSA <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
KF2JBK	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> PSA <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
KMLH4D	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
	<u>Other Tests Performed</u> HEMDIRECT <i>Positive/Indicative</i>		
KWN32Z	Hstix (KM) <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Due to nature of where the body fluid was collected according to the SOP <b>Conclusion:</b> Not Tested	As per SOP no prelim tests for Saliva to be performed <b>Conclusion:</b> Not Tested

Table 1 - Item 4  
Evidence - Four yellow plastic swabs containing Blood & Saliva Mixture

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
KYVDX4	KM OBTI	Positive/Indicative Positive/Indicative	Not tested based on case scenario		RSID-Saliva	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Positive/Indicative	
L47NTJ	KM	Positive/Indicative	ALS		Negative	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
L7D2GC	LMG	Positive/Indicative	AP		Negative	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
L9YRHG	KM TEST RSID-Blood	Positive/Indicative Positive/Indicative	AP TEST		Negative	
	<b>Conclusion:</b> No Response		<b>Conclusion:</b> No Response		<b>Conclusion:</b> No Response	
LA84XW	HEMASTIX	Positive/Indicative			NO AVAILABLE TEST FOR Saliva	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
LBC97F	Visual KM	Positive/Indicative Positive/Indicative	AP		Negative	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
LNPRB2	KM OBTI	Positive/Indicative Positive/Indicative	Not tested based on case scenario		RSID-Saliva	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Positive/Indicative	
M2XQ6T	TMB HemaTrace	Positive/Indicative Positive/Indicative	AP PSA		Negative Negative	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
M6CLLQ	TMB	Positive/Indicative			Phadebas	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Positive/Indicative	
MGNXUE	LMG	Positive/Indicative	AP Micro		Negative Negative	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
MH42MK	KM	Positive/Indicative	Based on scenario, there was no indication of Semen on the victim's breast			
	<b>Conclusion:</b> No Response		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
MHGTDG	KM - Hemophan (paper test for Blood erythrocytes, haemoglobin) by Erba Lachema - non-specific test for Blood FOB - cassette test for determination of faecal occult Blood by NADAL - specific test for Human Blood				RSID-Saliva	
	Positive/Indicative Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Positive/Indicative	
MLM86G	KM HemaTrace	Positive/Indicative Positive/Indicative	AP		Negative	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	

Table 1 - Item 4  
Evidence - Four yellow plastic swabs containing Blood & Saliva Mixture

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
MP2R6B	Seratec HemDirect	Positive/Indicative	Micro	Negative	Seratec Amylase Test	Positive/Indicative
		<b>Conclusion:</b> Positive/Indicative	Seratec PSA	Negative		<b>Conclusion:</b> Positive/Indicative
MUB6RF	KM	Positive/Indicative	AP	Negative		
		<b>Conclusion:</b> Positive/Indicative	Micro	Negative		<b>Conclusion:</b> Not Tested
			PSA	Negative		
MVA9KQ	Hemastix	Positive/Indicative	AP	Negative		
	KM	Positive/Indicative				<b>Conclusion:</b> Not Tested
		<b>Conclusion:</b> Positive/Indicative				
MW4W4L	KM	Positive/Indicative	AP	Negative	RSID	Positive/Indicative
		<b>Conclusion:</b> Positive/Indicative				<b>Conclusion:</b> Positive/Indicative
MZLBBT	TMB	Positive/Indicative	AP	Negative	RSID	Positive/Indicative
	HemaTrace	Positive/Indicative				<b>Conclusion:</b> Positive/Indicative
		<b>Conclusion:</b> Positive/Indicative				
N4UXGG	KM	Positive/Indicative	ALS	Negative		
		<b>Conclusion:</b> Positive/Indicative				<b>Conclusion:</b> Not Tested
NPXL8D	KM	Positive/Indicative	No test needed per case scenario			
		<b>Conclusion:</b> Positive/Indicative				<b>Conclusion:</b> Not Tested
NXRWAV	TMB -Hstix	Positive/Indicative	No presumptive test for Semen according to scenario		No presumptive test for Saliva according to SOP BIO0008P	Inconclusive
		<b>Conclusion:</b> Positive/Indicative				<b>Conclusion:</b> Inconclusive
P3FYU7	SERATEC-SANGRE	Positive/Indicative	MicroSCOPIO	Negative	SERATEC-Saliva	Positive/Indicative
		<b>Conclusion:</b> Positive/Indicative	RSID-Semen	Negative		<b>Conclusion:</b> Positive/Indicative
P69KR4	LMG	Positive/Indicative	AP	Negative	Amylase Diffusion	Positive/Indicative
	HemaTrace	Positive/Indicative	Micro	Negative		<b>Conclusion:</b> Positive/Indicative
		<b>Conclusion:</b> Positive/Indicative				
P8RWB7	LMG	Positive/Indicative	AP	Negative		
		<b>Conclusion:</b> Positive/Indicative				<b>Conclusion:</b> Not Tested
PAX8GH	[Participant did not return results for Item 4]					
PEULCK	KM	Positive/Indicative	Not tested based on scenario of incident/location of collection		The [Laboratory] does not perform tests for Saliva	
	HemaTrace	Positive/Indicative				<b>Conclusion:</b> Not Tested
		<b>Conclusion:</b> Positive/Indicative				
PF4ZDY	KM	Positive/Indicative	Not tested based on case scenario		RSID-Saliva	Positive/Indicative
	OBTI	Positive/Indicative				<b>Conclusion:</b> Positive/Indicative
		<b>Conclusion:</b> Positive/Indicative				



Table 1 - Item 4  
Evidence - Four yellow plastic swabs containing Blood & Saliva Mixture

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
PN2NBQ	KM	Positive/Indicative	AP	Negative	RSID Saliva	Positive/Indicative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
PU4R3A	KM	Positive/Indicative	AP	Negative		
	HemaTrace	Positive/Indicative	PSA	Negative		
			Micro	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
Q62YBE	Leucomalachite Green	Positive/Indicative	No tests available.		No tests available.	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
QC3ALD	KM	Positive/Indicative	ALS	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
QDWVJB	KM	Positive/Indicative	AP	Negative	Phadebas	Positive/Indicative
	Modified Takayama	Positive/Indicative				
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
QGHK4N			AP	Negative		
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
QP966F	KM	Positive/Indicative	ALS	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
QQ3V99	ALS	Negative	AP	Negative	ALS	Negative
	KM	Positive/Indicative	ALS	Negative	RSID	Positive/Indicative
	RSID	Positive/Indicative	RSID	Negative		
			Micro	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
QRFNNA	KM	Positive/Indicative	AP SPOT	Negative		
	<b>Conclusion:</b> No Response		<b>Conclusion:</b> No Response		<b>Conclusion:</b> Not Tested	
QYE6K9	KM	Positive/Indicative	AP	Negative		
	HemaTrace	Positive/Indicative	PSA	Negative		
			Micro	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
R3UUJC	KM	Positive/Indicative	PSA	Negative	Saliva RSID	Positive/Indicative
	HemaTrace	Positive/Indicative	Micro-Sperm	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
R6ZHWF	HemaStix	Positive/Indicative	Acid Phosphatase	Negative	RSID-Saliva	Positive/Indicative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
RJ28Y9	Hemastix	Positive/Indicative	AP	Negative	RSID Saliva	Positive/Indicative
	RSID Blood	Positive/Indicative	RSID Semen	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	

Table 1 - Item 4  
Evidence - Four yellow plastic swabs containing Blood & Saliva Mixture

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
RJGF2G	KM TMB	Positive/Indicative Positive/Indicative	AP	Negative	RSID	Positive/Indicative
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Positive/Indicative
RKCZMV	KM OBTI	Positive/Indicative Positive/Indicative	Not tested based on case scenario		RSID-Saliva	Positive/Indicative
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Not Tested	<b>Conclusion:</b>	Positive/Indicative
RQ44Y8	KM HemaTrace	Positive/Indicative Positive/Indicative	AP PSA Micro	Negative Negative Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
RRATXA	HEMASTIX	Positive/Indicative	BRENTAMINE	Negative	NO AVAILABLE TEST FOR Saliva	
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
RT728F	TMB HemaTrace	Positive/Indicative Positive/Indicative	AP Micro	Negative Negative	RSID	Positive/Indicative
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Positive/Indicative
RT9VQL	see comments section		AP	Negative	see comments section	
	<b>Conclusion:</b>	Not Tested	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
RX2XQE	KM	Positive/Indicative	ALS	Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
RXG4AB	Hemochromogen Positive/Indicative					
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Not Tested	<b>Conclusion:</b>	Not Tested
RYVJNC	KM HemaTrace	Positive/Indicative Positive/Indicative	AP	Negative	RSID	Positive/Indicative
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Positive/Indicative
T6UMQF	TMB HemaTrace	Positive/Indicative Positive/Indicative	AP	Negative	RSID	Positive/Indicative
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Positive/Indicative
TDB779	LMG	Positive/Indicative	AP	Negative	Amylase Diffusion	Positive/Indicative
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Positive/Indicative
TJXU6K			AP	Negative		
	<b>Conclusion:</b>	Not Tested	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
TK3Q4U	HEMASTIX Positive/Indicative				NO AVAILABLE TEST FOR Saliva	
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Not Tested	<b>Conclusion:</b>	Not Tested
TLZRC7	LMG	Positive/Indicative	AP Micro PSA	Positive/Indicative Negative Negative	Amylase Diffusion	Positive/Indicative
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Positive/Indicative

Table 1 - Item 4  
Evidence - Four yellow plastic swabs containing Blood & Saliva Mixture

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
TPKL98	HEMOPHAN FOB <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative	RSID Semen PSA <b>Conclusion:</b> Negative	Negative Negative	RSID Saliva <b>Conclusion:</b> Positive/Indicative	Positive/Indicative
TPY8KU	KM HemaTrace <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
U2DKJA	Visual KM HemaTrace <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative Positive/Indicative	Per scenario- no indication of penile contact with victim's breast <b>Conclusion:</b> Not Tested		Visual ALS RSID <b>Conclusion:</b> Positive/Indicative	Negative Negative Positive/Indicative
U4ZY9K	<b>Conclusion:</b> Not Tested		AP <b>Conclusion:</b> Negative	Negative	<b>Conclusion:</b> Not Tested	
UA43XH	<b>Conclusion:</b> Not Tested		AP <b>Conclusion:</b> Negative	Negative	<b>Conclusion:</b> Not Tested	
UBHEU3	Visual O-tol HemaTrace <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative Positive/Indicative	ALS AP <b>Conclusion:</b> Negative	Positive/Indicative Negative	<b>Conclusion:</b> Not Tested	
UBYTX6	O-tol HEX OBTI <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative	AP <b>Conclusion:</b> Negative	Negative	<b>Conclusion:</b> Not Tested	
UD69B4	KM <b>Conclusion:</b> Positive/Indicative	Positive/Indicative	<b>Conclusion:</b> Not Tested		Phadebas <b>Conclusion:</b> Positive/Indicative	Positive/Indicative
UJAUJ7	ALS O-tol OBTI <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative Positive/Indicative	ALS AP <b>Conclusion:</b> Negative	Positive/Indicative Negative	Our lab does not test for Saliva. <b>Conclusion:</b> Not Tested	
UMQJHA	O-tol HemaTrace <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative	AP PSA Micro <b>Conclusion:</b> Negative	Negative Negative Negative	<b>Conclusion:</b> Not Tested	
UNPFCD	Visual KM HemaTrace <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative Positive/Indicative	ALS ABAcad p30 <b>Conclusion:</b> Negative	Inconclusive Negative	<b>Conclusion:</b> Not Tested	
UTYHE9	O-tol HemaTrace <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	

Table 1 - Item 4  
Evidence - Four yellow plastic swabs containing Blood & Saliva Mixture

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
VCNGT7	O-tol <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	NT: case scenario did not indicate a need for this test <b>Conclusion:</b> Not Tested	RSID-Saliva <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
VGJ7F6	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> PSA <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	Amylase Diffusion <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
VXTUT6	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Micro <i>Negative</i> PSA <i>Negative</i> <b>Conclusion:</b> Negative	Amylase Diffusion <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
VY377Z	SERATEC- HemDirect hemoglobin Assay <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Christmas Tree Stain-Micro <i>Negative</i> RSID Semen <i>Negative</i> <b>Conclusion:</b> Negative	SERATEC-Amylase Test <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
W6MFGJ	Hemochromogen <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested
W7EDQB	KM <i>Positive/Indicative</i> ABACard HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Inconclusive</i> ABACard p30 <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
W7H6F7	HEMASTIX <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
W7HZ4H	pheno <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID-Saliva <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
WC7HLZ	KM <i>Positive/Indicative</i> <b>Conclusion:</b> No Response	AP <i>Negative</i> PSA <i>Negative</i> <b>Conclusion:</b> No Response	Phadebas Amylase <i>Positive/Indicative</i> <b>Conclusion:</b> No Response
WET9M6	O-tol <i>Positive/Indicative</i> Seratec HemDirect <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Seratec PSA <i>Negative</i> <b>Conclusion:</b> Negative	Amylase Diffusion <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
WFKMR9	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
WGZMBX	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
WHCE4E	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested

Table 1 - Item 4  
Evidence - Four yellow plastic swabs containing Blood & Saliva Mixture

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
WHITE3B	LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> PSA <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	Amylase Radial Diffusion <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
WKDHV2	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
WREWG3	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> PSA <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
WUNL77	Visual <i>Positive/Indicative</i> LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
WUZP9W	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested
WWAL2G	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
WYFXTQ	HEMASTIX <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
X3B7GW	Hem Direct Immunocromatografic SERATEC <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Christmas tree coloration <i>Negative</i> Rapid Stain Identification Semen RSID <i>Negative</i> <b>Conclusion:</b> Negative	Forensic test Kit SERATEC Amylase test Immunocromatografic <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
X6KZP4	Hemastix <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Breast swab not requested for testing by Triage scientist <b>Conclusion:</b> Not Tested	RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative
X9ZNU9	Hemochromogen <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested
XENFB3	Visual <i>Positive/Indicative</i> KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> No Response	Not tested for Semen as swabs taken from breast due to alleged biting. Therefore Semen not a consideration in this sample. <b>Conclusion:</b> Not Tested	Phadebas Paper <i>Negative</i> <b>Conclusion:</b> No Response
XF2TU6	Visual <i>Positive/Indicative</i> LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative

Table 1 - Item 4  
Evidence - Four yellow plastic swabs containing Blood & Saliva Mixture

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
XPMX36	KM	Positive/Indicative	AP	Negative	Phadebas	Positive/Indicative
	Modified Takayama	Positive/Indicative				
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Positive/Indicative
XQK9X8	KM	Positive/Indicative	Scenario gave no indication to warrant this testing		RSID	Positive/Indicative
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Not Tested	<b>Conclusion:</b>	Positive/Indicative
XW6FC7	KM	Positive/Indicative	AP	Negative	Amylase radial Diffusion	Positive/Indicative
	HemaTrace	Positive/Indicative	Micro	Negative		
			PSA	Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Positive/Indicative
XZ8C2Z	KM	Positive/Indicative	AP	Negative		
	HemaTrace	Positive/Indicative	PSA	Negative		
			Micro	Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
Y44E48	KM	Positive/Indicative	AP	Negative		
			Micro	Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
Y6GWGK	HEMASTIX	Positive/Indicative	BRENTAMINE	Negative	NO AVAILABLE TEST FOR Saliva	
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Not Tested
Y8JR6U	HemDirect Hemoglobin (SERATEC)	Positive/Indicative	Christmas Tree Coloring	Negative	Amylase Test (SERATEC)	Positive/Indicative
			Inmunocromatographic Test (Semen-RSID)	Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	No Response	<b>Conclusion:</b>	Positive/Indicative
YKN8N6	TMB	Positive/Indicative	AP	Negative	RSID Saliva	Positive/Indicative
	FOB	Positive/Indicative	RSID Semen	Negative	Seratec alpha Amylase	Positive/Indicative
	Seratec PMB Test menstrual	Negative				
	Seratec PMB Test peripheral	Positive/Indicative				
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Positive/Indicative
YQDKUY	KM	Positive/Indicative	AP	Negative	SALIGAE	Positive/Indicative
	HemaTrace	Positive/Indicative	p30	Negative	Micro	Positive/Indicative
			Micro	Negative		
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Negative	<b>Conclusion:</b>	Positive/Indicative
YXE6X	O-tol	Positive/Indicative	Scenario didn't support this analysis		RSID	Positive/Indicative
	HemaTrace	Positive/Indicative				
	<b>Conclusion:</b>	Positive/Indicative	<b>Conclusion:</b>	Not Tested	<b>Conclusion:</b>	Positive/Indicative
Z6CT77	KM	Positive/Indicative	AP	Negative	Saliva testing not performed in lab	
	<b>Conclusion:</b>	No Response	<b>Conclusion:</b>	No Response	<b>Conclusion:</b>	Not Tested

**Table 1 - Item 4**  
**Evidence - Four yellow plastic swabs containing Blood & Saliva Mixture**

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
ZAHM23	LMG HemaTrace	Positive/Indicative Positive/Indicative	AP PSA Micro	Negative Negative Negative		NT
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
ZFBUGP	HEMASTIX	Positive/Indicative				NO AVAILABLE TEST FOR Saliva
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
ZM8LR6	KM	Positive/Indicative	AP	Negative		Do not perform
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
ZPJAFB	Micro KM	Positive/Indicative Positive/Indicative	AP Micro	Negative Negative		RSID
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	
ZUCGUD			AP	Negative		
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
ZWYX9R	KM	Positive/Indicative	AP	Negative		RSID
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative	

**Response Summary for Table 1 - Item 4: Four yellow plastic swabs containing Blood & Saliva Mixture**

	Blood	Semen	Saliva
Positive/Indicative	213	1	124
Negative	0	157	0
Inconclusive	0	0	1
Not Tested (NT)	9	67	102
No Response	10	7	5
<b>Total</b>	<b>232</b>	<b>232</b>	<b>232</b>

# Screening Conclusions & Test(s) Performed

Indicate the overall conclusion from the results of the screening tests performed.

Table 1 - Item 5  
Evidence - Red Rag containing Blood

WebCode	BLOOD Tests Performed Results	SEMEN Tests Performed Results	SALIVA Tests Performed Results
24D4LA	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	ALS <i>Negative</i> AP <i>Negative</i> PSA <i>Negative</i> Micro <i>Negative</i>  <b>Conclusion:</b> Negative	The [Laboratory] does not conduct forensic serological tests for Saliva.   <b>Conclusion:</b> Not Tested
24XLKP	<b>Conclusion:</b> Not Tested	AP <i>Negative</i>  <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
<u>Other Tests Performed</u> ALS-blue light <i>Negative</i>			
27ZRVF	HEMASTIX <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	NO AVAILABLE TEST FOR Saliva  <b>Conclusion:</b> Not Tested
2HAFUE	KM <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i>  <b>Conclusion:</b> Negative	RSID <i>Negative</i>  <b>Conclusion:</b> Negative
<u>Other Tests Performed</u> ALS <i>Negative</i> IR (Infrared ALS) <i>Positive/Indicative</i>			
2PGRAY	LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	ALS <i>Negative</i> AP <i>Negative</i> Micro <i>Negative</i>  <b>Conclusion:</b> Negative	Amylase Diffusion <i>Negative</i>   <b>Conclusion:</b> Negative
2QN273	KM <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	Scenario did not support testing for Semen  <b>Conclusion:</b> Not Tested	Scenario did not support testing for Saliva  <b>Conclusion:</b> Not Tested
3EC4Q2	LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> PSA <i>Negative</i> Micro <i>Negative</i>  <b>Conclusion:</b> Negative	Amylase Radial Diffusion <i>Inconclusive</i>   <b>Conclusion:</b> Inconclusive
<u>Other Tests Performed</u> ALS <i>Negative</i>			
3HUDM7	TMB <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i>  <b>Conclusion:</b> Negative	RSID <i>Negative</i>  <b>Conclusion:</b> Negative
<u>Other Tests Performed</u> ALS <i>Negative</i> IR <i>Positive/Indicative</i>			



Table 1 - Item 5  
Evidence - Red Rag containing Blood

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
3KX989	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested
3KXA9U	O-tol <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Scenario does not suggest Semen present on this sample. <b>Conclusion:</b> Not Tested	Scenario does not suggest Saliva present on this sample. <b>Conclusion:</b> Not Tested
3QHEXN	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> No Response	see additional comments <b>Conclusion:</b> Not Tested	see additional comments <b>Conclusion:</b> Not Tested
3RYBLG	HEMASTIX <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
3U376K	HEMASTIX <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
447TM9	Micro <i>Positive/Indicative</i> KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Negative</i> AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
4ABGEP	SERATEC HemDirect <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Christmas Tree <i>Negative</i> Immunochromatography Test identification of Human Semen (RSID-Semen) <i>Negative</i> <b>Conclusion:</b> Negative	SERATEC Amylase Test <i>Negative</i> <b>Conclusion:</b> Negative
4B9RAR	HemDirect Hemoglobin Seratec <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Not tested <b>Conclusion:</b> Not Tested	Not tested <b>Conclusion:</b> Not Tested
4BN4RW	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Negative</i> AP <i>Negative</i> Micro <i>Negative</i> PSA <i>Negative</i> <b>Conclusion:</b> Negative	Amylase Diffusion <i>Negative</i> <b>Conclusion:</b> Negative
4E79LL	KM <i>Positive/Indicative</i> OBTI <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Not tested based on case scenario <b>Conclusion:</b> Not Tested	Generally not tested unless specified <b>Conclusion:</b> Not Tested
4JLRRR	ALS <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Inconclusive</i> AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
4K8M4G	Hemastix (HemaTrace) <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested

Table 1 - Item 5  
Evidence - Red Rag containing Blood

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
4L7NCT	PTMB <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested
4LA7EY	KM <i>Positive/Indicative</i> Modified Takayama <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	Phadebas Amylase <i>Negative</i> <b>Conclusion:</b> Negative
4QDG2H	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested
4UKGK4	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
4V7FET	SERATEC HemDirect <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Christmas tree <i>Negative</i> Immunochromatography test Rapid Stain Identification of Human Semen (RSID-Semen) <i>Negative</i> SERATEC-PSA <i>Negative</i> <b>Conclusion:</b> Negative	SERATEC Amylase <i>Negative</i> <b>Conclusion:</b> Negative
4XZ2BQ	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Negative</i> AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
62TKQU	PTMB <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	No indications of Saliva <b>Conclusion:</b> Not Tested
66TU YA	Hemastix <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	not indicated by ALS exam/ case scenerio <b>Conclusion:</b> Not Tested	not indicated by ALS exam/case scenerio <b>Conclusion:</b> Not Tested
	<u>Other Tests Performed</u> ALS CrimeLite 82S Blue <i>Negative</i> ALS CrimeLite 82S IR <i>Positive/Indicative</i>		
67PA82	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
68KVZR	PTMB <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	No indication of possible seminal fluid <b>Conclusion:</b> Not Tested	No indication of possible Saliva <b>Conclusion:</b> Not Tested
6B3X4Q	Kastle Meyer/3% Hydrogen Peroxide <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Per case scenario, no need to test for Semen on this item. <b>Conclusion:</b> Not Tested	Per case scenario, no need to test for Saliva on this item. <b>Conclusion:</b> Not Tested
6CWLLL	PTMB <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP, PSA, Micro, ALS <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested

Table 1 - Item 5  
Evidence - Red Rag containing Blood

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
6H3EEW	Phenolphthalein	Positive/Indicative	BCIP	Negative	Phadebas	Negative
			p30	Negative		
			Micro	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
6PKQLW	Hemastix	Positive/Indicative	Triaging scientist did not request rag for Semen detection		Phadebas Press Test	Negative
	HemaTrace	Positive/Indicative				
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Negative	
6VPH62	Hemastix	Positive/Indicative				
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
<u>Other Tests Performed</u>						
Alternate Light Source Negative						
776VCW	LMG	Positive/Indicative	AP	Negative	Saliva testing is not performed at the laboratory.	
	HemaTrace	Positive/Indicative	PSA	Negative		
			Micro	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
7CTBC2	TMB	Positive/Indicative	Used to injure suspect's face		RSID	Negative
	HemaTrace	Positive/Indicative				
	Luminol	Positive/Indicative				
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Negative	
<u>Other Tests Performed</u>						
Semen/Saliva- ALS blue Negative						
Blood- ALS IR Positive/Indicative						
7CWXP9	Phenolphthalein	Positive/Indicative	Acid Phosphatase	Negative	RSID	Negative
	Luminol	Positive/Indicative				
	IR	Positive/Indicative				
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
<u>Other Tests Performed</u>						
Alternate light source Positive/Indicative						
7U9PLJ	KM	Positive/Indicative	Not tested based on case scenario.		Generally not tested unless specified.	
	OBTI	Positive/Indicative				
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
7V63AW	KM	Positive/Indicative	AP	Negative	Laboratory does not test for Saliva	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
89PX43	KM	Positive/Indicative	Scenario did not warrant testing.		[Laboratory] does not routinely test for Saliva.	
	HemaTrace	Positive/Indicative				
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
8NM624	KM	Positive/Indicative	AP	Negative	RSID	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
<u>Other Tests Performed</u>						
Semen/Saliva - ALS Negative						

Table 1 - Item 5  
Evidence - Red Rag containing Blood

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
8QN8Q6	KM	Positive/Indicative	AP	Negative	RSID	Negative
		<b>Conclusion:</b> Positive/Indicative	Micro	Negative		<b>Conclusion:</b> Negative
8UNBTZ	LMG	Positive/Indicative	AP	Negative	Amylase Radial Diffusion	Inconclusive
	HemaTrace	Positive/Indicative				<b>Conclusion:</b> Inconclusive
92M92N	LMG	Positive/Indicative	AP	Negative		<b>Conclusion:</b> Not Tested
94QAGR	BLUESTAR (LUMINOL)	Positive/Indicative	AP	Negative	Phadebas	Negative
	HEXAGON OBTI TEST	Positive/Indicative				<b>Conclusion:</b> Negative
97KPG4	KM	Positive/Indicative	AP	Negative	RSID	Negative
	Micro	Positive/Indicative	Micro	Negative		<b>Conclusion:</b> Negative
		<b>Conclusion:</b> Positive/Indicative	ALS	Positive/Indicative		
987KRA	HEMASTIX	Positive/Indicative	BRENTAMINE	Negative	NO AVAILABLE TEST FOR Saliva	
	LUMINOL	Positive/Indicative				<b>Conclusion:</b> Not Tested
9J6AWQ	KM	Positive/Indicative	AP	Negative		<b>Conclusion:</b> Not Tested
	HemaTrace	Positive/Indicative				
9RWMWQ	LMG	Positive/Indicative	AP	Negative		<b>Conclusion:</b> Not Tested
9TC7FM	LMG	Positive/Indicative	AP	Negative		<b>Conclusion:</b> Not Tested
9TT6UK	LMG	Positive/Indicative	AP	Negative	Amylase Diffusion	Negative
		<b>Conclusion:</b> Positive/Indicative	Micro	Negative		<b>Conclusion:</b> Negative
A49C8Z	LMG	Positive/Indicative	ALS	Positive/Indicative	RSID	Negative
	HemeTrace	Positive/Indicative	AP	Negative		<b>Conclusion:</b> Negative
A4L4XW	KM	Positive/Indicative	scenario does not support testing		RSID	Negative
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Negative
AARLDN	LMG, HemDirect	Positive/Indicative	AP	Negative	Saliva is not tested	
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested

Table 1 - Item 5  
Evidence - Red Rag containing Blood

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
AB9QVM	O-tol HemaTrace	Positive/Indicative Positive/Indicative		Case scenario does not indicate the need for this testing.		Case scenario does not indicate the need for this testing.
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested
AMYUTL	KM OBTI	Positive/Indicative Positive/Indicative		Not tested based on case scenario.		Generally not tested, unless specified.
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested
AP8KHP	Phenolphthalein	Positive/Indicative	Microscopic Examination p30 BCIP	Negative Negative Negative		Phadebas Negative
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative
AQW9HW	KM	Positive/Indicative	ALS	Negative		
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested
AW84KK	KM	Positive/Indicative	AP	Negative		Scenario does not indicate oral contact
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested
AYDKY4			ALS-Blue AP	Negative Negative		
		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested
B2BMZP	ALS LMG	Positive/Indicative Positive/Indicative	ALS AP Micro PSA	Negative Negative Negative Negative		Amylase Diffusion Negative
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative
B3839F	KM	Positive/Indicative	ALS Micro p30	Positive/Indicative Negative Negative		Not validated procedure
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested
B4JQUZ	KM HemaTrace	Positive/Indicative Positive/Indicative	ALS AP	Negative Negative		Saliva testing not offered by our laboratory
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested
BBLR7N	LMG RSID	Positive/Indicative Positive/Indicative	AP RSID	Negative Negative		RSID Negative
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative
BCFFPJ	Visual examination KM	Positive/Indicative Positive/Indicative				
		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested

Table 1 - Item 5  
Evidence - Red Rag containing Blood

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
BFWV63	ALS KM	Positive/Indicative Positive/Indicative	ALS AP Micro	Negative Negative Negative	RSID	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
BHL7WV	KM	Positive/Indicative	ALS	Negative		
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
BKMANH	LMG	Positive/Indicative	AP Micro ALS	Negative Negative Negative	Amylase Diffusion	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
BQBWEG	HemDirect Seratec	Positive/Indicative	Micro PSA	Negative Negative	Amylase Seratec	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
BT7FKP	LMG HemaTrace	Positive/Indicative Positive/Indicative	ALS AP PSA	Negative Negative Negative	Amylase Diffusion	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
BUB9BG	HemDirect Hemoglobin (SERATEC)	Positive/Indicative	Christmas Tree Stain Slide (Micro) PSA Semiquant (SERATEC)	Negative Negative	Amylase Test (SERATEC)	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
BVQAGP	LMG ([Laboratory]: Leuco-Malachite)	Positive/Indicative	-Item used to wipe victim ring (repeatedly) after causing injury to suspect with ring -No Fluorescence observed on swab using ALS		[Laboratory] does not employ tests for Saliva	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
C8J7Z3	Hemastix Crime Lite IR	Positive/Indicative Positive/Indicative	p30	Negative	neg ALS	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
	<u>Other Tests Performed</u>					
	Semen/Saliva - ALS Negative					
CBXYV3	O-tol HemaTrace	Positive/Indicative Positive/Indicative	not tested or inconclusive		not tested or inconclusive	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
CFCELU	Phenolphthalein Takayama	Positive/Indicative Positive/Indicative	Acid Phosphatase	Negative	Phadebas	Negative
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
CNJDUV	KM HEXAGON OBTI	Positive/Indicative	case scenario		case scenario	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	

Table 1 - Item 5  
Evidence - Red Rag containing Blood

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
CUTGYB	KM <i>Positive/Indicative</i> <b>Conclusion:</b> No Response	Micro, ALS, p30 <i>Negative</i> <b>Conclusion:</b> No Response	<b>Conclusion:</b> Not Tested
D7426P	Visual <i>Positive/Indicative</i> LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Positive/Indicative</i> AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID-Saliva <i>Negative</i> ALS <i>Positive/Indicative</i> <b>Conclusion:</b> Negative
D94JU6	HEMASTIX <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
DF7NRF	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	N/A per scenario <b>Conclusion:</b> Not Tested	N/A per scenario <b>Conclusion:</b> Not Tested
DKXZJ7	Hemastix Test (TMB) <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	No evidential value <b>Conclusion:</b> Not Tested	No test for Saliva in ER. No evidential value <b>Conclusion:</b> Not Tested
	<u>Other Tests Performed</u> Possible Hair <i>Negative</i>		
DXNMY	<b>Conclusion:</b> Not Tested	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
E3A4KN	LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> Ouchterlony <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Micro <i>Negative</i> PSA <i>Negative</i> <b>Conclusion:</b> Negative	Fluid not searched for, per senario info <b>Conclusion:</b> Not Tested
EC6X2V	LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> Visual Examination <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> ALS <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> ALS <i>Negative</i> <b>Conclusion:</b> Negative
EGZPDX	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Micro <i>Negative</i> ALS <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
EJN4ZM	Phenolphthalein <i>Positive/Indicative</i> Modified Takyama <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Acid Phosphatase <i>Negative</i> <b>Conclusion:</b> Negative	Phadebas <i>Negative</i> <b>Conclusion:</b> Negative
ELP4ZK	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
EM3NZG	Seratec HEM LN 200076 D.D: 22-09 <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID LN 09120S1 D. D. 22-09 <i>Negative</i> Christmas Tree <i>Negative</i> <b>Conclusion:</b> Negative	Seratec AMY LN 200078 D.D: 22-09 <i>Negative</i> <b>Conclusion:</b> Negative

Table 1 - Item 5  
Evidence - Red Rag containing Blood

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
EPBXTE	Human Blood <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	CHRISTMAS TREE <i>Negative</i> SemenOGELINA <i>Negative</i> <b>Conclusion:</b> Negative	Human Saliva <i>Negative</i> <b>Conclusion:</b> Negative
ERGE8W	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested
EYDBVZ	Phenolphthalein <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> Hemastix <i>Positive/Indicative</i> Luminol <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
<u>Other Tests Performed</u> Semen/Saliva - ALS <i>Positive/Indicative</i> Blood - IR Light <i>Positive/Indicative</i>			
FATH8U	Visual <i>Positive/Indicative</i> LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Negative</i> AP <i>Negative</i> <b>Conclusion:</b> Negative	ALS <i>Negative</i> RSID <i>Negative</i> <b>Conclusion:</b> Negative
FC3HEM	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	Blue paper <i>Negative</i> <b>Conclusion:</b> Negative
FHJBD	Kastle-Meyer <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Acid phosphatase <i>Negative</i> <b>Conclusion:</b> Negative	Phadebas tube test <i>Negative</i> <b>Conclusion:</b> Negative
FKR6D6	TMB (Hstix) <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Not tested due to nature of exhibit according to case summary <b>Conclusion:</b> Not Tested	no presumptive test for Saliva; Not tested due to nature of exhibit <b>Conclusion:</b> Not Tested
<u>Other Tests Performed</u> Possible hair <i>Negative</i>			
FP8NMZ	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	Phadebas <i>Negative</i> <b>Conclusion:</b> Negative
FQ2ELM	HEMASTIX <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> No Response
FQHTUW	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
<u>Other Tests Performed</u> Crime-Lite ALS blue <i>Negative</i> Crime-Lite ALS IR <i>Positive/Indicative</i>			



Table 1 - Item 5  
Evidence - Red Rag containing Blood

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
FXXDW9	KM OBTI	Positive/Indicative Positive/Indicative	Not tested based on case scenario.		Generally not tested unless specified	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
G2QWBC	Visual, KM	Positive/Indicative	Not tested		Not tested	
	<b>Conclusion:</b> No Response		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
G43C6D	Visual and KM	Positive/Indicative	Case circumstances don't suggest should be present.		Case circumstances don't suggest should be present.	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
G4LB8G	LMG	Positive/Indicative	AP		Not tested	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
G6R26K	LMG	Positive/Indicative	ALS AP Micro PSA		Amylase Diffusion	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
GD9E9P	KM	Positive/Indicative	ALS		Not tested	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
GDUVL8	KM OBTI	Positive/Indicative Positive/Indicative	Not tested based on case scenario - red rag used to wipe the victim's ring.		Generally not tested unless specified.	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
GL4D2J	KM HemaTrace	Positive/Indicative Positive/Indicative	AP		Not tested	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Not Tested	
GP7BEX	TMB HemaTrace Luminol ALS	Positive/Indicative Positive/Indicative Positive/Indicative Inconclusive	AP		Phadebas	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
GUZ6CY	KM	Positive/Indicative	based on case history, not tested for presence of Semen		Phadebas press test	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Positive/Indicative	
HBXUYF	PTMB RSID	Positive/Indicative Positive/Indicative	Not online with seminal fluid screening		Not online with Saliva screening	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
HKMHYN	KM Modified Takayama	Positive/Indicative Positive/Indicative	AP		Phadebas	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Negative	
HLFHP9	HEMASTIX	Positive/Indicative	Not tested		NO AVAILABLE TEST FOR Saliva	
	<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	

Table 1 - Item 5  
Evidence - Red Rag containing Blood

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
HQB89Z	HEMASTIX <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
HYKPTJ	KM <i>Positive/Indicative</i> Modified Takayama <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	Phadebas Amylase <i>Negative</i> <b>Conclusion:</b> Negative
J2T2AL	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Scenario did not provide any details that would lead me to test for Semen <b>Conclusion:</b> Not Tested	Scenario did not provide any details that would lead me to test for Saliva <b>Conclusion:</b> Not Tested
J8YXUL	KM <i>Positive/Indicative</i> Heme-direct <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> ALS <i>Negative</i> <b>Conclusion:</b> Negative	No Saliva testing at Lab <b>Conclusion:</b> Not Tested
JGGLF8	HEMASTIX <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
K4Q6CR	KM, Hemastix, Luminol <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID Saliva <i>Negative</i> <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> Body Fluid - Test Performed: ALS <i>Negative</i> Body Fluid - Test Performed: IR <i>Positive/Indicative</i>		
K8PF9R	Hemastix <i>Positive/Indicative</i> Luminol <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> Semen/Saliva - ALS <i>Positive/Indicative</i> Blood - Infrared Camera <i>Positive/Indicative</i>		
KBAB8D	TMB <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Negative</i> AP <i>Negative</i> <b>Conclusion:</b> Negative	*Amylase mapping is not in our laboratory TPM <b>Conclusion:</b> Not Tested
KED2FE	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested
KF2JBK	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Negative</i> AP <i>Negative</i> <b>Conclusion:</b> Inconclusive	<b>Conclusion:</b> Not Tested
KMLH4D	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	Phadebas <i>Negative</i> <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> HEMDIRECT <i>Positive/Indicative</i>		

Table 1 - Item 5  
Evidence - Red Rag containing Blood

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
KWN32Z	Hstix (KM) <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	the owner used to wipe the ring that has a Blood and was after the incident occurred and the rag was not used during the rape incident  <b>Conclusion:</b> Not Tested	As per SOP no prelim testing for Saliva to be performed  <b>Conclusion:</b> Not Tested
KYVDX4	KM <i>Positive/Indicative</i> OBTI <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Not tested based on case scenario  <b>Conclusion:</b> Not Tested	Generally not tested unless specified  <b>Conclusion:</b> Not Tested
L47NTJ	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
L7D2GC	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
L9YRHG	KM TEST <i>Positive/Indicative</i> RSID-Blood <i>Positive/Indicative</i> <b>Conclusion:</b> No Response	ALS <i>Negative</i> AP TEST <i>Negative</i> <b>Conclusion:</b> No Response	RSID-Saliva <i>Negative</i>  <b>Conclusion:</b> No Response
LA84XW	HEMASTIX <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
LBC97F	Visual stain <i>Positive/Indicative</i> KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	Phadebas Blue Paper <i>Negative</i> <b>Conclusion:</b> Negative
LNPRB2	KM <i>Positive/Indicative</i> OBTI <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Not tested based on case scenario  <b>Conclusion:</b> Not Tested	Generally not tested unless specified  <b>Conclusion:</b> Not Tested
M2XQ6T	TMB <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> Body Fluid - ALS <i>Negative</i>		
M6CLLQ	TMB <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested
MGNXUE	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Positive/Indicative</i> AP <i>Negative</i> <b>Conclusion:</b> Negative	Amylase Diffusion <i>Negative</i> <b>Conclusion:</b> Negative
MH42MK	KM <i>Positive/Indicative</i> <b>Conclusion:</b> No Response	AP <i>Negative</i> <b>Conclusion:</b> No Response	<b>Conclusion:</b> Not Tested

Table 1 - Item 5  
Evidence - Red Rag containing Blood

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
MHGTDG	KM - Hemophan (paper test for Blood erythrocytes, haemoglobin) by Erba Lachema - non-specific test for Blood Positive/Indicative FOB - cassette test for determination of faecal occult Blood by NADAL - specific test for Human Blood Positive/Indicative <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested
MLM86G	KM Positive/Indicative HemaTrace Positive/Indicative <b>Conclusion:</b> Positive/Indicative	AP Negative <b>Conclusion:</b> Negative	RSID Negative <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> ALS Negative		
MP2R6B	Seratec HemDirect Positive/Indicative <b>Conclusion:</b> Positive/Indicative	Micro Negative Seratec PSA Negative <b>Conclusion:</b> Negative	Seratec Amylase Test Negative <b>Conclusion:</b> Negative
MUB6RF	KM Positive/Indicative <b>Conclusion:</b> Positive/Indicative	ALS Negative AP Negative <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
MVA9KQ	Hemastix Positive/Indicative KM Positive/Indicative <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested
MW4W4L	KM Positive/Indicative Luminol Positive/Indicative IR Light Positive/Indicative <b>Conclusion:</b> Positive/Indicative	AP Negative <b>Conclusion:</b> Negative	RSID Negative <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> Semen/Saliva - ALS (see comments) Positive/Indicative		
MZLBBT	TMB Positive/Indicative ALS Positive/Indicative HemaTrace Positive/Indicative <b>Conclusion:</b> Positive/Indicative	ALS Negative AP Negative <b>Conclusion:</b> Negative	ALS Negative RSID Negative <b>Conclusion:</b> Negative
N4UXGG	KM Positive/Indicative <b>Conclusion:</b> Positive/Indicative	ALS Negative <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
NPXL8D	KM Positive/Indicative <b>Conclusion:</b> Positive/Indicative	No test needed per case scenario <b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested
NXRWAV	TMB - Hstix Positive/Indicative <b>Conclusion:</b> Positive/Indicative	No presumptive test required according to scenario <b>Conclusion:</b> Not Tested	No presumptive test f <b>Conclusion:</b> Not Tested
	<u>Other Tests Performed</u> No hair was found Negative		

Table 1 - Item 5  
Evidence - Red Rag containing Blood

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
P3FYU7	SERATEC-SANGRE <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	MicroSCOPIO <i>Negative</i> RSID-Semen <i>Negative</i> <b>Conclusion:</b> Negative	SERATEC-Saliva <i>Negative</i> <b>Conclusion:</b> Negative
P69KR4	LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Negative</i> AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	Amylase Diffusion <i>Negative</i> <b>Conclusion:</b> Negative
P8RWB7	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
PAX8GH	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> No Response	<b>Conclusion:</b> No Response	<b>Conclusion:</b> No Response
PEULCK	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Not tested based on scenario of incident <b>Conclusion:</b> Not Tested	The [Laboratory] does not perform tests for Saliva <b>Conclusion:</b> Not Tested
PF4ZDY	KM <i>Positive/Indicative</i> OBTI <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Not tested based on case scenario <b>Conclusion:</b> Not Tested	Generally not tested unless specified <b>Conclusion:</b> Not Tested
PN2NBQ	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	RSID Saliva <i>Negative</i> <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> ALS (Blue) <i>Negative</i> ALS (IR) <i>Positive/Indicative</i>		
PU4R3A	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
Q62YBE	Leucomalachite Green <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	No tests available. <b>Conclusion:</b> Not Tested	No tests available. <b>Conclusion:</b> Not Tested
	<u>Other Tests Performed</u> Forensic light source <i>Negative</i>		
QC3ALD	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
QDWWJB	KM <i>Positive/Indicative</i> Modified Takayama <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	Phadebas <i>Negative</i> <b>Conclusion:</b> Negative
QGHK4N	<b>Conclusion:</b> Not Tested	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested

Table 1 - Item 5  
Evidence - Red Rag containing Blood

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
QP966F	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
QQ3V99	ALS <i>Negative</i> KM <i>Positive/Indicative</i> RSID <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> ALS <i>Negative</i> RSID <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	ALS <i>Negative</i> RSID <i>Negative</i> <b>Conclusion:</b> Negative
QRFNA	KM <i>Positive/Indicative</i> <b>Conclusion:</b> No Response	AP OVERLAY <i>Negative</i> <b>Conclusion:</b> No Response	<b>Conclusion:</b> Not Tested
	<u>Other Tests Performed</u> FLS <i>Negative</i>		
QYE6K9	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
R3UUJC	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> PSA <i>Negative</i> Micro-Sperm <i>Negative</i> <b>Conclusion:</b> Negative	Saliva RSID <i>Negative</i> <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> ALS @ 450 nm		
R6ZHWF	Phenolphthalein <i>Positive/Indicative</i> Luminol <i>Positive/Indicative</i> IR <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Acid Phosphatase <i>Negative</i> <b>Conclusion:</b> Negative	RSID-Saliva <i>Negative</i> <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> Semen/Saliva - ALS <i>Negative</i>		
RJ28Y9	Hemastix <i>Positive/Indicative</i> RSID Blood <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS (Polilight) <i>Negative</i> AP <i>Negative</i> <b>Conclusion:</b> Negative	ALS (Polilight) <i>Negative</i> RSID Saliva <i>Negative</i> <b>Conclusion:</b> Negative
RJGF2G	KM <i>Positive/Indicative</i> TMB <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> PSA <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
RKCZMV	KM <i>Positive/Indicative</i> OBTI <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Not tested based on case scenario <b>Conclusion:</b> Not Tested	Generally not tested unless specified <b>Conclusion:</b> Not Tested
RQ44Y8	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested

Table 1 - Item 5  
Evidence - Red Rag containing Blood

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
RRATXA	HEMASTIX <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	BRENTAMINE <i>Negative</i> <b>Conclusion:</b> Negative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
RT728F	Hemastix <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> Luminol <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> Blood - ALS IR <i>Positive/Indicative</i> Semen/Saliva - ALS <i>Negative</i>		
RT9VQL	see comments section <b>Conclusion:</b> Not Tested	AP <i>Negative</i> ALS-blue <i>Negative</i> <b>Conclusion:</b> Negative	see comments section <b>Conclusion:</b> Not Tested
RX2XQE	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
RXG4AB	Hemochromogen <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested
	<u>Other Tests Performed</u> No hairs observed <i>Negative</i>		
RYVJNC	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> ALS <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
T6UMQF	TMB <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> Luminol <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> Possible Semen, Saliva, etc - ALS-Blue <i>Negative</i> Possible Blood - ALS - IR <i>Positive/Indicative</i>		
TDB779	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Negative</i> AP <i>Negative</i> <b>Conclusion:</b> Negative	Amylase Diffusion <i>Negative</i> <b>Conclusion:</b> Negative
TJXU6K	<b>Conclusion:</b> Not Tested	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
TK3Q4U	HEMASTIX <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
TLZRC7	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Negative</i> AP <i>Negative</i> <b>Conclusion:</b> Negative	Amylase Diffusion <i>Negative</i> <b>Conclusion:</b> Negative

Table 1 - Item 5  
Evidence - Red Rag containing Blood

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
TPKL98	HEMOPHAN FOB <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative	RSID Semen PSA <b>Conclusion:</b> Negative	Negative Negative	RSID Saliva <b>Conclusion:</b> Negative	Negative
TPY8KU	KM HemaTrace <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
U2DKJA	Visual KM HemaTrace <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative Positive/Indicative	Per scenario- no indication of penile contact with the ring or the rag <b>Conclusion:</b> Not Tested		Per scenario- no indication of oral (Saliva) contact with the ring or the rag <b>Conclusion:</b> Not Tested	
U4ZY9K	<b>Conclusion:</b> Not Tested		AP Micro <b>Conclusion:</b> Negative	Negative Negative	<b>Conclusion:</b> Not Tested	
UA43XH	<b>Conclusion:</b> Not Tested		AP <b>Conclusion:</b> Negative	Negative	<b>Conclusion:</b> Not Tested	
UBHEU3	Visual O-tol HemaTrace <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative Positive/Indicative	ALS AP <b>Conclusion:</b> Negative	Negative Negative	<b>Conclusion:</b> Not Tested	
UBYTX6	O-tol HEX OBTI <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative	ALS <b>Conclusion:</b> Negative	Negative	<b>Conclusion:</b> Not Tested	
UD69B4	KM <b>Conclusion:</b> Positive/Indicative	Positive/Indicative	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
UJAUJ7	ALS O-tol OBTI <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative Positive/Indicative	ALS <b>Conclusion:</b> Negative	Negative	Our lab does not test for Saliva. <b>Conclusion:</b> Not Tested	
UMQJHA	O-tol HemaTrace <b>Conclusion:</b> Positive/Indicative	Positive/Indicative	ALS AP PSA Micro <b>Conclusion:</b> Negative	Negative Negative Negative Negative	<b>Conclusion:</b> Not Tested	
UNPFCD	Visual KM HemaTrace <b>Conclusion:</b> Positive/Indicative	Positive/Indicative Positive/Indicative Positive/Indicative	ALS ABAcad p30 <b>Conclusion:</b> Negative	Inconclusive Negative	<b>Conclusion:</b> Not Tested	



Table 1 - Item 5  
Evidence - Red Rag containing Blood

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
UTYHE9	O-tol <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested
VCNGT7	O-tol <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	NT: case scenario did not indicate a need for this test <b>Conclusion:</b> Not Tested	NT: case scenario did not indicate a need for this test <b>Conclusion:</b> Not Tested
VGJ7F6	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Positive/Indicative</i> PSA <i>Negative</i> Micro <i>Negative</i> ALS <i>Negative</i> <b>Conclusion:</b> Negative	Amylase Diffusion <i>Negative</i> <b>Conclusion:</b> Negative
VXTUT6	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Negative</i> AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	Amylase Diffusion <i>Negative</i> <b>Conclusion:</b> Negative
VY377Z	SERATEC- HemDirect hemoglobin Assay <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Christmas Tree Stain-Micro <i>Negative</i> RSID Semen <i>Negative</i> <b>Conclusion:</b> Negative	SERATEC-Amylase Test <i>Negative</i> <b>Conclusion:</b> Negative
W6MFGJ	Hemochromogen <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested
	<u>Other Tests Performed</u> No hairs observed <i>Negative</i>		
W7EDQB	ALS (infrared) <i>Positive/Indicative</i> KM <i>Positive/Indicative</i> ABACard HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Inconclusive</i> ABACard p30 <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
W7H6F7	HEMASTIX <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
W7HZ4H	Pheno <i>Positive/Indicative</i> luminol <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID Saliva <i>Negative</i> <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> Semen/Saliva - ALS <i>Negative</i> Blood - IR <i>Positive/Indicative</i>		
WC7HLZ	KM <i>Positive/Indicative</i> <b>Conclusion:</b> No Response	Not applicable to scenario. <b>Conclusion:</b> Not Tested	Phadebas Amylase <i>Negative</i> <b>Conclusion:</b> No Response

Table 1 - Item 5  
Evidence - Red Rag containing Blood

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
WET9M6	O-tol <i>Positive/Indicative</i> Seratec HemDirect <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Seratec PSA <i>Negative</i> <b>Conclusion:</b> Negative	Amylase Diffusion <i>Negative</i> <b>Conclusion:</b> Negative
WFKMR9	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
WGZMBX	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
WHCE4E	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested
WHT3B	LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> PSA <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	Amylase Radial Diffusion <i>Inconclusive</i> <b>Conclusion:</b> Inconclusive
	<u>Other Tests Performed</u> ALS <i>Negative</i>		
WKDHV2	LMG <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
WREWG3	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
WUNL77	Visual <i>Positive/Indicative</i> LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Positive/Indicative</i> AP <i>Negative</i> <b>Conclusion:</b> Negative	ALS <i>Positive/Indicative</i> RSID <i>Negative</i> <b>Conclusion:</b> Negative
WUZP9W	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> No Response	<b>Conclusion:</b> No Response
WWAL2G	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> ALS <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
WYFXTQ	HEMASTIX <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
X3B7GW	Hem Direct Immunocromatografic SERATEC <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Christmas tree coloration <i>Negative</i> Rapid Stain Identification Semen RSID <i>Negative</i> <b>Conclusion:</b> Negative	Forensic test Kit SERATEC Amylase test Immunocromatografic <i>Negative</i> <b>Conclusion:</b> Negative

Table 1 - Item 5  
Evidence - Red Rag containing Blood

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
X6KZP4	Hemastix <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Triage scientist did not request testing for Semen <b>Conclusion:</b> Not Tested	ALS <i>Negative</i> Phadebas <i>Negative</i> <b>Conclusion:</b> Negative
X9ZNU9	Hemochromogen <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
	<u>Other Tests Performed</u> One hair fragment recovered <i>Negative</i>		
XENFB3	Visual <i>Positive/Indicative</i> KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> No Response	Not tested for Semen as item was used to clean victims ring, which was alleged to have contacted the suspects face. <b>Conclusion:</b> Not Tested	Not tested for Saliva due to same reason as above. <b>Conclusion:</b> Not Tested
XF2TU6	Visual <i>Positive/Indicative</i> LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Inconclusive</i> AP <i>Negative</i> <b>Conclusion:</b> Negative	ALS <i>Inconclusive</i> RSID <i>Negative</i> <b>Conclusion:</b> Negative
XPMX36	KM <i>Positive/Indicative</i> Modified Takayama <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	Phadebas <i>Negative</i> <b>Conclusion:</b> Negative
XQK9X8	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Scenario gave no indication to warrant this testing <b>Conclusion:</b> Not Tested	Scenario gave no indication to warrant this testing <b>Conclusion:</b> Not Tested
XW6FC7	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	No indication of mixed stain in scenario, ALS neg, <b>Conclusion:</b> Not Tested	Amylase radial Diffusion <i>Negative</i> <b>Conclusion:</b> Negative
XZ8C2Z	KM <i>Positive/Indicative</i> Hemtrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested
Y44E48	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Negative</i> AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
Y6GWGK	HEMASTIX <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	BRENTAMINE <i>Negative</i> <b>Conclusion:</b> Negative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
Y8JR6U	HemDirect Hemoglobin (SERATEC) <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Christmas Tree Coloring <i>Negative</i> Immunocromatographic Test (Semen-RSID) <i>Negative</i> <b>Conclusion:</b> Negative	Amylase Test (SERATEC) <i>Negative</i> <b>Conclusion:</b> Negative

Table 1 - Item 5  
Evidence - Red Rag containing Blood

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
YKN8N6	TMB <i>Positive/Indicative</i> FOB <i>Positive/Indicative</i> Seratec PMB Test peripheral <i>Positive/Indicative</i> Seratec PMB Test menstrual <i>Negative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> RSID Saliva <i>Negative</i> <b>Conclusion:</b> Negative	RSID Saliva <i>Negative</i> Seratec alpha Amylase test <i>Negative</i> <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> ALS <i>Negative</i>		
YQDKUY	KM <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Not tested based on scenario. <b>Conclusion:</b> Not Tested	SALIgAE <i>Negative</i> Micro <i>Negative</i> ALS <i>Negative</i> <b>Conclusion:</b> Negative
YXEV6X	O-tol <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Scenario didn't support this analysis <b>Conclusion:</b> Not Tested	Scenario didn't support this analysis <b>Conclusion:</b> Not Tested
Z6CT77	KM <i>Positive/Indicative</i> ALS <i>Negative</i> <b>Conclusion:</b> No Response	ALS <i>Negative</i> AP <i>Negative</i> <b>Conclusion:</b> No Response	Saliva testing not performed in lab <b>Conclusion:</b> Not Tested
ZAHM23	LMG <i>Positive/Indicative</i> HemaTrace <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	PSA <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	NT <b>Conclusion:</b> Not Tested
ZFBUGP	HEMASTIX <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
ZM8LR6	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	Do not perform <b>Conclusion:</b> Not Tested
ZPJAFB	Micro <i>Positive/Indicative</i> KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Negative</i> AP <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
ZUCGUD	<b>Conclusion:</b> Not Tested	AP <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested
ZWYX9R	KM <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	AP <i>Negative</i> <b>Conclusion:</b> Negative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> Semen/Saliva - ALS <i>Inconclusive</i>		

**Response Summary for Table 1 -  
Item 5: Red Rag containing Blood**

	<u>Blood</u>	<u>Semen</u>	<u>Saliva</u>
Positive/Indicative	210	0	1
Negative	0	147	88
Inconclusive	0	1	3
Not Tested (NT)	12	77	135
No Response	10	7	5
Total	232	232	232

# Screening Conclusions & Test(s) Performed

Indicate the overall conclusion from the results of the screening tests performed.

Table 1 - Item 6  
Evidence - Sanitary Pad containing Semen

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
24D4LA	KM <i>Negative</i>  <b>Conclusion:</b> Negative	ALS <i>Positive/Indicative</i> AP <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	The [Laboratory] does not conduct forensic serological tests for Saliva.  <b>Conclusion:</b> Not Tested
24XLKP	<b>Conclusion:</b> Not Tested  <u>Other Tests Performed</u> ALS-blue light <i>Positive/Indicative</i>	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
27ZRVF	<b>Conclusion:</b> Not Tested	BRENTAMINE <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	NO AVAILABLE TEST FOR Saliva  <b>Conclusion:</b> Not Tested
2HAFUE	KM <i>Negative</i>  <b>Conclusion:</b> Negative  <u>Other Tests Performed</u> ALS <i>Positive/Indicative</i>	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i>  <b>Conclusion:</b> Negative
2PGRAY	Visual exam - no red-brown staining <i>Negative</i>  <b>Conclusion:</b> Negative	ALS <i>Positive/Indicative</i> AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> p30 <i>Positive/Indicative</i> AP mapping <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	Amylase Diffusion <i>Negative</i> Amylase mapping <i>Negative</i>  <b>Conclusion:</b> Negative
2QN273	Scenario did not support testing for Blood  <b>Conclusion:</b> Not Tested	ALS <i>Positive/Indicative</i> AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	Scenario did not support testing for Saliva  <b>Conclusion:</b> Not Tested
3EC4Q2	LMG <i>Negative</i> HemaTrace <i>Positive/Indicative</i>  <b>Conclusion:</b> Negative  <u>Other Tests Performed</u> ALS <i>Positive/Indicative</i>	AP <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	Amylase Radial Diffusion <i>Negative</i>  <b>Conclusion:</b> Negative
3HUDM7	Not tested due to the absence of visible red brown staining  <b>Conclusion:</b> Not Tested  <u>Other Tests Performed</u> ALS <i>Positive/Indicative</i>	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i>  <b>Conclusion:</b> Negative

Table 1 - Item 6  
Evidence - Sanitary Pad containing Semen

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
3KX989	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested
3KXA9U	Scenario does not suggest Blood present on this sample. Also no red brown stains visible. <b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> ALS <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Scenario does not suggest Saliva present on this sample. <b>Conclusion:</b> Not Tested
3QHEXN	LMG <i>Negative</i> <b>Conclusion:</b> No Response	see additional comments <b>Conclusion:</b> Not Tested	see additional comments <b>Conclusion:</b> Not Tested
3RYBLG	<b>Conclusion:</b> Not Tested	BRENTAMINE <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
3U376K	<b>Conclusion:</b> Not Tested	BRENTAMINE <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
447TM9	KM <i>Negative</i> <b>Conclusion:</b> Negative	ALS <i>Positive/Indicative</i> AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
4ABGEP	SERATEC HemDirect <i>Negative</i> <b>Conclusion:</b> Negative	Christmas Tree <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	SERATEC Amylase Test <i>Negative</i> <b>Conclusion:</b> Negative
4B9RAR	Not tested. <b>Conclusion:</b> Not Tested	Christmas Tree Stain (Micro) <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Not tested. <b>Conclusion:</b> Not Tested
4BN4RW	LMG <i>Negative</i> <b>Conclusion:</b> Negative	ALS <i>Positive/Indicative</i> AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Amylase Diffusion <i>Negative</i> <b>Conclusion:</b> Negative
4E79LL	KM <i>Negative</i> <b>Conclusion:</b> Negative	RSID-Semen <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> AP <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Generally not tested unless specified <b>Conclusion:</b> Not Tested
4JLRRR	Micro <i>Negative</i> ALS <i>Negative</i> KM <i>Negative</i> <b>Conclusion:</b> Negative	ALS <i>Positive/Indicative</i> AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
4K8M4G	<b>Conclusion:</b> Not Tested	Brentamine (AP) <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
4L7NCT	PTMB <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested

Table 1 - Item 6  
Evidence - Sanitary Pad containing Semen

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
4LA7EY	KM <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	Phadebas Amylase <i>Negative</i>  <b>Conclusion:</b> Negative
4QDG2H	KM <i>Negative</i>  <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested
4UKGK4	No red/brown stain noted  <b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
4V7FET	SERATEC HemDirect <i>Negative</i>  <b>Conclusion:</b> Negative	Christmas tree <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	Amylase Test Seratec <i>Negative</i>  <b>Conclusion:</b> Negative
4XZ2BQ	  <b>Conclusion:</b> Not Tested	ALS <i>Positive/Indicative</i> AP <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	  <b>Conclusion:</b> Not Tested
62TKQU	No visible red-brown staining on item  <b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> p30 <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	No indications of Saliva  <b>Conclusion:</b> Not Tested
	<u>Other Tests Performed</u> Urine - Urित्रace <i>Negative</i>		
66TUYA	no RBS observed  <b>Conclusion:</b> Not Tested	AP, Micro, p30 <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	RSID-Saliva <i>Negative</i>  <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> ALS CrimeLite 82S Blue <i>Positive/Indicative</i>		
67PA82	  <b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> MicroSCOPE <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	  <b>Conclusion:</b> Not Tested
68KVZR	No color indicating Blood  <b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	No indication of possible Saliva  <b>Conclusion:</b> Not Tested
6B3X4Q	No staining consistent with possible Blood on item.  <b>Conclusion:</b> Not Tested	Acid Phosphatase <i>Positive/Indicative</i> Micro (In-house Prepped) <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	Per case scenario, no need to test for Saliva on this item.  <b>Conclusion:</b> Not Tested
6CWLLL	no red staining present  <b>Conclusion:</b> Not Tested	AP, PSA, Micro, ALS <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	  <b>Conclusion:</b> Not Tested



Table 1 - Item 6  
Evidence - Sanitary Pad containing Semen

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
6H3EEW	Visual exam	Negative	BCIP	Positive/Indicative	Phadebas	Negative
			p30	Positive/Indicative		
			Micro	Positive/Indicative		
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative	
6PKQLW	Hemastix	Negative	AP	Positive/Indicative	Triaging scientist did not request sanitary pad for Saliva	
			Micro	Positive/Indicative		
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested	
6VPH62			AP	Positive/Indicative		
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested	
	<u>Other Tests Performed</u>					
	Alternate Light Source Positive/Indicative					
776VCW			AP	Positive/Indicative	Saliva testing is not performed at the laboratory.	
			PSA	Positive/Indicative		
			Micro	Positive/Indicative		
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested	
7CTBC2	No red/brown staining observed		AP	Positive/Indicative	RSID	Negative
			Micro	Positive/Indicative		
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative	
	<u>Other Tests Performed</u>					
	Semen/Saliva- ALS blue Positive/Indicative					
7CWXP9	Phenolphthalein	Negative	Acid Phosphatase	Positive/Indicative	RSID	Negative
			Micro	Positive/Indicative		
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative	
	<u>Other Tests Performed</u>					
	Alternate light source Positive/Indicative					
7U9PLJ	KM	Negative	AP	Positive/Indicative	Generally not tested unless specified.	
			RSID-Semen	Positive/Indicative		
			PSA	Positive/Indicative		
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested	
7V63AW	KM	Negative	AP	Positive/Indicative	Laboratory does not test for Saliva	
			Micro	Positive/Indicative		
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested	
89PX43	No RBS observed.		ALS	Positive/Indicative	[Laboratory] does not routinely test for Saliva.	
			AP	Positive/Indicative		
			PSA	Positive/Indicative		
			Micro	Positive/Indicative		
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested	

Table 1 - Item 6  
Evidence - Sanitary Pad containing Semen

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
8NM624	KM <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i>  <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> Semen/Saliva - ALS <i>Positive/Indicative</i>		
8QN8Q6	KM <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i>  <b>Conclusion:</b> Negative
8UNBTZ	LMG <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Amylase Radial Diffusion <i>Inconclusive</i>  <b>Conclusion:</b> Inconclusive
92M92N	LMG <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
94QAGR	BLUESTAR (LUMINOL) <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> SERATEC PSA SEMI QUANT <i>Positive/Indicative</i> RSID Semen (UNIVERSAL BUFFER) <i>Positive/Indicative</i> RSID Semen (DUAL BUFFER) <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Phadebas <i>Negative</i>  <b>Conclusion:</b> Negative
97KPG4	KM <i>Negative</i> Micro <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> ALS <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i>  <b>Conclusion:</b> Negative
987KRA	hemastix <i>Negative</i> luminol <i>Negative</i>  <b>Conclusion:</b> Negative	BRENTAMINE <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	NO AVAILABLE TEST FOR Saliva  <b>Conclusion:</b> Not Tested
9J6AWQ	KM <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
9RWMWQ	LMG <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested

Table 1 - Item 6  
Evidence - Sanitary Pad containing Semen

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
9TC7FM	LMG	Negative	AP	Positive/Indicative		
			Micro	Positive/Indicative		
			PSA	Positive/Indicative		
		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested
9TT6UK	Visual	Negative	AP	Positive/Indicative	Amylase Diffusion	Negative
			Micro	Positive/Indicative		
			PSA	Positive/Indicative		
		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative
A49C8Z	Visual	Negative	ALS	Positive/Indicative	RSID	Negative
			AP	Positive/Indicative		
			p30	Positive/Indicative		
			Microscopic	Positive/Indicative		
		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative
A4L4XW	Visual	Negative	AP	Positive/Indicative		scenario does not support testing
			Micro	Positive/Indicative		
			Visual/ALS	Positive/Indicative		
		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested
AARLDN	Expert opinion due to no visible stain		AP, PSA, Micro	Positive/Indicative	Saliva is not tested	
		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested
AB9QVM	Case scenario does not indicate the need for this testing.		AP	Positive/Indicative	Case scenario does not indicate the need for this testing.	
			Micro	Positive/Indicative		
		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested
AMYUTL	KM	Negative	AP	Positive/Indicative	Generally not tested, unless specified.	
			PSA	Positive/Indicative		
			RSID-Semen	Positive/Indicative		
		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested
AP8KHP	Phenolphthalein	Negative	Microscopic Examination	Positive/Indicative	Phadebas	Negative
			p30	Positive/Indicative		
			BCIP	Positive/Indicative		
		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative
AQW9HW			ALS	Positive/Indicative		
			PSA	Positive/Indicative		
			Micro	Positive/Indicative		
		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested
AW84KK	KM	Negative	AP	Positive/Indicative	Scenario does not indicate oral contact	
			Micro	Positive/Indicative		
		<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested

Table 1 - Item 6  
Evidence - Sanitary Pad containing Semen

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
AYDKY4	<b>Conclusion:</b> Not Tested	AP Positive/Indicative Micro Positive/Indicative <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
B2BMZP	No red/brown discoloration upon Visual inspection. <b>Conclusion:</b> Not Tested	ALS Positive/Indicative AP Positive/Indicative Micro Positive/Indicative PSA Positive/Indicative <b>Conclusion:</b> Positive/Indicative	Amylase Diffusion Negative <b>Conclusion:</b> Negative
B3839F	Not red stained <b>Conclusion:</b> Not Tested	ALS Positive/Indicative Micro Positive/Indicative <b>Conclusion:</b> Positive/Indicative	Not validated procedure <b>Conclusion:</b> Not Tested
B4JQUZ	KM Negative <b>Conclusion:</b> Negative	ALS Positive/Indicative AP Positive/Indicative Micro Positive/Indicative <b>Conclusion:</b> Positive/Indicative	Saliva testing not offered by our laboratory <b>Conclusion:</b> Not Tested
BBLR7N	LMG Negative RSID Negative <b>Conclusion:</b> Negative	AP Positive/Indicative RSID Positive/Indicative <b>Conclusion:</b> Positive/Indicative	RSID Negative <b>Conclusion:</b> Negative
BCFFPJ	<b>Conclusion:</b> Not Tested	AP Positive/Indicative Microscopic examination for Sperm heads Positive/Indicative <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
BFVV63	ALS Negative KM Negative <b>Conclusion:</b> Negative	ALS Positive/Indicative AP Positive/Indicative Micro Positive/Indicative <b>Conclusion:</b> Positive/Indicative	RSID Negative <b>Conclusion:</b> Negative
BHL7WV	KM Negative <b>Conclusion:</b> Negative	ALS Positive/Indicative PSA Positive/Indicative Micro Positive/Indicative <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
BKMANH	LMG Negative <b>Conclusion:</b> Negative	ALS Positive/Indicative AP Positive/Indicative Micro Positive/Indicative <b>Conclusion:</b> Positive/Indicative	Amylase Diffusion Negative <b>Conclusion:</b> Negative
BQBWEG	HemDirect Seratec Negative <b>Conclusion:</b> Negative	Micro Positive/Indicative PSA Positive/Indicative <b>Conclusion:</b> Positive/Indicative	Amylase Seratec Negative <b>Conclusion:</b> Negative

Table 1 - Item 6  
Evidence - Sanitary Pad containing Semen

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
BT7FKP	No red-brown color observed  <b>Conclusion:</b> Not Tested	ALS Positive/Indicative AP Positive/Indicative Micro Positive/Indicative PSA Positive/Indicative <b>Conclusion:</b> Positive/Indicative	Amylase Diffusion Negative  <b>Conclusion:</b> Negative
BUB9BG	HemDirect Hemoglobin (SERATEC) Negative <b>Conclusion:</b> Negative	Christmas Tree Stain Slide (Micro) Positive/Indicative <b>Conclusion:</b> Positive/Indicative	Amylase Test (SERATEC) Negative <b>Conclusion:</b> Negative
BVQAGP	Observed light tan colored stain fluoresced significantly using ALS <b>Conclusion:</b> Not Tested	AP Negative <b>Conclusion:</b> Negative	[Laboratory] does not employ tests for Saliva <b>Conclusion:</b> Not Tested
C8J7Z3	no rbs <b>Conclusion:</b> Not Tested	AP Positive/Indicative Micro Positive/Indicative ABAcad p30 Positive/Indicative <b>Conclusion:</b> Positive/Indicative	scenario did not indicate oral contact <b>Conclusion:</b> Not Tested
	<u>Other Tests Performed</u> Semen/Saliva - ALS Positive/Indicative		
CBXYV3	<b>Conclusion:</b> Not Tested	AP Positive/Indicative p30 Positive/Indicative Microscopy Positive/Indicative <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
CFCELU	Phenolphthalein Negative <b>Conclusion:</b> Negative	Acid Phosphatase Positive/Indicative Microscopic / Christmas Tree Stain Positive/Indicative <b>Conclusion:</b> Positive/Indicative	Phadebas Negative <b>Conclusion:</b> Negative
CNJDUV	lab policy <b>Conclusion:</b> Not Tested	AP Positive/Indicative <b>Conclusion:</b> Positive/Indicative	case scenario <b>Conclusion:</b> Not Tested
CUTGYB	Not brown stained. <b>Conclusion:</b> Not Tested	Micro, ALS Positive/Indicative <b>Conclusion:</b> No Response	<b>Conclusion:</b> Not Tested
D7426P	Visual Positive/Indicative LMG Negative <b>Conclusion:</b> Negative	AP Positive/Indicative ABAcad p30 Positive/Indicative Micro Positive/Indicative Visual Positive/Indicative <b>Conclusion:</b> Positive/Indicative	RSID-Saliva Negative <b>Conclusion:</b> Negative
D94JU6	<b>Conclusion:</b> Not Tested	BRENTAMINE Positive/Indicative <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
DF7NRF	no r/b staining <b>Conclusion:</b> Not Tested	BCIP Positive/Indicative Micro Positive/Indicative <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
	<u>Other Tests Performed</u> Amylase Diffusion Negative		

Table 1 - Item 6  
Evidence - Sanitary Pad containing Semen

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
DKXZJ7	Not tested due to the nature of the exhibit <b>Conclusion:</b> Not Tested	Brentamine Test <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	No test for Saliva in ER. No evidential value. <b>Conclusion:</b> Not Tested
	<u>Other Tests Performed</u> Possible Hair <i>Negative</i>		
DXNMY	<b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
E3A4KN	LMG <i>Negative</i> <b>Conclusion:</b> Negative	ALS <i>Positive/Indicative</i> AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Fluid not searched for, per senario info <b>Conclusion:</b> Not Tested
EC6X2V	LMG <i>Negative</i> Visual Examination <i>Positive/Indicative</i> <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> p30 <i>Positive/Indicative</i> ALS <i>Positive/Indicative</i> Microscopic examination <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i> ALS <i>Positive/Indicative</i> <b>Conclusion:</b> Negative
EGZPDX	KM <i>Negative</i> Micro <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> ALS <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
EJN4ZM	Phenolphthalein <i>Negative</i> <b>Conclusion:</b> Negative	Acid Phosphatase <i>Positive/Indicative</i> Xmas Tree Stain/Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Phadebas <i>Negative</i> <b>Conclusion:</b> Negative
ELP4ZK	KM <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
EM3NZG	Seratec HEM LN 200076 D.D: 22-09 <i>Negative</i> <b>Conclusion:</b> Negative	RSID - LN 09120S1 D. D. 22-09 <i>Positive/Indicative</i> Christmas Tree <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Seratec AMY LN 200078 D.D: 22-09 <i>Negative</i> <b>Conclusion:</b> Negative
EPBXTE	Human Blood <i>Negative</i> <b>Conclusion:</b> Negative	CHRISTMAS TREE <i>Positive/Indicative</i> SemenOGELINA <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Human Saliva <i>Negative</i> <b>Conclusion:</b> Negative
ERGE8W	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested

Table 1 - Item 6  
Evidence - Sanitary Pad containing Semen

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
EYDBVZ	Phenolphthalein <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
<u>Other Tests Performed</u> Semen/Saliva - ALS <i>Positive/Indicative</i>			
FATH8U	Visual <i>Negative</i> <b>Conclusion:</b> Negative	ALS <i>Positive/Indicative</i> AP <i>Positive/Indicative</i> p30 <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS <i>Positive/Indicative</i> RSID <i>Negative</i> <b>Conclusion:</b> Negative
FC3HEM	No staining with appearance of Blood <b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> Spermatozoa Microscopy <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Blue paper <i>Negative</i> <b>Conclusion:</b> Negative
FHJBBD	Kastle-Meyer <i>Negative</i> <b>Conclusion:</b> Negative	Acid phosphatase <i>Positive/Indicative</i> Microscopy and Christmas Tree staining <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Phadebas tube test <i>Negative</i> <b>Conclusion:</b> Negative
FKR6D6	Not tested due to nature of exhibit <b>Conclusion:</b> Not Tested	AP (Brentamine) <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	No presumptive test for Saliva; Not tested due to nature of exhibit <b>Conclusion:</b> Not Tested
<u>Other Tests Performed</u> Possible hair <i>Negative</i>			
FP8NMZ	KM <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> p30 <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Phadebas <i>Negative</i> <b>Conclusion:</b> Negative
FQ2ELM	<b>Conclusion:</b> Not Tested	BRENTAMINE <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
FQHTUW	<b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
<u>Other Tests Performed</u> ALS <i>Positive/Indicative</i>			
FXXDW9	KM <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> RSID-Semen <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Generally not tested unless specified <b>Conclusion:</b> Not Tested
G2QWBC	Visual, KM <i>Negative</i> <b>Conclusion:</b> Not Tested	AP, Microscopy <i>Positive/Indicative</i> <b>Conclusion:</b> No Response	<b>Conclusion:</b> Not Tested

Table 1 - Item 6  
Evidence - Sanitary Pad containing Semen

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
G43C6D	Visual and KM <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> Xmas Tree Slide <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	No suggestion of digital penetration or oral ic plus might expect vaginal Amylase  <b>Conclusion:</b> Not Tested
	<u>Other Tests Performed</u> hairs/fibres <i>Negative</i>		
G4LB8G	LMG <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
G6R26K	Did not observe a reddish brown stain  <b>Conclusion:</b> Not Tested	ALS <i>Positive/Indicative</i> AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	Amylase Diffusion <i>Negative</i>  <b>Conclusion:</b> Negative
GD9E9P	<b>Conclusion:</b> Not Tested	PSA <i>Positive/Indicative</i> ALS <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
GDUVL8	KM <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> RSID-Semen <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	Generally not tested unless specified.  <b>Conclusion:</b> Not Tested
GL4D2J	KM <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
GP7BEX	TMB <i>Negative</i> Luminol <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> RSID <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> ALS <i>Inconclusive</i>  <b>Conclusion:</b> Positive/Indicative	Phadebas <i>Negative</i>  <b>Conclusion:</b> Negative
GUZ6CY	based on case history, not tested for presence of Blood  <b>Conclusion:</b> Not Tested	AP, p30 <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	based on case history not tested for presence of Saliva  <b>Conclusion:</b> Not Tested
HBXUYF	PTMB <i>Negative</i>  <b>Conclusion:</b> Negative	Not online with seminal fluid screening  <b>Conclusion:</b> Not Tested	Not online with Saliva screening  <b>Conclusion:</b> Not Tested
HKMHYN	KM <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	Phadebas <i>Negative</i>  <b>Conclusion:</b> Negative



Table 1 - Item 6  
Evidence - Sanitary Pad containing Semen

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
HLFHP9	<b>Conclusion:</b> Not Tested	BRENTAMINE <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
HQB89Z	<b>Conclusion:</b> Not Tested	BRENTAMINE <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
HYKPTJ	KM <i>Negative</i> <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Phadebas Amylase <i>Negative</i> <b>Conclusion:</b> Negative
J2T2AL	Scenario did not provide any details that would lead me to test for Blood <b>Conclusion:</b> Not Tested	ALS <i>Positive/Indicative</i> AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Scenario did not provide any details that would lead me to test for Saliva <b>Conclusion:</b> Not Tested
J8YXUL	No stains for testing <b>Conclusion:</b> Not Tested	ALS <i>Positive/Indicative</i> AP <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	No Saliva testing at Lab <b>Conclusion:</b> Not Tested
JGGLF8	<b>Conclusion:</b> Not Tested	BRENTAMINE <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
K4Q6CR	No reddish-brown staining observed <b>Conclusion:</b> Not Tested	AP, Micro, PSA, p30 <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID Saliva <i>Negative</i> <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> Body Fluid - Test Performed: ALS <i>Positive/Indicative</i>		
K8PF9R	No visible staining observed <b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i> <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> Semen/Saliva - ALS <i>Positive/Indicative</i>		
KBAB8D	*no stains having the appearance of Blood observed. <b>Conclusion:</b> Not Tested	ALS <i>Positive/Indicative</i> AP <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Microscopic <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	*Amylase mapping is not in our laboratory TPM <b>Conclusion:</b> Not Tested
KED2FE	<b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested

Table 1 - Item 6  
Evidence - Sanitary Pad containing Semen

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
KF2JBK	No red-brown staining  <b>Conclusion:</b> Not Tested	AP Positive/Indicative PSA Positive/Indicative Micro Positive/Indicative <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
	<u>Other Tests Performed</u> Semen - ALS Positive/Indicative		
KMLH4D	LMG Negative <b>Conclusion:</b> Negative	AP Positive/Indicative <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
	<u>Other Tests Performed</u> H&E SLIDE: +4H/T Positive/Indicative		
KWN32Z	We don't Hstix/ Luminol for sanitary pad because we dont test for Blood <b>Conclusion:</b> Not Tested	Brentamine (AP) Positive/Indicative <b>Conclusion:</b> Positive/Indicative	As per SOP no prelim testing for Saliva to be performed <b>Conclusion:</b> Not Tested
KYVDX4	KM Negative <b>Conclusion:</b> Negative	AP Positive/Indicative RSID-Semen Positive/Indicative PSA Positive/Indicative <b>Conclusion:</b> Positive/Indicative	Generally not tested unless specified <b>Conclusion:</b> Not Tested
L47NTJ		ALS Positive/Indicative PSA Positive/Indicative Micro Positive/Indicative <b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested
L7D2GC	LMG Negative <b>Conclusion:</b> Negative	AP Positive/Indicative Micro Positive/Indicative PSA Positive/Indicative <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
L9YRHG	KM TEST Negative <b>Conclusion:</b> No Response	AP TEST Positive/Indicative RSID-Semen Positive/Indicative Micro Positive/Indicative <b>Conclusion:</b> No Response	RSID-Saliva Negative <b>Conclusion:</b> No Response
LA84XW		BRENTAMINE Positive/Indicative <b>Conclusion:</b> Not Tested	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
LBC97F	Visual - no red-brown staining observed Negative <b>Conclusion:</b> Not Tested	AP Positive/Indicative Micro Positive/Indicative <b>Conclusion:</b> Positive/Indicative	Phadebas Blue Paper Negative <b>Conclusion:</b> Negative
LNPRB2	KM Negative <b>Conclusion:</b> Negative	AP Positive/Indicative PSA Positive/Indicative RSID-Semen Positive/Indicative <b>Conclusion:</b> Positive/Indicative	Generally not tested unless specified <b>Conclusion:</b> Not Tested

Table 1 - Item 6  
Evidence - Sanitary Pad containing Semen

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
M2XQ6T	TMB <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i>  <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> Body Fluid - ALS <i>Positive/Indicative</i>		
M6CLLQ	<b>Conclusion:</b> Not Tested	Acid Phosphatase <i>Positive/Indicative</i> Microscopy <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
MGNXUE	no red/brown stains observed  <b>Conclusion:</b> Not Tested	ALS <i>Positive/Indicative</i> AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Amylase Diffusion <i>Negative</i>  <b>Conclusion:</b> Negative
MH42MK	Did not observe any red brown staining  <b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> No Response	<b>Conclusion:</b> Not Tested
MHGTDG	<b>Conclusion:</b> Not Tested	AP - Phosphatesmo (paper test for the determination of acid phosphatase) by Macherey-Nagel <i>Positive/Indicative</i> PSA - cassette test for prostate specific antigen by SERATEC <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
MLM86G	KM <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> p30 <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i>  <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> ALS <i>Positive/Indicative</i>		
MP2R6B	Seratec HemDirect <i>Negative</i> <b>Conclusion:</b> Negative	Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Seratec Amylase Test <i>Negative</i> <b>Conclusion:</b> Negative
MUB6RF	KM <i>Negative</i>  <b>Conclusion:</b> Negative	ALS <i>Positive/Indicative</i> AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
MVA9KQ	<b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested

Table 1 - Item 6  
Evidence - Sanitary Pad containing Semen

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
MW4W4L	No red/brown staining on item  <b>Conclusion:</b> Not Tested	AP Positive/Indicative Micro Positive/Indicative  <b>Conclusion:</b> Positive/Indicative	No oral assault alleged  <b>Conclusion:</b> Not Tested
<u>Other Tests Performed</u> Semen - ALS Positive/Indicative			
MZLBBT	TMB Negative ALS Negative  <b>Conclusion:</b> Negative	ALS Positive/Indicative AP Positive/Indicative Micro Positive/Indicative PSA Positive/Indicative  <b>Conclusion:</b> Positive/Indicative	ALS Positive/Indicative RSID Negative  <b>Conclusion:</b> Negative
N4UXGG	KM Negative  <b>Conclusion:</b> Negative	ALS Positive/Indicative PSA Positive/Indicative Micro Positive/Indicative  <b>Conclusion:</b> Positive/Indicative	   <b>Conclusion:</b> Not Tested
NPXL8D	No visible Blood stain present for testing  <b>Conclusion:</b> Not Tested	AP Positive/Indicative  <b>Conclusion:</b> Positive/Indicative	  <b>Conclusion:</b> Not Tested
NXRWAV	Not tested for Blood according to SOP  <b>Conclusion:</b> Not Tested	AP (Brent) Positive/Indicative  <b>Conclusion:</b> Positive/Indicative	No presumptive test  <b>Conclusion:</b> Not Tested
<u>Other Tests Performed</u> No hair was found Negative			
P3FYU7	SERATEC-SANGRE Negative  <b>Conclusion:</b> Negative	MicroSCOPIO Positive/Indicative  <b>Conclusion:</b> Positive/Indicative	SERATEC-Saliva Negative  <b>Conclusion:</b> Negative
P69KR4	Visual Exam - no red staining observed  <b>Conclusion:</b> Not Tested	ALS Positive/Indicative AP Positive/Indicative Micro Positive/Indicative PSA Positive/Indicative AP Mapping Positive/Indicative  <b>Conclusion:</b> Positive/Indicative	Amylase Diffusion Negative Amylase Mapping Negative  <b>Conclusion:</b> Negative
P8RWB7	LMG Negative  <b>Conclusion:</b> Negative	AP Positive/Indicative Micro Positive/Indicative PSA Positive/Indicative  <b>Conclusion:</b> Positive/Indicative	   <b>Conclusion:</b> Not Tested
PAX8GH	[Participant did not return results for Item 6]		
PEULCK	No red-brown staining seen  <b>Conclusion:</b> Not Tested	ALS Positive/Indicative AP Positive/Indicative PSA Positive/Indicative Micro Positive/Indicative  <b>Conclusion:</b> Positive/Indicative	The [Laboratory] does not perform tests for Saliva  <b>Conclusion:</b> Not Tested

Table 1 - Item 6  
Evidence - Sanitary Pad containing Semen

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
PF4ZDY	KM <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> RSID-Semen <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	Generally not tested unless specified  <b>Conclusion:</b> Not Tested
PN2NBQ	no staining consistent with Blood  <b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	RSID Saliva <i>Negative</i>  <b>Conclusion:</b> Negative
<u>Other Tests Performed</u> ALS (Blue) <i>Positive/Indicative</i>			
PU4R3A	KM <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	  <b>Conclusion:</b> Not Tested
Q62YBE	Leucomalachite Green <i>Negative</i>  <b>Conclusion:</b> Negative	No tests available.  <b>Conclusion:</b> Not Tested	No tests available.  <b>Conclusion:</b> Not Tested
<u>Other Tests Performed</u> Forensic light source <i>Positive/Indicative</i>			
QC3ALD	  <b>Conclusion:</b> Not Tested	ALS <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	  <b>Conclusion:</b> Not Tested
QDWVJB	KM <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	Phadebas <i>Negative</i>  <b>Conclusion:</b> Negative
QGK4N	  <b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	  <b>Conclusion:</b> Not Tested
QP966F	  <b>Conclusion:</b> Not Tested	ALS <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	  <b>Conclusion:</b> Not Tested
QQ3V99	ALS <i>Negative</i> KM <i>Negative</i> RSID <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> ALS <i>Positive/Indicative</i> RSID <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	ALS <i>Negative</i> RSID <i>Negative</i>  <b>Conclusion:</b> Negative
QRFPNA	  <b>Conclusion:</b> Not Tested	AP OVERLAY <i>Positive/Indicative</i>  <b>Conclusion:</b> No Response	  <b>Conclusion:</b> Not Tested
<u>Other Tests Performed</u> FLS <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>			

Table 1 - Item 6  
Evidence - Sanitary Pad containing Semen

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
QYE6K9	KM <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
R3UUJC	No reddish-brown staining seen.  <b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro-Sperm <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Saliva RSID <i>Negative</i>  <b>Conclusion:</b> Negative
<u>Other Tests Performed</u> ALS @ 450 nm			
R6ZHWF	N/A, no red/brown discoloration observed  <b>Conclusion:</b> Not Tested	Acid Phosphatase <i>Positive/Indicative</i> Microscopic Identification of Spermatozoa <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID-Saliva <i>Negative</i>  <b>Conclusion:</b> Negative
<u>Other Tests Performed</u> Semen/Saliva - ALS <i>Positive/Indicative</i>			
RJ28Y9	<b>Conclusion:</b> Not Tested	ALS (Polilight) <i>Positive/Indicative</i> AP <i>Positive/Indicative</i> RSID Semen <i>Positive/Indicative</i> Microscopic Exam <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	ALS (Polilight) <i>Positive/Indicative</i> RSID Saliva <i>Negative</i>  <b>Conclusion:</b> Negative
RJGF2G	No Red/brown staining to indicate a need for Blood testing.  <b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Not tested due to no Saliva-related allegations regarding this item in the reported scenario.  <b>Conclusion:</b> Not Tested
RKCZMV	KM <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> RSID-Semen <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Generally not tested unless specified  <b>Conclusion:</b> Not Tested
RQ44Y8	KM <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
RRATXA	<b>Conclusion:</b> Not Tested	BRENTAMINE <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	NO AVAILABLE TEST FOR Saliva  <b>Conclusion:</b> Not Tested
RT728F	No red-brown staining observed  <b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID <i>Negative</i>  <b>Conclusion:</b> Negative
<u>Other Tests Performed</u> Semen/Saliva - ALS <i>Positive/Indicative</i>			

Table 1 - Item 6  
Evidence - Sanitary Pad containing Semen

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
RT9VQL	see comments section  <b>Conclusion:</b> Not Tested	AP Positive/Indicative Micro Positive/Indicative ALS-blue Positive/Indicative <b>Conclusion:</b> Positive/Indicative	see comments section  <b>Conclusion:</b> Not Tested
RX2XQE	<b>Conclusion:</b> Not Tested	ALS Positive/Indicative PSA Positive/Indicative Micro Positive/Indicative <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
RXG4AB	<b>Conclusion:</b> Not Tested	FB Positive/Indicative Micro Positive/Indicative <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
	<u>Other Tests Performed</u> No hairs observed Negative		
RYVJNC	KM Negative  <b>Conclusion:</b> Negative	AP Positive/Indicative p30 Positive/Indicative Micro Positive/Indicative ALS Positive/Indicative <b>Conclusion:</b> Positive/Indicative	RSID Negative  <b>Conclusion:</b> Negative
T6UMQF	Not tested due to lack of red/brown staining  <b>Conclusion:</b> Not Tested	AP Positive/Indicative Micro Positive/Indicative <b>Conclusion:</b> Positive/Indicative	RSID Negative  <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> Possible Semen, Saliva, etc - ALS - Blue Positive/Indicative		
TDB779	Visually inconsistent with Blood.  <b>Conclusion:</b> Not Tested	ALS Positive/Indicative AP Positive/Indicative Micro Positive/Indicative <b>Conclusion:</b> Positive/Indicative	Amylase Diffusion Negative  <b>Conclusion:</b> Negative
TJXU6K	<b>Conclusion:</b> Not Tested	AP Positive/Indicative Micro Positive/Indicative ALS-blue Positive/Indicative <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
TK3Q4U	<b>Conclusion:</b> Not Tested	BRENTAMINE Positive/Indicative <b>Conclusion:</b> Positive/Indicative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
TLZRC7	LMG Negative  <b>Conclusion:</b> Negative	ALS Positive/Indicative AP Positive/Indicative Micro Positive/Indicative PSA Positive/Indicative <b>Conclusion:</b> Positive/Indicative	Amylase Diffusion Negative  <b>Conclusion:</b> Negative

Table 1 - Item 6  
Evidence - Sanitary Pad containing Semen

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
TPKL98	FOB <i>Negative</i>  <b>Conclusion:</b> Negative	RSID Semen <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	RSID Saliva <i>Negative</i>  <b>Conclusion:</b> Negative
TPY8KU	KM <i>Negative</i>  <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested
U2DKJA	Not tested- no staining consistent with Blood was observed.  <b>Conclusion:</b> Not Tested	Visual <i>Positive/Indicative</i> ALS <i>Positive/Indicative</i> AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	Not tested- per scenario there is no indication of (s) oral/ (v) pubic area contact  <b>Conclusion:</b> Not Tested
U4ZY9K	<b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
UA43XH	<b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
UBHEU3	Visual <i>Negative</i> O-tol <i>Negative</i>  <b>Conclusion:</b> Negative	ALS <i>Positive/Indicative</i> AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
UBYTX6	O-tol <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> ALS <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
UD69B4	<b>Conclusion:</b> Not Tested	PSA <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
UJAUJ7	ALS <i>Negative</i>  <b>Conclusion:</b> Negative	ALS <i>Positive/Indicative</i> AP <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	Our lab does not test for Saliva.  <b>Conclusion:</b> Not Tested
UMQJHA	O-tol <i>Negative</i>  <b>Conclusion:</b> Negative	ALS <i>Positive/Indicative</i> AP <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
UNPFCD	Visual <i>Inconclusive</i> KM <i>Negative</i>  <b>Conclusion:</b> Negative	ALS <i>Positive/Indicative</i> ABACard p30 <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested



Table 1 - Item 6  
Evidence - Sanitary Pad containing Semen

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
UTYHE9	O-tol <i>Negative</i> <b>Conclusion:</b> Negative	<b>Conclusion:</b> Not Tested	<b>Conclusion:</b> Not Tested
VCNGT7	NT: no staining indicative of Blood to warrant testing <b>Conclusion:</b> Not Tested	ALS <i>Positive/Indicative</i> AP <i>Positive/Indicative</i> p30/PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	NT: case scenario did not indicate a need for this test <b>Conclusion:</b> Not Tested
VGJ7F6	Visual- no red color observed <b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> ALS <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Amylase Diffusion <i>Negative</i> <b>Conclusion:</b> Negative
VXTUT6	Visually inconsistent with Blood <b>Conclusion:</b> Not Tested	ALS <i>Positive/Indicative</i> AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	Amylase Diffusion <i>Negative</i> <b>Conclusion:</b> Negative
VY377Z	SERATEC- HemDirect hemoglobin Assay <i>Negative</i> <b>Conclusion:</b> Negative	Christmas Tree Stain-Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	SERATEC-Amylase Test <i>Negative</i> <b>Conclusion:</b> Negative
W6MFGJ	<b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
	<u>Other Tests Performed</u> No hairs observed <i>Negative</i>		
W7EDQB	KM <i>Negative</i> <b>Conclusion:</b> Negative	ALS <i>Positive/Indicative</i> ABAcad p30 <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
W7H6F7	<b>Conclusion:</b> Not Tested	BRENTAMINE <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
W7HZ4H	NA - no rbs observed <b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i> <b>Conclusion:</b> Positive/Indicative	RSID-Saliva <i>Negative</i> <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> ALS - Semen/Saliva <i>Positive/Indicative</i>		
WC7HLZ	Not applicable to scenario. <b>Conclusion:</b> Not Tested	Microscopical Examination <i>Positive/Indicative</i> <b>Conclusion:</b> No Response	Not applicable to scenario. <b>Conclusion:</b> Not Tested

Table 1 - Item 6  
Evidence - Sanitary Pad containing Semen

WebCode	BLOOD		SEMEN		SALIVA	
	Tests Performed	Results	Tests Performed	Results	Tests Performed	Results
WET9M6	O-tol Seratec HemDirect	Inconclusive Negative	AP Seratec PSA	Positive/Indicative Positive/Indicative	Amylase Diffusion	Negative
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative	
WFKMR9			ALS PSA Micro	Positive/Indicative Positive/Indicative Positive/Indicative		
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested	
WGZMBX	KM	Negative	AP Micro	Positive/Indicative Positive/Indicative	RSID	Negative
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative	
WHCE4E						
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Not Tested	
WHTE3B	LMG HemaTrace	Negative Negative	AP PSA Micro	Positive/Indicative Positive/Indicative Positive/Indicative	Amylase Radial Diffusion	Negative
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative	
	<u>Other Tests Performed</u>					
	ALS Positive/Indicative					
WKDHV2	LMG	Negative	AP Micro PSA	Positive/Indicative Positive/Indicative Positive/Indicative		
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested	
WREWG3	KM	Negative	AP PSA Micro	Positive/Indicative Positive/Indicative Positive/Indicative		
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested	
WUNL77	Visual LMG	Positive/Indicative Negative	ALS AP p30 Micro	Positive/Indicative Positive/Indicative Positive/Indicative Positive/Indicative	ALS RSID	Positive/Indicative Negative
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative	
WUZP9W			AP	Positive/Indicative		
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> No Response	
WWAL2G	KM	Negative	AP Micro	Positive/Indicative Positive/Indicative	RSID	Negative
	<b>Conclusion:</b> Negative		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Negative	
WYFXTQ			BRENTAMINE	Positive/Indicative	NO AVAILABLE TEST FOR Saliva	
	<b>Conclusion:</b> Not Tested		<b>Conclusion:</b> Positive/Indicative		<b>Conclusion:</b> Not Tested	

Table 1 - Item 6  
Evidence - Sanitary Pad containing Semen

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
X3B7GW	Hem Direct Immunocromatografic SERATEC <i>Negative</i>  <b>Conclusion:</b> Negative	Christmas tree coloration <i>Positive/Indicative</i> Rapid Stain Identification Semen RSID <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	Forensic test Kit SERATEC Amylase test Immunocromatografic <i>Negative</i>  <b>Conclusion:</b> Negative
X6KZP4	No red-brown staining observed  <b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	Triage scientist did not request testing for Saliva  <b>Conclusion:</b> Not Tested
X9ZNU9	  <b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	  <b>Conclusion:</b> Not Tested
<u>Other Tests Performed</u> No hairs observed <i>Negative</i>			
XENFB3	Visual <i>Negative</i> KM <i>Negative</i>  <b>Conclusion:</b> No Response	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> No Response	Phadebas paper <i>Negative</i>  <b>Conclusion:</b> No Response
XF2TU6	Visual <i>Negative</i>  <b>Conclusion:</b> Negative	ALS <i>Positive/Indicative</i> AP <i>Positive/Indicative</i> p30 <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	ALS <i>Positive/Indicative</i> RSID <i>Negative</i>  <b>Conclusion:</b> Negative
XPMX36	KM <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	Phadebas <i>Negative</i>  <b>Conclusion:</b> Negative
XQK9X8	Visual <i>Negative</i>  <b>Conclusion:</b> Not Tested	ALS <i>Positive/Indicative</i> AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	Scenario gave no indication to warrant this testing  <b>Conclusion:</b> Not Tested
XW6FC7	No Blood-like stains observed  <b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	Amylase radial Diffusion <i>Inconclusive</i>  <b>Conclusion:</b> Inconclusive
XZ8C2Z	  <b>Conclusion:</b> Not Tested	AP <i>Positive/Indicative</i> PSA <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	  <b>Conclusion:</b> Not Tested
Y44E48	KM <i>Negative</i>  <b>Conclusion:</b> Negative	AP <i>Positive/Indicative</i> Micro <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	  <b>Conclusion:</b> Not Tested
Y6GWGK	  <b>Conclusion:</b> Not Tested	BRENTAMINE <i>Positive/Indicative</i>  <b>Conclusion:</b> Positive/Indicative	NO AVAILABLE TEST FOR Saliva  <b>Conclusion:</b> Not Tested

Table 1 - Item 6  
Evidence - Sanitary Pad containing Semen

WebCode	BLOOD	SEMEN	SALIVA
	Tests Performed Results	Tests Performed Results	Tests Performed Results
Y8JR6U	HemDirect Hemoglobin (SERATEC) Negative <b>Conclusion:</b> Negative	Christmas Tree Coloring Positive/Indicative <b>Conclusion:</b> Positive/Indicative	Amylase Test (SERATEC) Negative <b>Conclusion:</b> Negative
YKN8N6	TMB Positive/Indicative FOB Positive/Indicative Seratec PMB Test menstrual Negative Seratec PMB Test peripheral Negative <b>Conclusion:</b> Positive/Indicative	AP Positive/Indicative RSID Semen Positive/Indicative <b>Conclusion:</b> Positive/Indicative	RSID Saliva Negative Seratec Alpha Amylase Test Negative <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> ALS Positive/Indicative		
YQDKUY	Not tested due to absence of red-brown staining. <b>Conclusion:</b> Not Tested	AP Positive/Indicative p30 Positive/Indicative Micro Positive/Indicative ALS Positive/Indicative <b>Conclusion:</b> Positive/Indicative	Not tested based on scenario. <b>Conclusion:</b> Not Tested
YXEV6X	Scenario didn't support this analysis <b>Conclusion:</b> Not Tested	ALS Positive/Indicative AP Positive/Indicative Micro Positive/Indicative <b>Conclusion:</b> Positive/Indicative	Scenario didn't support this analysis <b>Conclusion:</b> Not Tested
Z6CT77	No RBS observed <b>Conclusion:</b> Not Tested	AP Positive/Indicative Micro Positive/Indicative <b>Conclusion:</b> No Response	Saliva testing not performed in lab <b>Conclusion:</b> Not Tested
ZAHM23	LMG Negative <b>Conclusion:</b> Negative	PSA Positive/Indicative Micro Positive/Indicative <b>Conclusion:</b> Positive/Indicative	NT <b>Conclusion:</b> Not Tested
ZFBUGP	<b>Conclusion:</b> Not Tested	BRENTAMINE Positive/Indicative <b>Conclusion:</b> Positive/Indicative	NO AVAILABLE TEST FOR Saliva <b>Conclusion:</b> Not Tested
ZM8LR6	KM Negative <b>Conclusion:</b> Negative	AP Positive/Indicative <b>Conclusion:</b> Positive/Indicative	Do not perform <b>Conclusion:</b> Not Tested
ZPJAFB	Micro Negative KM Negative <b>Conclusion:</b> Negative	ALS Positive/Indicative AP Positive/Indicative Micro Positive/Indicative <b>Conclusion:</b> Positive/Indicative	RSID Negative <b>Conclusion:</b> Negative
ZUCGUD	<b>Conclusion:</b> Not Tested	AP Positive/Indicative Micro Positive/Indicative <b>Conclusion:</b> Positive/Indicative	<b>Conclusion:</b> Not Tested
ZWYX9R	KM Negative <b>Conclusion:</b> Negative	AP Positive/Indicative Micro Positive/Indicative <b>Conclusion:</b> Positive/Indicative	RSID Negative <b>Conclusion:</b> Negative
	<u>Other Tests Performed</u> Semen/Saliva - ALS Positive/Indicative		

**Response Summary for Table 1 -  
Item 6: Sanitary Pad containing Semen**

	<u>Blood</u>	<u>Semen</u>	<u>Saliva</u>
Positive/Indicative	1	212	0
Negative	110	1	83
Inconclusive	0	0	2
Not Tested (NT)	117	10	143
No Response	4	9	4
Total	232	232	232

# Additional Comments

## TABLE 2

WebCode	Additional Comments
24D4LA	The [Laboratory] does not conduct forensic serological tests for saliva. Therefore, items 1, 2, 3, 4, 5, and 6 did not have saliva tests performed on them.
24XLKP	This test is being completed as part of a male screening protocol and only tests that may be performed by the analyst in casework were performed on this proficiency test.
3EC4Q2	Amylase Radial Diffusion: A faint/partial clearing was observed in the wells around items 1, 3, and 5; therefore, the results are inconclusive. Amylase is present in body fluids including blood and/or semen, which these items also tested positive for. A stain on item 6 tested positive for the presence of human hemoglobin using the HemaTrace test; however, a negative result was obtained with LMG, a presumptive test for blood and no visual characteristics of blood were observed. Due to the sensitivity of this test, human hemoglobin can be detected in body fluids other than blood such as saliva, urine, semen, or sweat. The stain on item 6 tested positive for semen.
3KX989	No test for saliva validated for Field Investigation Unit (FIU) use. Non-swab Items 5 and 6 not tested because this type of testing is performed by a laboratory unit not the FIU field responders.
3KXA9U	This scenario / test design was much closer to what we would encounter in actual casework. The details helped to guide the testing.
3QHEXN	As per laboratory procedure, items with visible staining were tested and the only presumptive testing our crime scene unit performs is LMG for the possible presence of blood. Items suspected of having bodily fluids present on them would typically be collected and forwarded to the biological sciences section for analysis.
3RYBLG	Item 3: I did not test using Luminol because there was visible blood which I tested using Hemastix. Item 4: I did not test for semen because covering minute says the suspect ejaculated in the victim's vagina. I did not test using Luminol because there was visible blood, and the victim scratched the suspect on his face, so he could have bled and dropped some blood on her breasts. Reason for submitting swab for possible blood. Item 5: I did not test for semen because the covering minute says she wiped her ring with the rag and used the sanitary pad to collect semen.
4ABGEP	Item 1: Four swab with white handle is POSITIVE for Blood and Negative for Semen and for Saliva. Item 2: Four swab with Pink handle is POSITIVE for Saliva and Negative for Blood and for Semen. Item 3: Four swab with Blue handle is POSITIVE for Blood and for Semen and Negative for Saliva. Item 4: Four swab with Yellow handle is POSITIVE for Blood and for Saliva and Negative for Semen. Item 5: One red rag used to wipe victim's ring is POSITIVE for Blood and Negative for Semen and for Saliva. Item 6: One Sanitary Pad from victim is POSITIVE for Semen and Negative for Blood and for Saliva.
4B9RAR	In the laboratory there standard work procedures. 1) Item 1,3,4,5 contain blood, indicative of human origin. Blood was not found in item 2. 2) Item 3 and 6 contain semen with spermatozoa. Semen was not found on Item 1 and 2. 3) Item 2 and 4 contain amylase, indicative of human saliva. Saliva was not found on item 1. The sheet was not marked with Item number. The Item 1 correspond with page 3, Item 2 with page 4, Item 3 with page 5, Item 4 with page 6, Item 5 with page 7 and Item 6 with page 8.
4K8M4G	Swab 3 was tested for both blood and semen. Hemastix was used because of visible blood. Swab 4 had visible blood, and according to SOP possible blood to be tested. Suspect's saliva on the swab would be of interest, 4B - would be used for this purpose, hence it was not tested. Item 5 only tested or blood because the cover letter states that the victim used it to wipe the blood off her ring which had the suspect's blood. Brentamine /possible semen not tested. Item 6 invisible blood (possible blood) not tested for on the sanitary pad. Hair removed from exhibits, if present, however not tested.
4L7NCT	Only screened for blood per DNA Casework Technical Leader on this proficiency.
4QDG2H	This laboratory no longer tests for semen. If a sexual assault is suspected the evidence would be sent to another laboratory for screening and DNA testing. This laboratory does not test for saliva. If saliva is suspected on an evidence item, that item would be forwarded to another laboratory for DNA testing.
4UKGK4	[Laboratory] does not perform saliva testing.

TABLE 2

WebCode	Additional Comments
4V7FET	Item 1: Four swab with white handle is positive for Blood and Negative for Semen and Saliva. Item 2: Four swab with Pink handle is positive for Saliva, Negative for Blood and Semen. Item 3: Four swab with Blue handle is positive for Blood and Semen and negative for Saliva. Item 4: Four swab with Yellow handle is positive for Blood and Saliva and negative for Semen. Item 5: One red rag used to wipe victim's ring is positive for Blood and Negative for Semen and Saliva. Item 6: One Sanitary pad from victim is positive for Semen and negative for Blood and Saliva.
4XZ2BQ	The reason for selecting "NT" for saliva tests: I have not been trained to perform these tests. The reason I did not perform a blood screening test (LMG) for items 2 and 6: There were no suspected bloodstains observed.
6B3X4Q	Blood was indicated on samples tested from Item 1, Item 3, Item 4, and Item 5. Examinations on a sample tested from Item 6 revealed the presence of semen containing spermatozoa. No semen was found on samples tested from Item 1 and Item 2. No human salivary alpha-amylase was detected on a sample tested from Item 1. Human salivary alpha-amylase was indicated on samples tested from Item 2 and Item 4.
6VPH62	We do not perform a specific screening test for saliva. Fluorescent areas, to include those presumptively tested for semen, would be submitted to the Laboratory for further examination in our Forensic Biology section. The fluorescence of item 2 was observed at the base of the cotton, where the cotton meets the stick and needed to be compared to the control swabs and other swabs to determine fluorescence. The fluorescence of item 3 was determined to be inconclusive as it was observed to be faint, as if there was possibly an extra layer of cotton on top of the red-brown staining observed.
7CWXP9	Item 2 was not tested with any blood tested as there was no Reddish brown staining observed
8UNBTZ	Amylase Radial Diffusion: A faint/partial clearing was observed in the wells around items 01, 03, 05, and 06; therefore, the results are inconclusive. Amylase is present in body fluids including blood and/or semen, which these items also tested positive for.
92M92N	My laboratory does not perform screening tests for saliva.
987KRA	item 4: possible semen not tested due to lack of evidential value.
9J6AWQ	Items 1, 3, 4, and 5 contain blood. Presumptive* testing for human origin was positive. No blood was found on Items 2 or 6. Items 3 and 6 contain semen. No semen was found on Items 1, 2, 4, or 5. No further analysis was conducted. *presumptive tests do not confirm the presence of bodily fluids or human origin
9RWMWQ	My laboratory does not perform screening tests for saliva.
9TC7FM	My laboratory does not perform screening tests for saliva.
A49C8Z	No hairs were observed on red rag (1.5) or sanitary pad (1.6). Samples from the swabs labeled Item #1, Item #2, Item #3, Item #4, a cutting from area 1 on the red rag, and a cutting from area 1 on the sanitary pad were collected and retained for PCR-based DNA analysis.
AP8KHP	Viewed Items 5 and 6 under ALS.
AYDKY4	This test is being completed as part of a male screening protocol and only tests that may be performed by the analyst in casework were performed on this proficiency test.
B3839F	Visual examination with an alternate light source was performed on item 1E1 (item 5) and item 1F1 (item 6). Presumptive testing detected the possible presence of blood on item 1A (item 1), item 1C (item 3), item 1D (item 4), and item 1E1 (item 5). Spermatozoa were observed on item 1C (item 3) and item 1F1 (item 6), which confirms the presence of semen. Semen was not detected on item 1A (item 1), item 1B (item 2), item 1D (item 4), and item 1E1 (item 5).
B4JQUZ	Report Wording: Blood was identified on Item 1, Item 3, Item 4, and Item 5. No blood was found on Item 2, Item 6, and Item 7. Semen was identified on Item 3 and Item 6. No semen was found on Item 1, Item 2, Item 4, Item 5, and Item 7. Appropriate samples are being submitted for DNA testing. If a DNA profile is developed, known oral swabs are needed from the victim and any developed suspect(s). Retained Samples: Item(s) Item 1, Item 2, Item 3, Item 4, and Item 7. Cutting(s) from Item 5 and Item 6 Tape lift(s) from Item 5 and Item 6.
BCFFPJ	Urine tests on item 1 were deemed inconclusive because the blood staining present on the swabs had discoloured the supernatant used to test for urine. It was therefore not possible to determine whether or not there may have been a positive reaction obtained.

TABLE 2

WebCode	Additional Comments
BQBWEG	1- According to the analyzes performed on samples of swabs (item 2) and swabs (item 4); human saliva was detected. 2- According to the analyzes performed on samples of swabs (item 1), swabs (item 3), red rag used to wipe victim's ring (item 5), and sanitary pad from victim (item 6), human saliva was not detected. 3- According to the analyzes performed on samples of swabs (item 1), swabs (item 3), swabs (item 4) and red rag used to wipe victim's ring (item 5); human blood was detected. 4- According to the analyzes performed on samples of swabs (item 2), and sanitary pad from victim (item 6); blood was not detected. 5- According to the analyzes performed on samples of swabs (item 3), and sanitary pad from victim (item 6); semen was detected. 6- According to the analyzes performed on samples of swabs (item 1), swabs (item 2), swabs (item 4), and red rag used to wipe victim's ring (item 5); human semen was not detected.
BUB9BG	- Item 1: Four (4) swabs are POSITIVE for blood and NEGATIVE for semen and saliva. - Item 2: Four (4) swabs are POSITIVE for saliva and NEGATIVE for semen and blood. - Item 3: Four (4) swabs are POSITIVE for blood and semen and NEGATIVE for saliva. - Item 4: Four (4) swabs are POSITIVE for blood and saliva and NEGATIVE for semen. - Item 5: One red rag used to wipe victim's ring is POSITIVE for blood and NEGATIVE for semen and saliva. - Item 6: One sanitary pad from victim is POSITIVE for semen and NEGATIVE for blood and saliva.
CUTGYB	Visual examination with an alternate light source was performed on Items 1E (Item 5) and 1F (Item 6). Presumptive testing detected the possible presence of blood on Items 1A (Item 1), 1C (Item 3), 1D (Item 4) and Sample 1E1 (Item 5). Spermatozoa were observed on Item 1C (Item 3) and Sample 1F1 (Item 6), which confirms the presence of semen. Semen was not detected on Items 1A (Item 1), 1B (Item 2) and 1D (Item 4) and Sample 1E1 (Item 5). Saliva testing was not performed because our laboratory does not have a validated procedure for saliva testing. [Initials] 05-09-2022
D7426P	No hairs were observed on the rag or on the sanitary pad.
DF7NRF	Our lab doesn't conduct saliva testing, but rather performs Amylase Diffusion to detect the presence of amylase. Item 1- result is inconclusive, but is the result I frequently see related to samples that are Phenolphthalein positive.
DXNMY Y	This test is being completed as part of a male screening protocol and only tests that may be performed by the analyst in casework were performed on this proficiency test.
EC6X2V	No hairs observed on the items.
ELP4ZK	Items 1, 3, 4 and 5 contain blood. Presumptive* testing for human origin was positive. Items 3 and 6 contain semen. No semen was found on Items 1, 2, 4, or 5. No blood was found on Items 2 or 6. *presumptive tests do not confirm the presence of bodily fluids or human origin.
ERGE8W	No test for saliva validated for Field Investigation Unit (FIU) use. Non-swab Items 5 and 6 not tested because this type of testing is performed by a laboratory unit not the FIU field responders.
FHJBD	No other body fluids tested for other than those indicated. DNA profiling carried out on each item, and results not added here.
FKR6D6	Item 6 was not tested for presumptive blood according to Evidence Recovery procedure BIO0008P. All exhibits were tested according to the nature as described in case summary and according to BIO0008P.
FQ2ELM	Item 3: tested for both blood and semen because there was a fight and the victim was raped on the floor. Item 4: tested for blood since the suspect bit the victim's breast. Item 5: tested for blood with only hemastix for visible stains. Did not test with luminol since the exhibit is not dark colored. [From Table 1 - Item 5: "NO AVAILABLE TEST FOR Saliva."]
FQHTUW	Items 2 and 6 not tested for blood due to lack of red-brown staining.
G4LB8G	My laboratory does not perform screening tests for saliva.
GL4D2J	Items 3 and 6 contain semen. No semen was found on Items 1, 2, 4, or 5. Items 1, 3, 4, and 5 contain blood. Presumptive* testing for human origin was positive. No blood was found on Items 2 or 6. Results relate only to the items or sampling of items tested. *presumptive tests do not confirm the presence of bodily fluids or human origin
GUZ6CY	[Laboratory] biology does not test swabs for the presence of saliva (using the Phadebas press test).
HBXUYF	Not online with seminal fluid and saliva screening.



TABLE 2

WebCode	Additional Comments
J2T2AL	This test was a great improvement over the 2021 test. Thank you for taking comments from last year into consideration for this year's test.
JGGLF8	Item 4: semen was not tested since it was not mentioned on the covering minute that the semen might have been deposited on the victim's body. Item 5: semen not tested, the rag was used by the victim to wipe the blood off the ring.it was not mentioned if the suspect used the rag. Item 6: According to the SOP, we do not test a panty liner for blood since it is used for drainage. We only check for visible blood.
K8PF9R	ABACard PSA test used during item 3 screening. Seratec PSA test used during item 6 screening.
KED2FE	Items 1, 3, 4 and 5 contain blood. Presumptive* testing for human origin was positive. No blood was found on Item 2. Items 3 and 6 contains semen. No semen was found on Items 1, 2 or 4. *Presumptive tests do not confirm the presence of bodily fluids or human origin.
KF2JBK	Saliva testing not performed in this lab. For Item 5, ALS and AP were negative so I did not perform PSA or micro tests.
L7D2GC	My laboratory does not perform screening tests for saliva.
LA84XW	item 3: Brentamine test was performed on one of the blood swabs because i suspected the semen might have spilled on the floor. Indeed the test was positive for semen giving me a mixed stain result.
LBC97F	Prior to reporting blood we use the following statement: "The reporting of blood in this statement is based on its appearance and a positive result for a presumptive chemical test for blood. A presumptive test is used to screen for the presence of a substance but it cannot confirm its presence." Positive amylase results are reported as such: "The item was examined for the presence of amylase. Amylase is a substance which occurs at high levels in saliva, however it can also be found at lower levels in other body fluids. A positive test result is reported as probable saliva being present".
M2XQ6T	Item 5: Screened with ALS for Saliva and Seminal material only. Blood visible without ALS screening.
MH42MK	Saliva was not tested because our Forensics Lab does not test for saliva, therefore I did not have any of the chemicals to use for saliva testing.
MUB6RF	Our laboratory does not perform saliva testing, therefore, it was not conducted.
MVA9KQ	This test is being completed as part of a protocol for male screening and discipline expertise in vehicle processing. Only tests that may be performed by the analyst in case work or vehicle processing were performed on this proficiency test.
MW4W4L	Item 5 - In "Other Tests" section: I performed ALS and had to indicate positive because there was a fluorescent glow around the single red/brown stain. There were no other areas on the items that were positive with ALS, but because of the fluorescent glow, I indicated positive.
NPXL8D	Our crime scene team does not perform test for the presence of saliva.
NXRWAV	Item 4 : Sanitary pad was not tested for blood in accordance to SOP BIO0008P.
P8RWB7	My laboratory does not perform screening tests for saliva
PAX8GH	Our laboratory only examines blood stains at the moment. That is why we only examined the red rug (item 5) for blood.
PU4R3A	Items 3 and 6 contain semen. No semen was found on Items 1, 2, 4, or 5. Items 1, 3, 4, and 5 contain blood. Presumptive* testing for human origin was positive. No blood was found on Items 2 or 6. No further analysis was conducted. *presumptive tests do not confirm the presence of bodily fluids or human origin
Q62YBE	In our labratory we do not have tests for semen and amylas at the moment. All materials where semen might occur is sent to our biggest labrotory where they use Acid Phosphatase and Microscopes.
QGHK4N	This test is being completed as part of a male screening protocol and only tests that may be performed by the analyst in casework were performed on this proficiency test.
QYE6K9	Items 1, 3, 4 and 5 contain blood. Presumptive* testing for human origin was positive. No blood was found on Items 2 or 6. Items 3 and 6 contain semen. No semen was found on Items 1, 2, 4 or 5. No further analysis was conducted. *presumptive tests do not confirm the presence of body fluids or human origin.

TABLE 2

WebCode	Additional Comments
RJ28Y9	Item 1 - Human blood was detected. Item 2 - Apparent saliva was detected. Item 3 - Human blood and semen were detected. Spermatozoa were observed. Item 4 - Human blood and apparent saliva were detected. Item 5 - Human blood was detected. Item 6 - Semen was detected, spermatozoa were observed.
RRATXA	ITEM 4: BRENTAMINE TEST PERFORMED ON THE EXHIBIT SINCE THE SUSPECT JUST RUN OFF AND STAIN OF HIS SEMEN COULD ALSO BE DEPOSITED ON THE VICTIM'S BREAST. ITEM 5: BRENTAMINE TEST WAS PERFORMED ON THE CLOTH, AS TRACES OF SEMEN IS OF EVIDENTIAL VALUE TO THE CASE. ITEM 6: NO BLOOD TEST PERFORMED ON EXHIBITS AS THE VICTIM COULD HAVE USE FOR DRAINAGE AND POSSIBLE SEMEN HAVE EVIDENTIAL VALUE ON EXHIBIT.
RT9VQL	This test is being completed as part of a male screening protocol and only tests that may be performed by the analyst in casework were performed on this proficiency test.
TJXU6K	This test is being completed as part of a male screening protocol and only tests that may be performed by the analyst in casework were performed on this proficiency test.
TK3Q4U	Item 3-only hemastix test was done because blood was visible. Item 4- i did not test for semen (brentamine test) because the swab was collected from the victims breast. Item 5-i did not test for semen (brentamine test) because the red rag was used by victim to wipe her ring.
TPY8KU	Item 2 was visually examined and no evidence of blood was observed, therefore no chemical testing was performed. Since the laboratory does not perform DNA analysis, saliva, or semen testing any items needing further analysis would be forwarded to another laboratory.
U2DKJA	This body fluid identification proficiency test continues to consume an excess of analyst time and laboratory resources and again has an overly complicated scenario. One non-scenario sample for all body fluid identification and two scenario samples would be more than sufficient for annual proficiency assessment.
U4ZY9K	This test is being completed as part of a male screening protocol and only tests that may be performed by the analyst in casework were performed on this proficiency test.
UA43XH	This test is being completed as part of a male screening protocol and only tests that may be performed by the analyst in casework were performed on this proficiency test.
UBHEU3	This laboratory does not confirm the presence of saliva.
UD69B4	N/A = not applicable. The following items were not tested for all bodily fluids due to lack of indication for the test(s) to be done in the scenario and visual examination of the items as is our normal work procedure: Item 3 was not tested for saliva. Item 4 not tested for semen. Item 5 not tested for semen or saliva. Item 6 not tested for blood or saliva
UMQJHA	This laboratory does not test for saliva.
UNPFCD	Our laboratory does not test for saliva.
UTYHE9	Only authorized for blood screening. No semen or saliva testing was performed.
W7EDQB	The ABACard® HemaTrace® test kits will give positive results for blood from humans, all primates, and the domestic ferret. The ABACard® p-30 test kits can give positive results for evidentiary samples containing neat male urine. The condition of the materials (aged, washed, chemically treated, etc.) that are tested for biological fluids may affect the results. This laboratory does not perform saliva testing.
W7H6F7	ITEM 5: TESTED FOR HEMASTIX ONLY BECAUSE THE VICTIM ONLY WIPED HER RING WITH A RAG AS SHE HAD INJURED THE SUSPECT WITH HER RING WHILE HE WAS TRYING TO RAPE HER
WET9M6	The sample collected from Item 6 developed a light blue color when tested with O-ToI
WHCE4E	No test for saliva validated for Field Investigation Unit (FIU) use. Non-swab Items 5 and 6 not tested because this type of testing is performed by a laboratory unit not the FIU field responders.
WHE3B	Amylase Radial Diffusion: A faint/partial clearing was observed in the wells around items 1, 3, and 5; therefore, the results are inconclusive. Amylase is present in body fluids including blood and/or semen, which these items tested positive for.
WKDHV2	My laboratory does not perform screening tests for saliva.

TABLE 2

WebCode	Additional Comments
WREWG3	Items 1, 3, 4, and 5 contain blood. Presumptive* testing for human origin was positive. Items 3 and 6 contain semen. No blood was found on Items 2 or 6. No semen was found on Items 1, 2, 4, or 5. Results relate only to the items or sampling of items tested. *presumptive tests do not confirm the presence of bodily fluids or human origin
WUNL77	No hairs were observed on the red rag or sanitary pad.
X3B7GW	Not blood, semen, weren't detected on the control swabs. Sample No 1. Blood Indicative of human origin. Sample No 2. Saliva indicative of human origin. Sample No 3. Blood and Semen indicative of human origin. Sample No 4. Blood and saliva indicative of human origin. Sample No 5. Blood indicative of human origin. Sample No 6. Semen indicative of human origin.
X6KZP4	Item 3 RSID - Extract colour dark red/brown. Item 5 Semen - Rag examined with ALS, which includes 470nm with 530 and 555nm interference goggles during saliva screen. These combinations are also used for detection of semen. No fluorescence was observed.
XF2TU6	No hairs were observed on the item 5 rag or the item 6 sanitary pad. All microscopic examinations conducted following the Kernechtrot-Picroindigocarmine staining procedure.
Y44E48	Saliva testing is not performed in our laboratory.
Y6GWGK	item 6: was not tested for blood as there was no visible blood as well as the fact that the pad was worn after the incident. Blood from the victim does not have evidential value.
YQDKUY	Item 2 swabs were tested for urea. The tests were inconclusive due to false positive results. For urea tests using bromothymol blue-infused filter paper and a urease solution, our manual states: "A blue color change at this step [after adding one drop of deionized water onto the suspected urine stain and filter paper, but before adding one drop of the urease solution] indicates a false positive result."
ZAHM23	Saliva testing is not performed in our lab.
ZM8LR6	Items 1, 3, 4, and 5 were presumptively positive for blood. Items 3 and 6 was presumptively positive for semen. Items 1, 2, 4, and 5 were presumptively negative for semen. Items 2 and 6 was presumptively negative for blood. This department does not test for saliva. It will be noted that the presumptive semen tests were expired at the time of testing; non-expired tests were unavailable. Controls were performed upon receipt of the tests batch by the QA supervisor.
ZPJAFB	Control swabs not tested @ this time.
ZUCGUD	This test is being completed as part of a male screening protocol and only tests that may be performed by the analyst in casework were performed on this proficiency test.

-End of Report-  
(Appendix may follow)

## Test No. 22-5781: Body Fluid Identification

DATA MUST BE SUBMITTED BY **May 23, 2022, 11:59 p.m.** TO BE INCLUDED IN THE REPORT

Participant Code: U1234A

WebCode: CHHRDT

The Accreditation Release section can be accessed by using the "Continue to Final Submission" button above. This information can be entered at any time prior to submitting to CTS.

**Scenario (this scenario applies only to Items 3-6):**

Police are investigating a sexual assault involving a female victim and male suspect. The victim and suspect first connected through a dating site and later physically met at the victim's home. After a few drinks, the couple went to the victim's bedroom. The victim told police that at first, they were kissing but then the suspect became sexually aggressive. The suspect pulled her down to the floor and would not stop after she asked. The suspect severely hit the victim in her face and forcefully bit her breast. The victim tried to fight him off, cutting his face with her ring. The victim also reports to police that she believes he may have ejaculated in her vagina, after which he quickly grabbed his clothes and left. After the suspect left, the victim placed a sanitary pad in her underwear and wiped her ring off with a rag. The following items are being submitted to your laboratory for examination: One envelope containing four duplicate swabs (Item 3) taken from a stain on the hardwood floor in the victim's bedroom. One envelope containing four duplicate swabs (Item 4) which were taken from the victim's breast. One stained rag (Item 5) used to wipe the victim's ring. One sanitary pad (Item 6) worn by the victim after the assault.

**Items Submitted (Sample Pack BFI1):**

Item 1: Swab with white handle (provided as 4 replicates) - please examine this item for body fluids tested in normal laboratory casework; scenario not applicable

Item 2: Swab with pink handle (provided as 4 replicates) - please examine this item for body fluids tested in normal laboratory casework; scenario not applicable

Item 3: Swab with blue handle (provided as 4 replicates) - taken from stain on bedroom floor

Item 4: Swab with yellow handle (provided as 4 replicates) - taken from victim's breast

Item 5: One red rag used to wipe victim's ring

Item 6: One sanitary pad from victim

Control swabs (unused): One package to be used for substrate control testing, as necessary.

**Instructions:**

Please indicate the overall conclusion for each body fluid using the check boxes provided. List the tests performed and the results of each test. Item descriptions (as applicable) are provided at the top of each Item page.

For the purposes of this test, all swabs within an Item have been prepared as duplicates in order to provide sufficient sample quantity. A package of unused swabs is also provided for control purposes.

Please use the abbreviations listed in this response key to fill in the Screening Test tables. This is not an all inclusive list of tests, and should not be used to determine what tests should be performed. TESTS NOT ON THIS LIST MAY BE USED FOR SCREENING.

Test	Abbreviation	Test	Abbreviation
Acid Phosphatase	AP	Ortho-tolidine	O-tol
Alternate Light Source	ALS	Phenolphthalein-Tetramethyl benzidine	PTMB
Kastle Meyer	KM	Prostate Specific Antigen	PSA
Leucomalachite Green	LMG	Rapid Stain Identification	RSID
Microscopic	Micro	Tetramethyl benzidine	TMB

**Example**

**Blood Tests**

		Pos./Ind.	Neg.	Inc.	NT*
	<b>What is the overall conclusion for blood?</b>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Test(s) Performed	HemaTrace	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	
	KM	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	

Pos./Ind. - Positive/Indicative; Neg. - Negative; Inc. - Inconclusive; NT - Not Tested

\*Should a body fluid conclusion be marked as NT (Not Tested), please document any Item specific reasons under the "Test(s) Performed" section. All other reasons should be documented in the Additional Comments section of this data sheet.

**Item 1: Cotton tipped swabs with white plastic handle.**

Four replicate white handled swabs. Scenario is not applicable for this Item. Utilizing your laboratory policies, please examine this item for body fluids tested in normal laboratory casework.

<b>Blood Tests</b>		<b>Pos./Ind.</b>	<b>Neg.</b>	<b>Inc.</b>	<b>NT*</b>
	<b>What is the overall conclusion for blood?</b>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<b>Test(s) Performed</b>	<input type="text"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	

<b>Semen Tests</b>		<b>Pos./Ind.</b>	<b>Neg.</b>	<b>Inc.</b>	<b>NT*</b>
	<b>What is the overall conclusion for semen?</b>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<b>Test(s) Performed</b>	<input type="text"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	

<b>Saliva Tests</b>		<b>Pos./Ind.</b>	<b>Neg.</b>	<b>Inc.</b>	<b>NT*</b>
	<b>What is the overall conclusion for saliva?</b>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<b>Test(s) Performed</b>	<input type="text"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	

\*Should a body fluid conclusion be marked as NT (Not Tested), please document any Item specific reasons under the "Test(s) Performed" section. All other reasons should be documented in the Additional Comments section of this data sheet.

<b>Other Tests</b>		<b>Pos./Ind.</b>	<b>Neg.</b>	<b>Inc.</b>
	<b>Please report Other Tests as 'Body Fluid - Test Performed'</b>			
	<input type="text"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

### Item 2: Cotton tipped swabs with pink plastic handle.

Four replicate pink handled swabs. Scenario is not applicable for this Item. Utilizing your laboratory policies, please examine this item for body fluids tested in normal laboratory casework.

<b>Blood Tests</b>		Pos./Ind.	Neg.	Inc.	NT*
What is the overall conclusion for blood?		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Test(s) Performed	<input type="text"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	

<b>Semen Tests</b>		Pos./Ind.	Neg.	Inc.	NT*
What is the overall conclusion for semen?		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Test(s) Performed	<input type="text"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	

<b>Saliva Tests</b>		Pos./Ind.	Neg.	Inc.	NT*
What is the overall conclusion for saliva?		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Test(s) Performed	<input type="text"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	

\*Should a body fluid conclusion be marked as NT (Not Tested), please document any Item specific reasons under the "Test(s) Performed" section. All other reasons should be documented in the Additional Comments section of this data sheet.

<b>Other Tests</b>		Pos./Ind.	Neg.	Inc.
Please report Other Tests as 'Body Fluid - Test Performed'				
<input type="text"/>		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

### Item 3: Cotton tipped swabs with blue plastic handle.

Four replicate blue handled swabs taken from stain on bedroom floor.

Blood Tests		Pos./Ind.	Neg.	Inc.	NT*
What is the overall conclusion for blood?		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Test(s) Performed	<input type="text"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	

Semen Tests		Pos./Ind.	Neg.	Inc.	NT*
What is the overall conclusion for semen?		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Test(s) Performed	<input type="text"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	

Saliva Tests		Pos./Ind.	Neg.	Inc.	NT*
What is the overall conclusion for saliva?		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Test(s) Performed	<input type="text"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	

\*Should a body fluid conclusion be marked as NT (Not Tested), please document any Item specific reasons under the "Test(s) Performed" section. All other reasons should be documented in the Additional Comments section of this data sheet.

Other Tests		Pos./Ind.	Neg.	Inc.
Please report Other Tests as 'Body Fluid - Test Performed'				
<input type="text"/>		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>



### Item 4: Cotton tipped swabs with yellow plastic handle.

Four replicate yellow handled swabs taken from victim's breast.

Blood Tests	Pos./Ind.	Neg.	Inc.	NT*
What is the overall conclusion for blood?	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Test(s) Performed	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	

Semen Tests	Pos./Ind.	Neg.	Inc.	NT*
What is the overall conclusion for semen?	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Test(s) Performed	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	

Saliva Tests	Pos./Ind.	Neg.	Inc.	NT*
What is the overall conclusion for saliva?	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Test(s) Performed	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	

\*Should a body fluid conclusion be marked as NT (Not Tested), please document any Item specific reasons under the "Test(s) Performed" section. All other reasons should be documented in the Additional Comments section of this data sheet.

Other Tests	Pos./Ind.	Neg.	Inc.
Please report Other Tests as 'Body Fluid - Test Performed'			
	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

**Item 5: One red rag used to wipe victim's ring.**

This item of evidence is a red rag used to wipe the victim's ring.

<b>Blood Tests</b>		Pos./Ind.	Neg.	Inc.	NT*
What is the overall conclusion for blood?		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Test(s) Performed	<input type="text"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	

<b>Semen Tests</b>		Pos./Ind.	Neg.	Inc.	NT*
What is the overall conclusion for semen?		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Test(s) Performed	<input type="text"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	

<b>Saliva Tests</b>		Pos./Ind.	Neg.	Inc.	NT*
What is the overall conclusion for saliva?		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Test(s) Performed	<input type="text"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	

\*Should a body fluid conclusion be marked as NT (Not Tested), please document any Item specific reasons under the "Test(s) Performed" section. All other reasons should be documented in the Additional Comments section of this data sheet.

<b>Other Tests</b>		Pos./Ind.	Neg.	Inc.
Please report Other Tests as 'Body Fluid - Test Performed'				
<input type="text"/>		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

**Item 6: One sanitary pad worn by victim.**

This item of evidence is a sanitary pad worn by the victim after the assault.

<b>Blood Tests</b>		<b>Pos./Ind.</b>	<b>Neg.</b>	<b>Inc.</b>	<b>NT*</b>
	<b>What is the overall conclusion for blood?</b>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<b>Test(s) Performed</b>	<input type="text"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	

<b>Semen Tests</b>		<b>Pos./Ind.</b>	<b>Neg.</b>	<b>Inc.</b>	<b>NT*</b>
	<b>What is the overall conclusion for semen?</b>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<b>Test(s) Performed</b>	<input type="text"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	

<b>Saliva Tests</b>		<b>Pos./Ind.</b>	<b>Neg.</b>	<b>Inc.</b>	<b>NT*</b>
	<b>What is the overall conclusion for saliva?</b>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<b>Test(s) Performed</b>	<input type="text"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	

\*Should a body fluid conclusion be marked as NT (Not Tested), please document any Item specific reasons under the "Test(s) Performed" section. All other reasons should be documented in the Additional Comments section of this data sheet.

<b>Other Tests</b>		<b>Pos./Ind.</b>	<b>Neg.</b>	<b>Inc.</b>
	<b>Please report Other Tests as 'Body Fluid - Test Performed'</b>			
	<input type="text"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

### Additional Comments

*Please note: Any additional formatting applied in the free form space below will not transfer to the Summary Report and may cause your information to be illegible. This includes additional spacing and returns that present your responses in lists and tabular formats.*

## RELEASE OF DATA TO ACCREDITATION BODIES

The Accreditation Release is accessed by pressing the "Continue to Final Submission" button online and can be completed at any time prior to submission to CTS.

CTS submits external proficiency test data directly to ASCLD/LAB, ANAB, and/or A2LA. Please select one of the following statements to ensure your data is handled appropriately.

- This participant's data is intended for submission to ASCLD/LAB, ANAB, and/or A2LA. (Accreditation Release section below must be completed.)
- This participant's data is **not** intended for submission to ASCLD/LAB, ANAB, and/or A2LA.

Have the laboratory's designated individual complete the following steps **only if your laboratory is accredited in this testing/calibration discipline** by one or more of the following Accreditation Bodies.

**Step 1: Provide the applicable Accreditation Certificate Number(s) for your laboratory.**

ANAB Certificate No.   
(Include ASCLD/LAB Certificate here)

A2LA Certificate No.

**Step 2: Complete the Laboratory Identifying Information in its entirety.**

Authorized Contact Person and Title

Laboratory Name

Location (City/State)